

# User's guide

## XAC77 EP

ATEX certification category 2  
for use in zones 1, 21, 2, 22  
and temperature class T6 (T85°C)



**EtherNet/IP™**



II2 GD, Ex d IIC T6 Gb, Ex tb IIIC T85°C Db, IP65  
II2 GD, Ex d IIB T6 Gb, Ex tb IIIC T85°C Db, IP65

- 18-bit singleturn encoder version for high precision demands
- 30-bit multiturn encoder version for high end applications
- In compliance with ODVA specification, edition April 2017
- Class 1 Real Time Ethernet (RTE) according to IEC 61 784-2

### Suitable for the following models:

- XAC77-18-00-EP2-...
- XAC77-16-14-EP2-...

### General Contents

1 - Safety summary	26
2 - Identification	28
3 - ATEX certificate	29
4 - Safety instructions	36
5 - Mounting instructions	38
6 - Electrical connections	41
7 - Quick reference	46
8 - EtherNet/IP interface	74
9 - Integrated Web Server	132
10 - Default parameters list	153

This publication was produced by Lika Electronic s.r.l. 2023. All rights reserved. Tutti i diritti riservati. Alle Rechte vorbehalten. Todos los derechos reservados. Tous droits réservés.

This document and information contained herein are the property of Lika Electronic s.r.l. and shall not be reproduced in whole or in part without prior written approval of Lika Electronic s.r.l. Translation, reproduction and total or partial modification (photostat copies, film and microfilm included and any other means) are forbidden without written authorisation of Lika Electronic s.r.l.

The information herein is subject to change without notice and should not be construed as a commitment by Lika Electronic s.r.l. Lika Electronic s.r.l. reserves the right to make all modifications at any moments and without forewarning.

This manual is periodically reviewed and revised. As required we suggest checking if a new or updated edition of this document is available at Lika Electronic s.r.l.'s website. Lika Electronic s.r.l. assumes no responsibility for any errors or omissions in this document. Critical evaluation of this manual by the user is welcomed. Your comments assist us in preparation of future documentation, in order to make it as clear and complete as possible. Please send an e-mail to the following address [info@lika.it](mailto:info@lika.it) for submitting your comments, suggestions and criticisms.

The logo for Lika Electronic s.r.l. features the word "lika" in a bold, lowercase, sans-serif typeface. The letters are black and have a modern, clean appearance.

# General contents

User's guide.....	1
General contents.....	3
Subject index.....	10
Typographic and iconographic conventions.....	13
Preliminary information.....	14
Glossary of EtherNet/IP terms.....	15
List of abbreviations.....	24
References.....	25
<b>1 Safety summary.....</b>	<b>26</b>
1.1 Safety.....	26
1.2 Electrical safety.....	26
1.3 Mechanical safety.....	27
1.4 Operational safety.....	27
<b>2 Identification.....</b>	<b>28</b>
<b>3 ATEX certificate.....</b>	<b>29</b>
<b>4 Safety instructions.....</b>	<b>36</b>
<b>5 Mounting instructions.....</b>	<b>38</b>
5.1 Encumbrance sizes.....	38
5.2 Solid shaft (LKM-1758) and Fixing plate (LKM-1520).....	39
5.3 Mounting instructions.....	39
<b>6 Electrical connections.....</b>	<b>41</b>
6.1 PWR power supply and Ethernet connection (Figure 2).....	42
6.1.1 T8 cable specifications.....	42
6.2 Network configuration: cables, hubs, switches - Recommendations.....	42
6.3 Ground connection.....	43
6.4 Line termination.....	43
6.5 MAC address and IP address.....	44
6.6 EtherNet/IP Node ID.....	44
6.6.1 Setting the node ID.....	45
<b>7 Quick reference.....</b>	<b>46</b>
7.1 Quick setting and main functions.....	46
7.1.1 Setting the node address.....	47
7.1.2 Setting scaling function and custom resolution.....	47
7.1.3 Reading the absolute position.....	47
7.1.4 Reading the velocity value.....	48
7.1.5 Setting and executing the preset.....	48
7.1.6 Saving data.....	48
7.1.7 Restoring defaults.....	48
7.2 About Lika encoders.....	49
7.2.1 Network identity.....	50
7.2.2 Network and communication settings.....	50
7.3 Configuring the encoder with Studio 5000 V30.00 from Rockwell Automation.....	50
7.4 MAC address.....	51
7.5 Encoder installation under Studio 5000 design environment.....	52
7.5.1 Description of the EDS file.....	52
7.5.2 Configuring the network interface controller (NIC) of the computer.....	53

7.5.3 Networking the PC and the Controller.....	56
7.5.4 Configuring the driver.....	56
7.5.5 Starting a new project.....	58
7.5.6 Installing the EDS file.....	59
7.5.7 Defining the communication path.....	60
7.5.8 Adding the encoder to the project.....	62
7.5.9 Checking the communication.....	64
7.5.10 Downloading the configuration to the Controller.....	64
7.5.11 Configuring the encoder.....	65
7.5.12 How to create a sample program and send parameters.....	65
<b>8 EtherNet/IP interface.....</b>	<b>74</b>
8.1 Introduction to EtherNet/IP.....	74
8.2 CIP protocol.....	74
8.3 CIP and International Standards.....	74
8.4 EtherNet/IP adaptation to CIP.....	75
8.5 The Physical Layer.....	76
8.6 The Data Link Layer.....	76
8.7 Ethernet data packets.....	77
8.8 The Network and Transport Layers.....	78
8.9 Upper Layers: Objects, Services, and Application Data.....	79
8.9.1 EtherNet/IP services.....	79
8.9.2 Simplified EtherNet/IP Object Model Overview.....	80
8.9.3 Exposing Application Data with CIP.....	80
8.9.4 Types of EtherNet/IP communications.....	82
8.9.5 Types of EtherNet/IP devices.....	83
8.10 ODVA.....	84
8.11 EDS file.....	84
8.12 Object Library.....	85
8.12.1 Class 01h: Identity Object.....	87
8.12.1.1 Supported Class Services.....	87
8.12.1.2 Class Attributes.....	87
01-01 Revision.....	87
01-02 Max Instance.....	87
01-03 Number of Instances.....	87
8.12.1.3 Supported Instance Services.....	87
8.12.1.4 Instance Attributes.....	88
01-01-01 Vendor ID.....	88
01-01-02 Device type.....	88
01-01-03 Product code.....	88
01-01-04 Revision.....	88
01-01-05 Status.....	89
Owned.....	89
Configured.....	89
Extended device status.....	89
Minor recoverable fault.....	89
Minor unrecoverable fault.....	89
Major recoverable fault.....	90
Major unrecoverable fault.....	90
01-01-06 Serial number.....	90
01-01-07 Product name.....	90



8.12.2 Class 02h: Message Router Object.....	91
8.12.3 Class 04h: Assembly Object.....	92
8.12.3.1 Supported Class Services.....	92
8.12.3.2 Class Attributes.....	92
04-01 Revision.....	92
04-02 Max Instance.....	92
8.12.3.3 Supported Instance Services.....	92
8.12.3.4 Supported connection types.....	92
Input Only connection.....	92
Listen Only connection.....	93
8.12.3.5 Instance Attributes.....	93
8.12.3.6 I/O Assembly Data Attribute Format.....	94
8.12.3.7 Configuration Assembly.....	94
8.12.4 Class 06h: Connection Manager Object.....	96
8.12.5 Class 23h: Position Sensor Object.....	97
8.12.5.1 Supported Class Services.....	97
8.12.5.2 Class Attributes.....	97
23-01 Revision.....	97
8.12.5.3 Supported Instance Services.....	97
8.12.5.4 Instance Attributes.....	98
23-01-03 Position value.....	98
23-01-0B Position Sensor type.....	98
23-01-0C Direction Counting Toggle.....	98
23-01-0E Scaling Function Control.....	98
23-01-10 Measuring Units per Span.....	99
23-01-11 Total Measuring Range.....	101
23-01-13 Preset Value.....	102
23-01-18 Velocity Value.....	104
23-01-19 Velocity Format.....	104
23-01-29 Operating Status.....	105
Counting direction.....	105
Scaling function.....	105
23-01-2A Physical Resolution Span.....	105
23-01-2B Number of Spans.....	106
23-01-2C Alarms.....	106
Diagnostic error.....	106
Flash memory error.....	106
23-01-2D Supported Alarms.....	107
23-01-2E Alarm Flag.....	107
23-01-2F Warnings.....	107
Parameters Error.....	107
23-01-30 Supported Warnings.....	108
23-01-31 Warning Flag.....	108
23-01-32 Operating Time.....	108
23-01-33 Offset Value.....	108
23-01-64 Application-DSC FW Version.....	109
23-01-65 Hardware Version.....	109
23-01-66 Network-DSC FW Version.....	109
23-01-67 Wrong Parameters List.....	110
Measuring Units per Span exceeded.....	110

Total Measuring Range exceeded.....	110
Preset Value exceeded.....	110
Offset Value exceeded.....	110
<b>23-01-68 Command Register.....</b>	<b>111</b>
Activate Preset.....	111
Save Parameters.....	112
Restore Parameters to Defaults.....	112
<b>23-01-69 Warning/Alarm Flags.....</b>	<b>113</b>
<b>23-01-6A Encoder Serial Number.....</b>	<b>113</b>
<b>23-01-6C Network-DSC Serial Number.....</b>	<b>114</b>
8.12.6 Class F5h: TCP/IP Interface Object.....	115
8.12.6.1 Supported Class Services.....	115
8.12.6.2 Class Attributes.....	115
<b>F5-01 Revision.....</b>	<b>115</b>
<b>F5-02 Max Instance.....</b>	<b>115</b>
<b>F5-03 Number of Instances.....</b>	<b>115</b>
8.12.6.3 Supported Instance Services.....	115
8.12.6.4 Instance Attributes.....	116
<b>F5-01-01 Status.....</b>	<b>116</b>
Interface Configuration Status.....	116
Mcast Pending.....	116
Interface Configuration Pending.....	116
AcStatus.....	116
AcdFault.....	116
<b>F5-01-02 Configuration Capability.....</b>	<b>116</b>
BOOTP Client.....	116
DNS Client.....	116
DHCP Client.....	116
DHCP-DNS Update.....	116
Configuration Settable.....	116
Hardware Configurable.....	117
Reset Required at change.....	117
AcCapable.....	117
<b>F5-01-03 Configuration Control.....</b>	<b>117</b>
<b>F5-01-04 Physical Link Object.....</b>	<b>117</b>
Path size.....	117
Path.....	117
<b>F5-01-05 Interface Configuration.....</b>	<b>117</b>
IP Address.....	117
Network Mask.....	117
Gateway Address.....	117
Name Server.....	117
Name Server 2.....	117
Domain Name.....	118
<b>F5-01-06 Host Name.....</b>	<b>118</b>
<b>F5-01-08 TTL Value.....</b>	<b>118</b>
<b>F5-01-09 Mcast Config.....</b>	<b>118</b>
Alloc Control.....	118
Num Mcast.....	118

Mcast Start Addr.....	118
F5-01-0A SelectAcid.....	118
F5-01-0B LastConflictDetected.....	119
AcidActivity.....	119
RemoteMAC.....	119
ArpPDU.....	119
F5-01-0C EtheNet/IP QuickConnect.....	119
F5-01-0D Encapsulation Inactivity Timeout.....	119
8.12.7 Class F6h: Ethernet Link Object.....	120
8.12.7.1 Supported Class Services.....	120
8.12.7.2 Class Attributes.....	120
F6-01 Revision.....	120
F6-02 Max Instance.....	120
F6-03 Number of Instances.....	120
8.12.7.3 Supported Instance Services.....	120
8.12.7.4 Instance Attributes.....	121
F6-01-01 Interface Speed.....	121
F6-01-02 Interface Flags.....	121
Link Status.....	121
Half/Full Duplex.....	121
Negotiation Status.....	121
Manual Setting Requires Reset.....	121
Local Hardware Fault.....	121
F6-01-03 Physical Address.....	121
F6-01-04 Interface Counters.....	122
In Octets.....	122
In Ucast Packets.....	122
In NUcast Packets.....	122
In Discards.....	122
In Errors.....	122
In Unknown Protos.....	122
Out Octets.....	122
Out Ucast Packets.....	122
Out NUcast Packets.....	122
Out Discards.....	122
Out Errors.....	122
F6-01-05 Media Counters.....	122
Alignment Errors.....	122
FCS Errors.....	122
Single Collisions.....	123
Multiple Collisions.....	123
SQE Test Errors.....	123
Deferred Transmissions.....	123
Late Collisions.....	123
Excessive Collisions.....	123
MAC Transmit Errors.....	123
Carrier Sense Errors.....	123
Frame Too Long.....	123
MAC Receive Errors.....	123

<b>F6-01-06 Interface Control</b> .....	123
<b>Control Bits</b> .....	123
Auto-negotiate.....	123
Forced Duplex Mode.....	124
<b>Forced Interface Speed</b> .....	124
<b>F6-01-07 Interface Type</b> .....	124
<b>F6-01-08 Interface State</b> .....	124
<b>F6-01-09 Admin State</b> .....	125
<b>F6-01-0A Interface Label</b> .....	125
<b>F6-01-0B Interface Capability</b> .....	125
<b>Manual Setting Requires Reset</b> .....	125
<b>Auto-negotiate</b> .....	126
<b>Auto-MDIX</b> .....	126
<b>Manual Speed/Duplex</b> .....	126
8.12.8 Class 47h: Device Level Ring (DLR) Object.....	127
8.12.8.1 Supported Class Services.....	127
8.12.8.2 Class Attributes.....	127
<b>47-01 Revision</b> .....	127
8.12.8.3 Supported Instance Services.....	127
8.12.8.4 Instance Attributes.....	127
<b>47-01-01 Network Topology</b> .....	127
<b>47-01-02 Network Status</b> .....	128
<b>47-01-0A Active Supervisor Address</b> .....	128
<b>47-01-0C Capability Flags</b> .....	128
<b>Announce-based Ring Node</b> .....	128
<b>Beacon-based Ring Node</b> .....	128
<b>Supervisor Capable</b> .....	128
<b>Redundant Gateway Capable</b> .....	128
<b>Flush_Table Frame Capable</b> .....	128
8.12.9 Class 48h: Quality of Service (QoS) Object.....	130
8.12.9.1 Supported Class Services.....	130
8.12.9.2 Class Attributes.....	130
<b>47-01 Revision</b> .....	130
8.12.9.3 Supported Instance Services.....	130
8.12.9.4 Instance Attributes.....	130
<b>48-01-01 802.1Q Tag Enable</b> .....	130
<b>48-01-04 DSCP Urgent</b> .....	131
<b>48-01-05 DSCP Scheduled</b> .....	131
<b>48-01-06 DSCP High</b> .....	131
<b>48-01-07 DSCP Low</b> .....	131
<b>48-01-08 DSCP Explicit</b> .....	131
<b>9 Integrated Web Server</b> .....	132
9.1 Integrated web server – Preliminary information.....	132
9.2 Web server Home page.....	133
9.3 Encoder position and speed.....	134
9.3.1 Specific notes on using Internet Explorer.....	135
9.4 Encoder information (EtherNet/IP attributes).....	136
9.5 Setting the Preset value.....	137
9.6 Setting the attributes.....	139
9.7 Firmware upgrade.....	143

9.8 Network configuration.....	149
<b>10 Default parameters list.....</b>	<b>153</b>
10.1 Attributes of the Class 01h Identity Object.....	153
10.2 Attributes of the Class 23h Position Sensor Object.....	153

# Subject index

## O

01-01 Revision.....	87
01-01-01 Vendor ID.....	88
01-01-02 Device type.....	88
01-01-03 Product code.....	88
01-01-04 Revision.....	88
01-01-05 Status.....	89
01-01-06 Serial number.....	90
01-01-07 Product name.....	90
01-02 Max Instance.....	87
01-03 Number of Instances.....	87
04-01 Revision.....	92
04-02 Max Instance.....	92

## 2

23-01 Revision.....	97
23-01-03 Position value.....	98
23-01-0B Position Sensor type.....	98
23-01-0C Direction Counting Toggle.....	98
23-01-0E Scaling Function Control.....	98
23-01-10 Measuring Units per Span.....	99
23-01-11 Total Measuring Range.....	101
23-01-13 Preset Value.....	102
23-01-18 Velocity Value.....	104
23-01-19 Velocity Format.....	104
23-01-29 Operating Status.....	105
23-01-2A Physical Resolution Span.....	105
23-01-2B Number of Spans.....	106
23-01-2C Alarms.....	106
23-01-2D Supported Alarms.....	107
23-01-2E Alarm Flag.....	107
23-01-2F Warnings.....	107
23-01-30 Supported Warnings.....	108
23-01-31 Warning Flag.....	108
23-01-32 Operating Time.....	108
23-01-33 Offset Value.....	108
23-01-64 Application-DSC FW Version.....	109
23-01-65 Hardware Version.....	109
23-01-66 Network-DSC FW Version.....	109
23-01-67 Wrong Parameters List.....	110
23-01-68 Command Register.....	111
23-01-69 Warning/Alarm Flags.....	113
23-01-6A Encoder Serial Number.....	113
23-01-6C Network-DSC Serial Number.....	114

## 4

47-01 Revision.....	127, 130
47-01-01 Network Topology.....	127
47-01-02 Network Status.....	128
47-01-0A Active Supervisor Address.....	128
47-01-0C Capability Flags.....	128
48-01-01 802.1Q Tag Enable.....	130
48-01-04 DSCP Urgent.....	131
48-01-05 DSCP Scheduled.....	131
48-01-06 DSCP High.....	131
48-01-07 DSCP Low.....	131
48-01-08 DSCP Explicit.....	131

## A

AcdActivity.....	119
AcdCapable.....	117
AcdFault.....	116
AcdStatus.....	116
Activate Preset.....	111
Alignment Errors.....	122
Alloc Control.....	118
Announce-based Ring Node.....	128
ArpPDU.....	119
Auto-MDIX.....	126
Auto-negotiate.....	123, 126

## B

Beacon-based Ring Node.....	128
BOOTP Client.....	116

## C

Carrier Sense Errors.....	123
Configuration Settable.....	116
Configured.....	89
Control Bits.....	123
Counting direction.....	105

## D

Deferred Transmissions.....	123
DHCP Client.....	116
DHCP-DNS Update.....	116
Diagnostic error.....	106
DNS Client.....	116
Domain Name.....	118

## E

Excessive Collisions.....	123
Extended device status.....	89

## F

F5-01 Revision.....	115
F5-01-01 Status.....	116
F5-01-02 Configuration Capability.....	116
F5-01-03 Configuration Control.....	117
F5-01-04 Physical Link Object.....	117
F5-01-05 Interface Configuration.....	117
F5-01-06 Host Name.....	118
F5-01-08 TTL Value.....	118
F5-01-09 Mcast Config.....	118
F5-01-0A SelectAcid.....	118
F5-01-0B LastConflictDetected.....	119
F5-01-0C EtheNet/IP QuickConnect.....	119
F5-01-0D Encapsulation Inactivity Timeout.....	119
F5-02 Max Instance.....	115
F5-03 Number of Instances.....	115
F6-01 Revision.....	120
F6-01-01 Interface Speed.....	121
F6-01-02 Interface Flags.....	121
F6-01-03 Physical Address.....	121
F6-01-04 Interface Counters.....	122
F6-01-05 Media Counters.....	122
F6-01-06 Interface Control.....	123
F6-01-07 Interface Type.....	124
F6-01-08 Interface State.....	124
F6-01-09 Admin State.....	125
F6-01-0A Interface Label.....	125
F6-01-0B Interface Capability.....	125
F6-02 Max Instance.....	120
F6-03 Number of Instances.....	120
FCS Errors.....	122
Flash memory error.....	106
Flush_Table Frame Capable.....	128
Forced Duplex Mode.....	124
Forced Interface Speed.....	124
Frame Too Long.....	123

## G

Gateway Address.....	117
----------------------	-----

## H

Half/Full Duplex.....	121
Hardware Configurable.....	117

## I

In Discards.....	122
In Errors.....	122
In NUCast Packets.....	122
In Octets.....	122
In Ucast Packets.....	122
In Unknown Protos.....	122
Interface Configuration Pending.....	116

Interface Configuration Status.....	116
Invalid Attribute Value.....	124
IP Address.....	117

## L

Late Collisions.....	123
Link Status.....	121
Local Hardware Fault.....	121

## M

MAC Receive Errors.....	123
MAC Transmit Errors.....	123
Major recoverable fault.....	90
Major unrecoverable fault.....	90
Manual Setting Requires Reset.....	121, 125
Manual Speed/Duplex.....	126
Mcast Pending.....	116
Mcast Start Addr.....	118
Measuring Units per Span exceeded.....	110
Minor recoverable fault.....	89
Minor unrecoverable fault.....	89
Multiple Collisions.....	123

## N

Name Server.....	117
Name Server 2.....	117
Negotiation Status.....	121
Network Mask.....	117
Num Mcast.....	118

## O

Object State Conflict.....	124
Offset Value exceeded.....	110
Out Discards.....	122
Out Errors.....	122
Out NUCast Packets.....	122
Out Octets.....	122
Out Ucast Packets.....	122
Owned.....	89

## P

Parameters Error.....	107
Path.....	117
Path size.....	117
Preset Value exceeded.....	110

## R

Redundant Gateway Capable.....	128
RemoteMAC.....	119
Reset Required at change.....	117
Restore Parameters to Defaults.....	112

## S

Save Parameters.....	112	Supervisor Capable.....	128
Scaling function.....	105	<b>T</b>	
Single Collisions.....	123	Total Measuring Range exceeded.....	110
SQE Test Errors.....	123		






# Typographic and iconographic conventions

In this guide, to make it easier to understand and read the text the following typographic and iconographic conventions are used:

- parameters and objects both of the device and the interface are colored in **GREEN**;
- alarms are colored in **RED**;
- states are colored in **FUCSIA**.

When scrolling through the text some icons can be found on the side of the page: they are expressly designed to highlight the parts of the text which are of great interest and significance for the user. Sometimes they are used to warn against dangers or potential sources of danger arising from the use of the device. You are advised to follow strictly the instructions given in this guide in order to guarantee the safety of the user and ensure the performance of the device. In this guide the following symbols are used:

	This icon, followed by the word WARNING, is meant to highlight the parts of the text where information of great significance for the user can be found: user must pay the greatest attention to them! Instructions must be followed strictly in order to guarantee the safety of the user and a correct use of the device. Failure to heed a warning or comply with instructions could lead to personal injury and/or damage to the unit or other equipment.
	This icon, followed by the word NOTE, is meant to highlight the parts of the text where important notes needful for a correct and reliable use of the device can be found. User must pay attention to them! Failure to comply with instructions could cause the equipment to be set wrongly: hence a faulty and improper working of the device could be the consequence.
	This icon is meant to highlight the parts of the text where suggestions useful for making it easier to set the device and optimize performance and reliability can be found. Sometimes this symbol is followed by the word EXAMPLE when instructions for setting parameters are accompanied by examples to clarify the explanation.

# Preliminary information

This guide is designed to provide the most complete information the operator needs to correctly and safely install and operate the following encoders **equipped with EtherNet/IP interface**:

<b>XAC77-18-00-EP2-...</b>	<b>(18 bit resolution singleturn encoder)</b>
<b>XAC77-16-14-EP2-...</b>	<b>(16 +14 bit resolution multiturn encoder)</b>

XAC77 encoders with EtherNet/IP interface support the complete package of EtherNet/IP functions and attributes and comply with the latest ODVA specification. In more detail they are **22 hex type devices** and comply with "Device Profiles, Encoder Device Type 22 hex" specifications of the "CIP NETWORKS LIBRARY". They are **Class 1 Real Time Ethernet (RTE) devices** according to IEC 61 784-2 for time-critical and high-speed industrial automation applications and implement **DLR Device Level Ring protocol** for continuous system operation even when a fault occurs.

XAC77 ATEX encoders are category 2 "high level of protection" devices with airtight, explosion- and flameproof enclosure for use in Zones 1, 2, 21 and 22 and in the temperature class T6 (T85°C). For complete information on ATEX certification please refer to the enclosed documentation.

To make it easier to read the text, this guide can be divided into some main sections.

In the first section (from chapter 1 to chapter 6) general information concerning the safety, the ATEX documentation, the mechanical installation, and the electrical connection is provided.

In the second section (chapter 7) information on how to install and configure the encoder under the Studio 5000 development environment as well as tips for setting up and running properly and efficiently the unit are provided.

In the third section (chapter 8) both general and specific information is given on the EtherNet/IP interface. In this section the interface features and the parameters implemented in the unit are fully described.

In the fourth section (chapter 9) the Integrated Web Server is described.

# Glossary of EtherNet/IP terms

EtherNet/IP, like many other networking systems, has a set of unique terminology. Table below contains a few of the technical terms used in this guide to describe the Ethernet/IP interface. They are listed in alphabetical order.

<b>Adapter</b>	Devices such as drives, controllers, and computers usually require an adapter to provide a communication interface between them and a network such as EtherNet/IP. An adapter reads data on the network and transmits it to the connected device. It also reads data in the device and transmits it to the network.
<b>Adapter Class Device</b>	An Adapter Class product emulates functions provided by traditional rack-adapter products. This type of node exchanges real-time I/O data with a Scanner Class product. It does not initiate connections on its own (see I/O Adapter).
<b>Application I/O Trigger</b>	The Application Trigger is one of three types of I/O triggers supported by CIP for the exchange of data on I/O connections. It is very similar to the CoS trigger and not common.
<b>Application Objects</b>	A reference to multiple Object Classes that implement product-specific features.
<b>Attribute</b>	<p>Attributes are characteristics of an Object and/or an Object Class. They provide a description of an externally visible characteristic or feature of an object. Typically, Attributes provide status information or govern the operation of an Object. For example: the ASCII name of an object; and the repetition rate of a cyclic object.</p> <p>The Attribute part of an object specification is divided into two sections:</p> <ul style="list-style-type: none"><li>• Class attributes;</li><li>• Instance attributes.</li></ul>
<b>Behavior</b>	<p>The relationship between attribute values and services, i.e. a specification of how an object acts. Actions results from different events the object detects, such as receiving service request, detecting internal faults or elapsing timers.</p> <p>The Behavior of an Object indicates how it responds to particular events. For example, a person can be abstractly viewed as an Instance within the Class Human. Generally speaking, all humans have the same set of attributes: age, gender, etc., yet, because the values of each attribute vary, each of us looks/behaves in a distinct fashion.</p>
<b>BOOTP (Bootstrap Protocol)</b>	BOOTP lets the device configure itself dynamically at boot time if the network has a BOOTP server. The BOOTP server assigns the device a pre-configured IP address, a subnet mask, and a gateway address; therefore, you do not have to

	configure these using the parameters in the device. BOOTP can make it easier to administer an EtherNet/IP network.
<b>Bridge</b>	A bridge refers to a network device that can route messages from one Ethernet network to another.
<b>Broadcast</b>	A broadcast transmission is a packet that all nodes on the network receive.
<b>Change of State I/O Trigger</b>	Change of State (CoS) is one of three types of I/O triggers supported by CIP for the exchange of data on Class 0 or 1 I/O connections. CoS endpoints send their messages when a change occurs. The data is also sent at a background cyclic interval if no change occurs to keep the connection from timing out.
<b>CIP (Common Industrial Protocol)</b>	CIP is the transport and application layer protocol used for messaging over EtherNet/IP, ControlNet, and DeviceNet networks. The protocol is used for implicit messaging (real time I/O) and explicit messaging (configuration, data collection, and diagnostics).
<b>Class</b>	<p>A class (of objects) is a set of objects that all represent the same kind of system component. A class is a generalization of an object. All objects in a class are identical in form and behavior, but may contain different attribute values. A class contains the objects that relate to a device, they are organized in instances.</p> <p>Ethernet/IP encoders from Lika supports the following classes:</p> <ul style="list-style-type: none"> <li>• Identity Object (Class Code 01h);</li> <li>• Message Router Object (Class Code 02h);</li> <li>• Assembly Object (Class Code 04h);</li> <li>• Connection Manager Object (Class Code 06h);</li> <li>• Position Sensor Object (Class Code 23h);</li> <li>• TCP/IP Interface Object (Class Code F5h);</li> <li>• EtherNet Link Object (Class Code F6h);</li> <li>• Device Level Ring (DLR) Object (Class Code 47h);</li> <li>• Quality of Service (QoS) Object (Class Code 48h).</li> </ul>
<b>Class Attribute</b>	A Class Attribute is an attribute whose scope is that of the class as a whole, rather than any one particular instance. Therefore, the list of Class Attributes is different than the list of Instance Attributes. CIP defines the Instance ID value zero (0) to designate the Class level versus a specific Instance within the Class.
<b>Class code</b>	A hexadecimal identifier assigned to each CIP object.
<b>Connected Messaging</b>	A CIP connection is a relationship between two or more application objects on different nodes. The connection establishes a virtual circuit between end points for transfer of data. Node resources are reserved in advance of data transfer and are dedicated and always available. Connected messaging reduces data handling of messages in the node. Connected messages can be Implicit (I/O) or Explicit.

<b>Connection Establishment/Close</b>	Connections are established Connection Originators using the ForwardOpen service and closed by using the ForwardClose service. Connection clean-up takes place when either connection end point times out.
<b>Connection Originator</b>	The source node that makes a request to a Connection Target for a connection. It can initiate either an I/O connection or explicit message connection using the ForwardOpen service.
<b>Connection Target</b>	Destination for I/O or explicit message connection requests. Responds to a connection request with a ForwardOpen service response.
<b>Client</b>	Within a client/server model, the client is the device that sends a request to a server. The client expects a response from the server.
<b>Communication Objects</b>	A reference to the Object Classes that manage and provide the run-time exchange of implicit (I/O) and explicit messages.
<b>Consumer</b>	Within the producer/consumer model, the consumer is one of potentially several consuming devices that picks up a message placed on the network by a producing device.
<b>Controller</b>	A controller, also called programmable logic controller, is a solid-state control system that has a user-programmable memory for storage of instructions to implement specific functions such as I/O control, logic, timing, counting, report generation, communication, arithmetic, and data file manipulation. A controller consists of a central processor, input/output interface, and memory.
<b>Cyclic I/O Trigger</b>	Cyclic is one of three types of I/O triggers supported by CIP for the exchange of data on Class 0 or 1 I/O connections. Endpoints send their messages at pre-determined cyclic time intervals.
<b>Data Rate</b>	The data rate is the speed at which data is transferred on the EtherNet/IP network. You can set the device to a data rate of 10 Mbps Full-Duplex, 10 Mbps Half-Duplex, 100 Mbps Full-Duplex, or 100 Mbps Half-Duplex. If another device on the network sets or auto-negotiates the data rate, you can set the device to automatically detect the data rate.
<b>DSI (Drive Serial Interface)</b>	DSI stands for Drive Serial Interface, it is based on the ModBus RTU serial communication protocol.
<b>DSI Peripheral</b>	A device that provides an interface between DSI and a network or user.
<b>DSI Product</b>	A device that uses the DSI communications interface to communicate with one or more peripheral devices. For example, a motor drive is a DSI product.
<b>Duplex</b>	Duplex describes the mode of communication. Full-duplex communications let a device exchange data in both directions at the same time. Half-duplex communications let a device exchange data only in one direction at a time. The duplex used

	by the adapter depends on the type of duplex that other network devices, such as switches, support.
<b>EDS (Electronic Data Sheet) Files</b>	EDS files are simple text files that are used by network configuration tools for EtherNet/IP to describe products so that you can easily commission them on a network. EDS files describe a product device type, revision, and configurable parameters. EDS files can be downloaded from Lika web site.
<b>EDS File</b>	An Electronic Data Sheet (EDS) is an ASCII text file that describes the features of an EtherNet/IP device and is used by software tools for device and network connection configuration.
<b>EEPROM</b>	EEPROM is the permanent memory of a device. Devices such as the encoder store parameters and other information in EEPROM so that they are not lost when the device loses power. EEPROM is sometimes called "NVS (Non-Volatile Storage)".
<b>Encapsulation Protocol</b>	Defines the communication relationship between two nodes known as an Encapsulation Session. The Encapsulation Protocol uses TCP/UDP Port 44818 for several Encapsulation Commands and for CIP Explicit Messaging. An example encapsulation command is the List_Identity Command that performs a "network who". An Encapsulation Session must be established before any CIP communications can take place. Data format for the Encapsulation Protocol is Little-Endian.
<b>EtherNet/IP Network</b>	Ethernet/IP (Industrial Protocol) is an open producer-consumer communication network based on the Ethernet standard (IEEE 802.3), TCP/IP, UDP/IP, and CIP. Designed for industrial communications, both I/O and explicit messages can be transmitted over the network. Each device is assigned a unique IP address and transmits data on the network. The number of devices that an EtherNet/IP network can support depends on the class of IP address. For example, a network with a Class C IP address can have 254 nodes. General information about EtherNet/IP and the EtherNet/IP specification are maintained by the Open DeviceNet Vendor's Association (ODVA). ODVA is online at <a href="http://www.odva.org">http://www.odva.org</a> .
<b>Exclusive Owner Connection</b>	This is one of three types of Implicit (I/O) Connections. It is a Class 0 or 1 bidirectional connection to an Output connection point (typically an Assembly Object), where the data of this assembly can only be controlled by one Scanner. There may be a connection to an input assembly; this data is being sent to the scanner. If the input data length is zero, then this direction becomes a Heartbeat connection.
<b>Explicit Message Client</b>	An explicit message client initiates request/response oriented communications with other devices. Examples of explicit message clients are HMI devices, programming tools, or PC or Linux based applications that gather data from control devices.

<b>Explicit Message Server</b>	An explicit message server responds to request/response oriented communications initiated by explicit message clients. An example of an explicit message server is a bar code reader.
<b>Explicit Messaging</b>	Explicit Messages are used to transfer data that does not require continuous updates. They are typically used to configure, monitor, and diagnose a device over the network. Explicit Messages can be sent as a connected or unconnected message. CIP defines an Explicit Messaging protocol that states the meaning of the message. This messaging protocol is contained in the message data. Explicit Messaging provide the means by which typical request/response oriented functions are performed (e.g., module configuration). These messages are typically point-to-point. Message rates and latency requirements are typically not as demanding as I/O messaging.
<b>ForwardOpen Service Request</b>	The ForwardOpen Service Request is sent by the Connection Originator and received by the Connection Target to open and establish explicit and I/O connections. The ForwardOpen Service request and associated response contains all of the connection parameters, including transport class, production trigger, timing information, electronic key and connection IDs.
<b>Gateway</b>	A gateway is a device on a network that connects an individual network to a system of networks. When a node needs to communicate with a node on another network, a gateway transfers the data between the two networks.
<b>Hardware Address</b>	Each Ethernet device has a unique hardware address (sometimes called a MAC address) that is 48 bits. The address appears as six digits separated by colons (for example, xx:xx:xx:xx:xx:xx). Each digit has a value between 0 and 255 (0x00 and 0xFF). This address is assigned in the hardware and cannot be changed. It is required to identify the device if you are using a BOOTP utility.
<b>I/O Adapter</b>	An I/O Adapter receives implicit communications requests from an I/O Scanner then produces and consumes its I/O data, typically at the requested cyclic rate. An I/O Adapter can be a simple digital input device, or something more complex such as a modular pneumatic valve system.
<b>I/O Client</b>	Function that uses the I/O messaging services of another (I/O Server) device to perform a task. Initiates a request for an I/O message to the server module. The I/O Client is a Connection Originator of Implicit Message connections
<b>I/O Data</b>	I/O data, sometimes called "implicit messages" or "input/output," transmit time-critical data. The terms "input" and "output" are defined from the controller's point of view. Output is transmitted by the controller and consumed by the device. Input is transmitted by the device and consumed by the controller.
<b>I/O Messaging</b>	Used interchangeably with the term Implicit Messaging.

<b>I/O Scanner</b>	An I/O scanner initiates implicit connections with I/O adapter devices, i.e., it is an I/O Client. A scanner is typically the most complex type of EtherNet/IP device, as it must deal with issues such as configuration of which connections to make, and how to configure the adapter device. Scanners also typically support initiating explicit messages, i.e., it is also an Explicit Message Client. A programmable controller is an example of an I/O scanner (used interchangeably with Scanner Class).
<b>I/O Server</b>	Function that provides I/O messaging services to another (I/O Client) device. Responds to a request from the I/O Client for an I/O connection. An I/O Server is the target of the implicit message connection request.
<b>Implicit Messaging</b>	Implicit Messages are exchanged across I/O Connections with an associated Connection ID. The Connection ID defines the meaning of the data and establishes the regular/repeated transport rate and the transport class. No messaging protocol is contained within the message data as with Explicit Messaging. Implicit Messages can be point to point (unicast) or multicast and are used to transmit application specific I/O data. This term is used interchangeably with the term I/O Messaging. Implicit Messaging on EtherNet/IP uses UDP/IP frames on port 2222. They are typically Class 0 or 1 and of the type Exclusive Owner, Input Only and Listen Only.
<b>Input Only Connection</b>	This is one of three types of Implicit (I/O) Connections. It is a Class 0 or 1 Connection to an Input connection point (typically an assembly object). The scanner receives input data from the target device and produces a Heartbeat to the target device. There is no Output data.
<b>Instance</b>	An object instance is the actual representation of a particular object within a class, i.e. it is a specific and real (physical) occurrence of an object. For example: New Zealand is an instance of the object class Country. Each instance of a class has the same attributes, but also has its own particular set of attribute values. The terms Object, Instance, and Object Instance all refer to a specific Instance.
<b>Instance Attribute</b>	An Instance Attribute is an attribute whose value is unique to an object instance and whose definition is shared by all instances of an object. Each instance need only support the optional attributes that apply to it. If an instance does not support an optional attribute, the Attribute Not Supported (General Status code 0x14) error shall be returned for services targeting that attribute.
<b>IP Address</b>	A unique IP address identifies each node on an EtherNet/IP network. An IP address consists of 32 bits that are divided into four segments of one byte each. It appears as four decimal integers separated by periods (xxx.xxx.xxx.xxx). Each "xxx" can have a decimal value from 0 to 255. For example, an IP address could be 192.168.0.1. An IP address has two parts: a network ID and a host ID. The class of network determines the



	<p>format of the address.</p> <div> <div>017152331</div> <div>Class A</div> <div> <div>0</div> <div>Network ID</div> <div>Host ID</div> </div> </div> <div> <div>017152331</div> <div>Class B</div> <div> <div>1</div> <div>0</div> <div>Network ID</div> <div>Host ID</div> </div> </div> <div> <div>0127152331</div> <div>Class C</div> <div> <div>1</div> <div>1</div> <div>0</div> <div>Network ID</div> <div>Host ID</div> </div> </div> <p>The number of devices on your EtherNet/IP network will vary depending on the number of bytes that are used for the network address. In many cases you are given a network with a Class C address, in which the first three bytes contain the network address (subnet mask = 255.255.255.0). This leaves 8 bits or 256 addresses on your network. Because two addresses are reserved for special uses (0 is an address for the network usually used by the router, and 255 is an address for broadcast messages to all network devices), you have 254 addresses to use on a Class C address block. You must ensure that each device on the Internet has a unique address. You can then set the unique IP address for the device by using a BOOTP server or by manually configuring parameters in the device. The device reads the values of these parameters only at power-up.</p>
<b>Listen Only Connection</b>	<p>This is one of three types of Implicit Connections. It is a Class 0 or 1 Connection to an Input connection point (typically an assembly object). The scanner receives input data from the target device and produces a Heartbeat to the target device. There is no Output data. A Listen Only Connection can only be attached to an existing Exclusive Owner or Input Only Connection. If this underlying connection closes, then the Listen Only connection will also be closed or timed out.</p>
<b>Master</b>	<p>EtherNet/IP does not use Master/Slave technology or terminology.</p>
<b>Message Client</b>	<p>Function that uses the Explicit messaging services of another (Message Server) device to perform a task. Initiates an Explicit Message request to the server device.</p>
<b>Message Server</b>	<p>Function that provides Explicit Messaging services to another (Message Client) device. Responds to an Explicit Message request from the Message Client.</p>
<b>Multicast</b>	<p>Multicast is the single transmission of an I/O data packet that may be consumed by multiple devices using multicast IP and Ethernet destination addresses. See Producer/Consumer Communications Model.</p>
<b>Object</b>	<p>A CIP node is modeled as a collection of Objects. An Object provides an abstract representation of a particular component within a product. The realization of this abstract object model</p>

	within a product is implementation dependent. In other words, a product internally maps this object model in a fashion specific to its implementation.
<b>Ping</b>	A ping is a message that is sent by a DSI product to its peripheral devices. They use the ping to gather data about the product, including whether it can receive messages and whether they can log in for control.
<b>Point to Point (Unicast)</b>	Point to Point or Unicast is the transmission of data to a single device.
<b>Producer</b>	Within the producer/consumer model, the producing device places a message on the network for consumption by one or several consumers. Generally, the produced message is not directed to a specific consumer.
<b>Producer/Consumer Communications Model</b>	For I/O Connections, CIP supports object-oriented Producer/Consumer communication. Connection identifiers embedded into each message are used by devices to determine which messages they should "consume" from other devices that "produce" messages. This enables efficient use of network bandwidth by transmitting information only once. Less bandwidth equates to greater efficiency and overall speed. EtherNet/IP uses IP multicast and Ethernet multicast destination addressing to implement this capability.
<b>Requested Packet Interval (RPI)</b>	EtherNet/IP devices typically produce or consume data based upon a Requested Packet Interval (RPI) value. Producer devices send data packets at a predetermined time interval based on the RPI, whereas consumer devices will listen for a packet of data at a given RPI.
<b>Scanner Class</b>	A Scanner Class product exchanges real-time I/O data with Adapter Class and Scanner Class products. This type of node can respond to connection requests and can also initiate connections to target devices (see I/O Scanner).
<b>Server</b>	Within a client/server model, the server is the device that receives a request from a client. The server is expected to give a response to the client.
<b>Service (common service)</b>	A list of the common services defined for the object. A function supported by an object and/or object class.
<b>Service (object-specific service)</b>	The full specifications of any services unique to the object.
<b>Service code</b>	Service codes are used to define the action that is requested to take place when an object or parts of an object are addressed through explicit messages. They are used to access classes or the attributes of a class or to generate specific events.
<b>Slave</b>	EtherNet/IP does not use Master/Slave technology or terminology.
<b>Subnet Mask</b>	A subnet mask is an extension to the IP addressing scheme

	that lets you use a single network ID for multiple physical networks. A bit mask identifies the part of the address that specifies the network and the part of the address that specifies the unique node on the network. A "1" in the subnet mask indicates the bit is used to specify the network. A "0" in the subnet mask indicates that the bit is used to specify the node. For example, a subnet mask on a Class C address may appear as follows: 11111111 11111111 11111111 11000000 (255.255.255.192). This mask indicates that 26 bits are used to identify the network and 6 bits are used to identify devices on each network. Instead of a single physical Class C network with 254 devices, this subnet mask divides it into four networks with up to 62 devices each.
<b>Switches</b>	Switches are network devices that provide virtual connections that help to control collisions and reduce traffic on the network. They are able to reduce network congestion by transmitting packets to an individual port only if they are destined for the connected device. In a control application, in which real time data access is critical, network switches may be required in place of hubs.
<b>TCP (Transmission Control Protocol)</b>	EtherNet/IP uses this protocol to transfer Explicit Messaging packets using IP. TCP guarantees delivery of data through the use of retries.
<b>Transport Classes</b>	CIP defines several Transport Classes for messaging connections. Within EtherNet/IP, I/O data sent on Class 1 connections is pre-pended with a 16-bit sequence count, while data on Class 0 connections is not. Class 3 connections are used for Explicit Messaging Connections.
<b>UDP (User Datagram Protocol)</b>	EtherNet/IP uses this protocol to transfer I/O packets using IP. UDP provides a simple, but fast capability to send I/O messaging packets between devices. This protocol ensures that devices transmit the most recent data because it does not use acknowledgments or retries.
<b>Unconnected Messaging</b>	Provides a means for a node to send message requests without establishing a CIP connection prior to data transfer. More overhead is contained within each message and the message is not guaranteed destination node resources. Unconnected Messaging is used for non-periodic requests (e.g., network "Who" function). Applies to explicit messages only.
<b>Unicast (Point to Point)</b>	Unicast or Point to Point is a connection for the transmission of data to a single device.

# List of abbreviations

Table below contains a list of abbreviations (in alphabetical order) which may be used in this guide to describe the EtherNet/IP interface.

<b>API</b>	Actual Packet Interval
<b>ASCII</b>	American Standard Code for Information Interchange
<b>ASN.1</b>	Abstract Syntax Notation
<b>CIP</b>	The Common Industrial Protocol defined in this volume of the CIP Networks Library. CIP includes both connected and unconnected messaging.
<b>CID</b>	Connection Identifier
<b>DLL</b>	Data Link Layer
<b>EPR</b>	Expected Packet Rate
<b>ISO</b>	International Standards Organization
<b>MAC ID</b>	Media Access Control Identifier
<b>PDU</b>	Protocol Data Unit
<b>ODVA</b>	ODVA, Inc.
<b>O ➡ T</b>	Originator to Target (used to describe packets that are sent from the originator to the target)
<b>OSI</b>	Open Systems Interconnection (see ISO 7498)
<b>RPI</b>	Requested Packet Interval
<b>SDU</b>	Service Data Unit
<b>SEM</b>	State Event Matrix
<b>SEMI</b>	Semiconductor Equipment Materials International
<b>STD</b>	State Transition Diagram, used to describe object behaviour
<b>T ➡ O</b>	Target to Originator (used to describe packets that are sent from the target to the originator)
<b>UCMM</b>	Unconnected Message Manager

# References

- [1] THE CIP NETWORKS LIBRARY, Volume 1, Common Industrial Protocol (CIP™), Edition 3.22, April 2017
- [2] THE CIP NETWORKS LIBRARY, Volume 2, EtherNet/IP Adaptation of CIP, Edition 1.23, April 2017

# 1 Safety summary



## 1.1 Safety

- Always adhere to the professional safety and accident prevention regulations applicable to your country during device installation and operation;
- installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and stationary mechanical parts;
- device must be used only for the purpose appropriate to its design: use for purposes other than those for which it has been designed could result in serious personal and/or the environment damage;
- high current, voltage and moving mechanical parts can cause serious or fatal injury;
- failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture, and intended use of the equipment;
- Lika Electronic assumes no liability for the customer's failure to comply with these requirements.



## 1.2 Electrical safety

- Turn off the power supply before connecting the device;
- connect according to the explanation in the "6 -Electrical connections" section on page 41;
- in classified areas the electrical connection of the device must be carried out in compliance with the methods indicated in the directive EN IEC 60079-0:2018-07 and according to EN 60079-14;
- in compliance with the 2014/30/EU norm on electromagnetic compatibility, following precautions must be taken:
  - before handling and installing, discharge electrical charge from your body and tools which may come in touch with the device;
  - power supply must be stabilized without noise, install EMC filters on device power supply if needed;
  - always use shielded cables (twisted pair cables whenever possible);
  - avoid cables runs longer than necessary;
  - avoid running the signal cable near high voltage power cables;
  - mount the device as far as possible from any capacitive or inductive noise source, shield the device from noise source if needed;
  - to guarantee a correct working of the device, avoid using strong magnets on or near by the unit;
  - minimize noise by connecting the shield and/or the connector housing and/or the frame to ground. Provide the ground connection as close as possible to the encoder. We suggest using the connection point provided in the encoder's enclosure (see the Figure on page 38) to connect the unit to ground. Fix the ground cable to the connection point by means of a ring



crimp terminal and a M4 bolt. The connection point to ground might be provided also on the installation side by connecting the cable shield to the earth point. It is user's duty to find the best solution to minimize the interference. Please make sure that ground is not affected by noise.



### 1.3 Mechanical safety

- Install the device following strictly the information in the "5 -Mounting instructions" section on page 38;
- mechanical installation has to be carried out with stationary mechanical parts;
- do not disassemble the encoder;
- do not tool the encoder or its shaft;
- delicate electronic equipment: handle with care; do not subject the device and the shaft to knocks or shocks;
- respect the environmental characteristics declared by manufacturer
- unit with hollow shaft: the encoder can be mounted directly on a shaft whose diameter has to respect the technical characteristics specified in the purchase order and clamped by means of the collar and, when requested, the anti-rotation pin.



### 1.4 Operational safety

- The described product is category 2 certified and is designed for use in potentially explosive zones 1 and 2 (according to EN60079-15) and 21-22 (according to EN60079-31). It is suitable for a safe use and a high level of protection in areas in which explosive atmospheres caused by mixture of gases and vapours (zones 1 and 2) or of air and dust (zones 21 and 22) are likely to occur. It complies with the constructional safety requirements of the temperature class T6 (+85°C / +185°F). **It is not to be used in Zone 0;**
- the manufacturer's specifications (temperature, speed, ...) must under no circumstances be exceeded;
- use the product according to the indicated degree of IP protection;
- the maximum permissible environmental temperature is -20°C to +40°C / -4°F to +104°F (at continuous rotational speed of max. 6000 rpm).

## 2 Identification















Device can be identified through the **order code**, the **serial number** and the **MAC address** printed on the label applied to its body. Information is listed in the delivery document too. Please always quote the order code, the serial number, and the MAC address when reaching Lika Electronic for purchasing spare parts or needing assistance. For any information on the technical characteristics of the product [refer to the technical catalog](#).



**Warning:** encoders having order code ending with "/Sxxx" may have mechanical and electrical characteristics different from standard and be supplied with additional documentation for special connections (Technical info).



### 3 ATEX certificate

<p><b>CESI</b></p> <p><small>CESI Centro Elettrotecnico Sperimentale Italiano Giacinto Motta SpA</small></p> <p><small>Via R. Rubattino 54 20134 Milano - Italia Telefono +39 022125.1 Fax +39 0221255440 www.cesi.it</small></p> <p><small>Capitale sociale 8 550 000 € interamente versato Codice fiscale e numero iscrizione CCIAA 00793580150</small></p> <p><small>Registro Imprese di Milano Sezione Ordinaria N. R.E.A. 429222 P.I. IT00793580150</small></p> <p style="writing-mode: vertical-rl; transform: rotate(180deg);">Schema di certificazione</p> <p><b>CESI-ATEX</b></p> <p><small>Il CESI è stato autorizzato dal governo italiano ad operare quale organismo di certificazione di apparecchi e sistemi destinati a essere utilizzati in atmosfera potenzialmente esplosiva con D.M. 1/3/1983, D.M. 19/6/1990, D.M. 20/7/1998, D.M. 27/9/2000 e D.M. 02/02/2006</small></p> <p><small>ATEX E C-22 - 1</small></p>	<p style="text-align: center;"><b>CERTIFICATE</b> </p> <p style="text-align: center;"><b>EC-TYPE EXAMINATION CERTIFICATE</b></p> <p>[1] <b>Equipment or Protective System intended for use in potentially explosive atmospheres Directive 94/9/EC</b></p> <p>[2] EC-Type Examination Certificate number:  <b>CESI 08 ATEX 013</b></p> <p>[3] Equipment: <b>Incremental Encoder series XC77 and Absolute Encoder series XAC77</b></p> <p>[4] Manufacturer: <b>Lika Electronic s.n.c.</b></p> <p>[5] Address: <b>Via S. Lorenzo 25, 36010 Carrè (Vi) - Italy</b></p> <p>[6] This equipment or protective system and any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.</p> <p>[7] CESI, notified body n. 0722 in accordance with Article 9 of the Council Directive 94/9/EC of 23 March 1994, certifies that this equipment or protective system has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of equipment and protective systems intended for use in potentially explosive atmospheres given in Annex II to the Directive.</p> <p>The examination and test results are recorded in confidential report n. A8008869</p> <p>[8] Compliance with the Essential Health and Safety Requirements has been assured by compliance with:  <b>EN 60079-0 :2004 EN 60079-1:2007 EN 61241-0 :2006 EN 61241-1 :2004</b></p> <p>[9] If the sign "X" is placed after the certificate number, it indicates that the equipment or protective system is subject to special conditions for safe use specified in the schedule to this certificate.</p> <p>[10] This EC-TYPE EXAMINATION CERTIFICATE relates only to the design, examination and tests of the specified equipment or protective system in accordance to the Directive 94/9/EC. Further requirements of the Directive apply to the manufacturing process and supply of this equipment or protective system. These are not covered by this certificate.</p> <p>[11] The marking of the equipment or protective system shall include the following:   <b>II 2GD Ex d IIC T6, Ex tD A21 IP65 T 85°C</b></p> <p>This certificate may only be reproduced in its entirety and without any change, schedule included.</p> <p style="text-align: center;"><b>Date 28.04.2008 - Translation issued the 28.04.2008</b></p> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;"> <b>Prepared</b> Gaetano Baldini  </td> <td style="text-align: center;"> <b>Verified</b> Mirko Balaz  </td> <td style="text-align: center;"> <b>Approved</b> Fiorenzo Bregani      </td> </tr> </table> <p style="text-align: center;">Page 1/3</p>	<b>Prepared</b> Gaetano Baldini 	<b>Verified</b> Mirko Balaz 	<b>Approved</b> Fiorenzo Bregani   
<b>Prepared</b> Gaetano Baldini 	<b>Verified</b> Mirko Balaz 	<b>Approved</b> Fiorenzo Bregani   		

## CESI

### [13] **Schedule**

[14] **EC-TYPE EXAMINATION CERTIFICATE n. CESI 08 ATEX 013**

#### [15] **Description of equipment**

The encoder is a rotating transducer that converts an angular position of the shaft into a digital electric signal. This electro-mechanical equipment is able to detect angular displacements and to estimate rotating speeds and accelerations by dedicated electronic and/or mechanical interfaces. The translation from mechanical motion to digital signal is obtained by photo-electric reading from an infrared led joined to a light beam collimator: emitted light hits a glass disk supplied by dark and transparent marks; escaped light rays are then gathered by a phototransistor set. The obtained signal are digitalized by a comparator device.

##### **XC77 Incremental Encoder**

Position is determined by counting pulses relative to the zero track.

##### **XAC77 Absolute Encoder**

Position is evaluated by reading output code, that is unique for every shaft position. Such devices keep then effective position data in the case of power fail and they not need the zero mark search when restart is carried out, as incremental encoder has to search.

Bulk and flange of both the encoders are made of anticorodal (EN AW-6082 aluminium alloy), while shaft and ring nut are made of 1.4305 stainless steel. The flange is screwed to the bulk.

The identification mark of the encoders is detailed in the descriptive documents here enclosed.

#### **Electrical and mechanical characteristics**

##### **XC77 Encoder**

Supply voltage:	5 V dc, 5 Vdc -30 Vdc, 10 Vdc -30 Vdc
No load maximum current:	70 mA
Maximum output current for every channel	40 mA
Output:	NPN, Push-Pull, Line Driver, PP/LD

##### **XAC77 Encoder**

Supply voltage:	10Vdc - 30 Vdc
No load max current:	150 mA
Max output current for every channel	40 mA
Output/Code	NPN, Push-Pull, SSI / Binario, Gray

Max rotation speed:	6000 rpm
Electrical protection:	Polarity inversion and short circuit.
Max shaft load:	60 N (axial and radial)
Degree of protection:	IP65 (EN 60529:1997)
Temperature class:	T6
Max surface temperature:	T 85 °C
Ambient temperature:	-20 °C ≤ Ta ≤ +40 °C

#### **Cables entries**

The accessories used for cable entries and for unused holes shall be subject of separate certification: in the unit of category II 2GD shall be certified according to the Standards: EN 60079-0, EN 60079-1 and EN 61241-1 and shall guarantee a degree of protection IP65 according to EN 60529 Standard.

This certificate may only be reproduced in its entirety and without any change, schedule included.

Page 2/3

Prot. A8008876

P: 3 + 26

## CESI

### Schedule

[13]

[14] EC-TYPE EXAMINATION CERTIFICATE n. CESI 08 ATEX 013

[16] Report n. A8008869

#### Routine tests

Manufacturer shall carry out the routine tests and checkouts prescribed at paragraph 27 of the EN 60079-0 and at paragraph 24 of the EN 61241-0 Standards. Manufacturer is not charged of overpressure test because the equipments have passed the overpressure test carried out by the static method using four times the reference pressure (28 bar).

#### Descriptive documents (prot. A8008877)

- Encoder Technical File series XC77 - XAC77		2 sheets	19/03/2008
- Absolute Encoder series XAC77 – ROTACOD Description		2 sheets	
- LKM 1362 XA77 Bulk – Radial	rev. 3	1 sheet	26/07/2007
- LKM 1367 XA77 Bulk – Axial	rev. 3	1 sheet	26/07/2007
- Incremental Encoder XC77 – ROTAPLUS Description		2 sheets	
- LKM 1368 XC77 Bulk	rev. 3	1 sheet	25/07/2007
- Sez. 4300 XC77 + XAC77 ( radial and axial cable ) Hollow shaft $\Phi$ 14			
	rev. 3	3 sheets	26/07/2007
- LKM 1363 XC77 and XAC77 Empty Axis	rev. 3	1 sheet	26/07/2007
- LKM 1361 XC77 e XAC77 Flange	rev. 3	1 sheet	25/07/2007
- LKM 1481 XC77 e XAC77 Ring nut	rev. 1	1 sheet	14/02/2006
- LKM 1364 XC77 e XAC77 Blocked Axis Ring nut	rev. 2	1 sheet	14/02/2006
- Technical data sheet FKM		1 sheet	19/05/2006
- Technical data sheet FKM 75.16-01 O-ring		2 sheets	25/10/2005
- LKM 1551 XC77-XAC77 Plate	rev. 3	1 sheet	28/04/2008
- Technical data sheet metalized polyester label (Brady)		3 sheets	
- XC77 e XAC77 Safety Instructions		2 sheets	19/03/2008
- CE Conformity Declaration	N. 4	1 sheet	19/03/2008

One copy of all documents is kept in CESI files.

[17] Special conditions for safe use

None.

[18] Essential Health and Safety Requirements

Guaranteed by the compliance to the mentioned Standards.

This certificate may only be reproduced in its entirety and without any change, schedule included.

Page 3/3

**CESI**

**ISMES**
**IPH**
**EGH**
**EXTENSION n. 01/15**

to Type Examination Certificate CESI 08 ATEX 013

**Equipment:** Incremental encoder series XC77 and absolute encoder series XAC77

**Manufacturer:** Lika Electronic Srl

**Address:** Via San Lorenzo, 25  
36010 Carrè (VI)  
Italy

**Admitted variation**

➤ *Changing of the company name:*

from:	<b>Lika Electronic Snc</b>	to:	<b>Lika Electronic Srl</b>
-------	----------------------------	-----	----------------------------

➤ *Updating to the following reference standards:*

EN 60079-0: 2012+A11:2013,  
EN 60079-1: 2007,  
EN 60079-31: 2009.

➤ *Addition of the possibility to mark for gas group IIB.*

➤ *Constructive changes:*

Addition of the possibility of using stainless steel enclosures,  
Addition of the possibility of having absolute encoders with reduced length enclosures,  
Addition of external mounting kits and other small changes not influencing the type of protection.

➤ *Updating of the ATEX marking on the plate:*

II 2G Ex d IIC T6 Gb  
Or  
II 2G Ex d IIB T6 Gb  
II 2D Ex tb IIIC T85°C Db



This extension and annexed descriptive documents must be annexed to the Type Examination Certificate CESI 08 ATEX 013.

This document may only be reproduced in its entirety and without any change.

Date 1/04/2015 - translation issued on 1<sup>st</sup> April 2015

**Prepared**  
Tiziano COLA



**Verified**  
Mirko BALAZ



**Approved**  
Roberto PICCIN



**CESI** S.p.A.  
Testing & Certification Division

Page 1/3

EST-CE-ING-0

**ACCREDIA**  
ENTE ITALIANO DI ACCREDITAMENTO  
PRD N. 0168  
Membro degli Accordi di Mutuo  
Riconoscimento EA, IAF e ILAC  
Signatory of EA, IAF and ILAC  
Mutual Recognition Agreements

CESI S.p.A.  
Via Rubattino 54  
I-20134 Milano - Italy  
Tel: +39 02 21251  
Fax: +39 02 2125440  
e-mail: info@cesi.it  
[www.cesi.it](http://www.cesi.it)

Capitale sociale € 8.550.000 interamente versato  
C.F. e numero iscrizione Reg. Imprese di Milano 00793580150  
P.I. IT00793580150  
N. R.E.A. 429222





## EXTENSION n. 01/15

to Type Examination Certificate CESI 08 ATEX 013

### Description of equipment

With this extension it is added the possibility of making the enclosure in stainless steel besides aluminium which was foreseen in the original certificate. The apparatus, without any constructive variation, can be marked IIB in order to simplify the selection of the cable gland. It is also added the possibility, as shown in the annexed documents, of making the enclosures of the absolute encoders a little shorter than in the original certificate.

The possibility, added with this extension, of supplying together with the encoder two mounting kits, does not affect the adopted type of protection.

The equipment mounting stainless steel enclosures are identified by a code ("S613") which is appended at the end of the apparatus encoding:

<b>XC77 dddd</b>	Incremental encoder having an aluminium enclosure
<b>XC77 dddd /S613</b>	Incremental encoder having a stainless steel enclosure
<b>XAC77 dddd</b>	Absolute encoder having an aluminium enclosure
<b>XAC77 dddd /S613</b>	Absolute encoder having a stainless steel enclosure

The fields identified by the characters "dddd" locate the part of the code containing information useful for the type of application but irrelevant for the protection of the apparatus.

### Electrical characteristics

Electrical data are unchanged respect to the original certificate. According to the new reference standards the marking to be put on the plate has been modified:

ATEX marking:	II 2GD
Marking for the gas protection:	Ex d IIC T6 Gb or Ex d IIB T6 Gb
Marking for the combustible dusts:	Ex tb IIIC T85°C Db

### Cable entries

Accessories used for the cables entry shall be subject of independent certification according to the standard EN 60079-0, EN 60079-1 and EN 60079-31 and guarantee a minimum protection level IP65 according to the standard EN 60529. For the selection of the cable gland follow the prescription of the standard EN 60079-14 and keep into account the marking of the encoder (gas group IIB or IIC).

### Warning labels

None.

Report n. EX-B5006802

### Routine tests

The manufacturer is exempted from carrying out the routine overpressure tests on the enclosures as they have overcome the type tests carried out with the static method at 28 bar, equal to 4 times the reference pressure.

This document may only be reproduced in its entirety and without any change.

Prot. B5006806

P: 3 + 30

page 2/3



## EXTENSION n. 01/15

to Type Examination Certificate CESI 08 ATEX 013

### *Descriptive documents* (prot. EX-B5006808)

Technical note encoder series XC77-XAC77 (2 pages)	dated 2015/03/30
Safety instructions encoder series XC77-XAC77 (2 pages)	dated 2015/03/30
Drawing n. KIT_LKM1520 rev. A (mounting kit 1: flange)	dated 2014/12/15
Drawing n. KIT_LKM-1758 rev. A (mounting kit 2: shaft)	dated 2014/12/15
Drawing n. LKM_001363 rev. A	dated 2014/12/01
Drawing n. LKM_001363_MO rev. A	dated 2014/12/02
Drawing plate n. LKM_1551 rev. 5	dated 2015/03/30
Drawing n. SEZ_4300 rev. A (3 pages)	dated 2014/03/03
Drawing n. PF_4300 rev. A	dated 2014/12/10
Drawing n. PF_4301 rev. A	dated 2014/12/10
Drawing n. PF_4302 rev. A	dated 2014/12/10
Data sheet ROTACOD absolute encoder XAC77 (3 pages)	
Data sheet ROTAPULS incremental encoder XC77 (2 pages)	
Data sheets shaft sealing ring (9 pages)	
Facsimile EC declaration of conformity	

One copy of all the descriptive documents mentioned above is kept in CESI files.

### *Special conditions for safe use*

None.

### *Essential Health and Safety Requirements*

Essential health and safety requirements are covered by compliance to the following standards:

- EN 60079-0: 2012 + A11: 2013 Explosive atmospheres  
Part 0: Equipment - General requirements;
- EN 60079-1 : 2007 Explosive atmospheres  
Part 1: Equipment protection by flameproof enclosures "d";
- EN 60079-31 : 2009 Explosive atmospheres  
Part 31: Equipment dust ignition protection by enclosure "t".

This document may only be reproduced in its entirety and without any change.

pagina 3/3

**CESI**

**NOTIFICATION**



CESI S.p.A.  
Via Rubattino 54  
I-20134 Milano - Italy  
Tel: +39 02 21251  
Fax: +39 02 21255440  
e-mail: info@cesi.it  
www.cesi.it

Schema di certificazione

**CESI-ATEX**

ATEX B9003481-10-EN

**ACCREDIA**  
PRD N. 018B  
Membro degli Accordi di Mutuo  
Riconoscimento EA, IAF e ILAC  
Signatory of EA, IAF and ILAC  
Mutual Recognition Agreements

- [1] **PRODUCT QUALITY ASSURANCE NOTIFICATION**
- [2] **Equipment or Protective System or Component intended for use in potentially explosive atmospheres Directive 2014/34/EU**
- [3] Notification number: **CESI 16 ATEX 005 Q**
- [4] Equipment or component type: **Shaft encoders**  
Protection concepts: **Flameproof enclosures "d"  
Dust ignition protection by enclosure "t"**
- [5] Applicant: **LIKA Electronic s.r.l.  
via San Lorenzo n° 25  
36010 Carrè - VI**
- [6] Manufacturer: **LIKA Electronic s.r.l.  
via San Lorenzo n° 25  
36010 Carrè - VI**
- [7] CESI, notified body n. 0722 in accordance with Articles 19 and 21 of the Directive 2014/34/EU of the European Parliament and of the Council of the 26 March 2014, notifies to the applicant that the actual manufacturer has a product quality system which complies to Annex VII of the Directive.
- [8] This notification is based on the audit report n. EX-B9002583 issued the 6/02/2019.  
This notification can be withdrawn if the manufacturer no longer satisfies the requirement of Annex VII.  
**Results of periodical re-assessment of the quality system are a part of this notification.**
- [9] This notification is **valid until 17/02/2022** and can be withdrawn if the Manufacturer does not satisfy the product quality assurance re-assessment.
- [10] According to Article 16 [3] of the Directive 2014/34/EU the CE marking shall be followed by the identification n. 0722 identifying the notified body involved in the production control stage.

This notification may only be reproduced in its entirety and without any change.

**Date of first issue  
17th February 2016**

**Current issue  
17th February 2019**

Translation issued on 17th February 2019

**Prepared  
Sergio G. Giugno**

**Verified  
Mirko Balaz**

**Approved  
Roberto Piccin**

*Sergio G. Giugno* *Mirko Balaz*

Page 1/1

**CESI S.p.A.**  
Testing & Certification Division  
Business Area Certification  
Responsabile  
*(Roberto Piccin)*

Prot. B9002587 P: 1 Issue: 1 (R: 1)

*Roberto Piccin*

## 4 Safety instructions



Lika Electronic Srl  
Via S. Lorenzo, 25  
36010 Carrè (VI) • Italy


Smart encoders & actuators

### SAFETY INSTRUCTIONS encoders series XC77-XAC77

1) Marking:

 II2 GD, Ex d IIC T6 Gb, Ex tb IIIC T 85°C Db, IP65

or

 II2 GD, Ex d IIB T6 Gb, Ex tb IIIC T 85°C Db, IP65

Nr. of certificate: **CESI 08 ATEX 013**

Explosion-proof encoder manufactured in compliance with the following regulations:

**EN IEC 60079-0:2018-07**

**EN 60079-1:2014-10**

**EN 60079-31:2014-07**

**EN 61000-6-4, EN 61000-6-2**

Compliance with directives listed above does not comprise marking which is certified by compliance with the following directives: **EN 60079-0:2012 + A11:2013, EN 60079-1:2007, EN 60079-31:2009.**

- **II:** Equipment intended for use in potentially explosive atmospheres other than mines
- **2 GD:** Category 2 equipment with high level protection for use in areas in which explosive atmospheres caused by gases, vapours, mists or air/dust mixtures are likely to occur.
- **Ex:** Equipment for use in potentially explosive atmospheres
- **d:** Protection by explosion-proof housing
- **IIB-IIC:** Electrical apparatus for use in potentially explosive atmospheres caused by gasses of the group IIB (e.g. C<sub>2</sub>H<sub>4</sub>) or group IIC (e.g. H<sub>2</sub>, C<sub>2</sub>H<sub>2</sub>).
- **T6:** Temperature class for gasses T6 = 85°C
- **Gb:** Level of protection (EPL). The equipment can be used in Zones 1 and 2.
- **tb:** Electrical apparatus with protective housing for use in the presence of combustible dust.
- **IIIC:** Equipment or protective housing intended for use in potentially explosive atmospheres with presence of combustible (including conductive dust).
- **T 85°C:** Maximum surface temperature.
- **Db:** Level of protection (EPL). The equipment can be used in Zones 21 and 22.
- **IP65:** Degree of IP protection for dust-proof housing.

Equipment intended for use in the following Zones:

**Zone 1, Zone 2:** Mixture of gas/air, vapour/air, mist/air

**Zone 21, Zone 22:** Mixture of dust/air

**ATTENTION:** Equipment not to be used in Zone 0

Lika Electronic Srl  
Smart encoders & actuators



**Headquarters & Plant**  
Via S. Lorenzo, 25  
36010 Carrè (VI) • Italy

Tel. +39 0445 806600  
Fax +39 0445 806699  
info@lika.biz • www.lika.biz

P.I./C.F. IT 00817760242  
VAT # IT 00817760242  
R.E.A. 165423/Vicenza





Lika Electronic Srl  
Via S. Lorenzo, 25  
36010 Carrè (VI) • Italy

**Smart encoders & actuators**

- 2) The equipment must be installed only by qualified personnel and according to the applicable regulations.
- 3) Do not tool or drill the equipment.
- 4) Do not open the equipment.
- 5) Do not loosen or unscrew the cable gland.
- 6) Use the encoder's fixing plate for installation and against rotation.
- 7) Protect the device against shock and mechanical damages.
- 8) Use the product according to the indicated degree of IP protection.
- 9) Maximum permissible environmental temperature -20°C to +40°C / -4°F to +104°F (at continuous rotational speed of max. 6000 rpm).
- 10) In classified areas the electrical connection of the device must be carried out in compliance with the methods indicated in the directive EN IEC 60079-0:2018-07 and according to EN 60079-14.
- 11) Connect the device according to the electrical connections scheme on the user's guide.
- 12) Provide a ground connection (GND) using the ground screw on the housing.

LIKA ELECTRONIC SRL  
Carrè, 17.05.2021

Lika Electronic Srl  
Smart encoders & actuators



**Headquarters & Plant**  
Via S. Lorenzo, 25  
36010 Carrè (VI) • Italy

Tel. +39 0445 806600  
Fax +39 0445 806699  
info@lika.biz • www.lika.biz

P.I./C.F. IT 00817760242  
VAT # IT 00817760242  
R.E.A. 165423/Vicenza

## 5 Mounting instructions



### WARNING

Installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected. Shaft and mechanical components must be in stop.

For any information on the mechanical data and the electrical characteristics of the encoder please refer to the technical catalogue.

### 5.1 Encumbrance sizes





Figure 1 - Encumbrance sizes

## 5.2 Solid shaft (LKM-1758) and Fixing plate (LKM-1520)

LKM-1758 is an optional feature thus it has to be ordered separately.



### WARNING

Unit with solid shaft: in order to guarantee maximum reliability over time of the mechanical parts, we recommend a flexible coupling to be installed to connect the encoder and the installation shaft; make sure the misalignment tolerances of the flexible coupling are respected.


## 5.3 Mounting instructions



### WARNING

Installation and maintenance operations have to be carried out by qualified personnel only, with power supply disconnected and mechanical parts absolutely in stop.

- Fasten the fixing plate **1** to the encoder using the three M4 screws **2** provided with the device;
- mount the encoder on the motor shaft using the reducing sleeve (if supplied); avoid forcing the encoder shaft;
- fasten the fixing plate **1** to the rear of the motor using four M4 cylindrical head screws **3**;
- fix the collar **4** to the encoder shaft.



## 6 Electrical connections



### WARNING

Power supply must be turned off before performing any electrical connection! Installation, electrical connection and maintenance operations must be carried out by qualified personnel only, with power supply disconnected. Mechanical components must be in stop. Do not open the encoder.



No user serviceable parts inside the encoder!

For any information on the mechanical and electrical characteristics of the encoder please [refer to the technical catalogue](#).




Figure 2 - Electrical connection and grounding point

## 6.1 PWR power supply and Ethernet connection (Figure 2)

A T8 type cable is used for power supply and Ethernet connection of the EtherNet/IP encoder. Connection is according to PoE IEEE 802.3af mode B standard and accepts max. 30Vdc power supply.

Function	T8 cable
Tx Data +	White
Tx Data -	Red
+10Vdc +30Vdc power supply	White
	Blue
Rx Data +	White
Rx Data -	Green
0Vdc power supply	White
	Yellow
Shield	Case

This encoder provides single-port connection capability.

The Ethernet interface supports 100 Mbit/s, half-duplex/full-duplex operation.

### 6.1.1 T8 cable specifications

Model:	LIKA cable type T8
Cross section:	4 x 2 x 0.25 mm <sup>2</sup> (AWG24)
Jacket:	Polyurethane, abrasion resistant
Shield:	Tinned copper braid, coverage ≥ 85%
Outer diameter:	9.0 mm (0.35")
Min. bend radius:	Outer diameter x 3, fixed application Outer diameter x 6, dynamic application
Work temperature:	-50°C +80°C / -40°F +176°F, fixed application -40°C +80°C / -40°F +176°F, dynamic application
Travel speed:	240 m/min.
Acceleration, deceleration:	Up to 30 m/sec <sup>2</sup> / 98.4 ft/sec <sup>2</sup>
Cable length inside chain:	15 m / 49.2 ft (horizontal only)
Bending:	From 3 to 6 millions of motions

## 6.2 Network configuration: cables, hubs, switches – Recommendations

Cables and connectors comply with the Ethernet specifications.

Standard Ethernet cables type CAT-5, CAT-5e and CAT-6 commercially available can be used.

The minimum cabling performance that will support EtherNet/IP is Category 5 as defined by ANSI/TIA/EIA-568-B.2 Annex N. There are reasons to select one category of cabling over another. In general, the higher the category, the better the cabling performance. Another consideration is balance. Category 5e, 6, and

the newest proposed category, known as augmented 6 or Category 6a, will support current applications such as 1Gb/s and 10 Gb/s. Generally speaking, the greater the cabling category, the less EMC protection that is needed. Consult your cable supplier for guidance on EMC protection for the specific cable being used.

For complete information please refer to IEC 61918, IEC 61784-5-13, and IEC 61076-2-101.

The maximum cable length (100 meters) predefined by Ethernet 100Base-TX must be compulsorily fulfilled.

Regarding wiring and EMC measures, the IEC 61918 and IEC 61784-5-13 must be considered.

Compliance with IEEE Ethernet standards provides users with a choice of network interface speeds – e.g., 10, 100 Mbps, 1 Gbps and beyond – and a flexible network architecture compatible with commercially available Ethernet installation options including copper, fiber, fiber ring and wireless, and topologies including star, linear and ring.

A hub is an inexpensive connectivity method that provides an easy method of connecting devices on information networks (shared Ethernet). A switch reduces collisions and is recommended for real-time control installations (switched Ethernet). Routers are used to isolate control data traffic from other types of office data traffic, to isolate information traffic on the plant floor from control traffic on the plant floor, and for security purposes, i.e., firewalls. Repeaters extend the overall network cable length. They can also connect networks with different media types.

For a complete list of the available cordsets, patchcords and connection kits please refer to the product datasheet ("Accessories" list).

### **6.3 Ground connection**

To minimize noise connect properly the shield and/or the connector housing and/or the frame to ground. Connect properly the cable shield to ground on user's side. Make sure that ground is not affected by noise. It is recommended to provide the ground connection as close as possible to the device. We suggest using the ground point provided in the enclosure (see Figure 1 and Figure 2).

### **6.4 Line termination**

EtherNet/IP network needs no line termination because the line is terminated automatically; in fact every Slave is able to detect the presence of the downstream Slaves.

### 6.5 MAC address and IP address

The unit can be identified in the network through the **MAC address** and the **IP address**.

The MAC address has to be intended as a permanent and globally unique identifier assigned to the unit for communication on the physical layer; while the IP address is the name of the unit in a network using the Internet protocol. MAC address is 6-byte long and cannot be modified. It consists of two parts, numbers are expressed in hexadecimal notation: the first three bytes are used to identify the manufacturer (OUI, namely Organizationally Unique Identifier), while the last three bytes are the specific identifier of the unit. The MAC address can be found on the label applied to the encoder.

The IP address must be assigned by the user to each interface of the unit to be connected in the network as well as the subnet mask.

For additional information on the MAC address refer to the "7.4 MAC address" section on page 51.

For additional information on the IP address refer to the "6.6 EtherNet/IP Node ID" section below.

### 6.6 EtherNet/IP Node ID



#### WARNING

Only competent technicians, who are properly trained, have adequate experience and are familiar with computer architecture, network design, and operating systems should configure the network communication parameters. The inappropriate setting of the network parameters results in an incorrect operation of the system.



#### WARNING

The EtherNet/IP address and communication parameters can be set only via software.

By default, the encoder is configured so that it uses the IP address, Subnet mask, and Gateway address that are saved internally. The use of a DHCP Server to allocate the IP address is disabled.

The IP address, the Subnet mask, and the Gateway address are set next to the **IP Address**, **Network Mask**, and **Gateway Address** parameters in the **F5-01-05 Interface Configuration** attribute, see the "8.12.6 Class F5h: TCP/IP Interface Object" section on page 115. For more information on setting the node ID refer to the "6.6.1 Setting the node ID" section hereafter.

The following table summarizes the default software IP parameters.

IP Parameter	IP address
IP address	192.168.1.10
Subnet mask	255.255.255.0
Gateway address	0.0.0.0
DHCP	Disabled



### 6.6.1 Setting the node ID

As stated, by default, the encoder is configured so that it uses the IP address saved internally.

The software values can be changed by using a software tool such as Studio 5000 or by means of the integrated web server (see the "9.8 Network configuration" section on page 149) or by enabling a DHCP server (see the "9.8 Network configuration" section on page 149).

Any Net ID value and Host ID value can be set via software.

## 7 Quick reference

### 7.1 Quick setting and main functions

The following instructions allow the operator to quickly and safely set up the encoder in a standard operational mode and to execute its main functions.

Sometimes a function or a procedure can be accomplished by using alternative ways:

- by means of a software tool such as Studio 5000 from Rockwell Automation (see the "7.5 Encoder installation under Studio 5000 design environment" section on page 52 ff);
- or by means of the Integrated Web Server (see the "Integrated Web Server" section on page 132).

They are all mentioned whenever available.

For complete and detailed information please read the mentioned pages thoroughly.

- Mechanically install the device, see on page 38 ff;
- execute the electrical and network connections, see on page 41 ff;
- switch on the +10Vdc +30Vdc power supply;
- in the software tool install the EDS file, see on page 59 ff;
- in the software tool insert the Lika module and select the encoder type, see on page 62 ff;
- in the software tool set the device name, see on page 62 ff;
- if required, set the IP address and the subnet mask to the node, see here later for alternatives; the default address and the network-related parameters set by Lika are:

IP Parameter	IP address
IP address	192.168.1.10
Subnet mask	255.255.255.0
Gateway address	0.0.0.0
DHCP	Disabled

- the attributes used to specifically configure the encoder are grouped in the Position Sensor Object, see the "8.12.5 Class 23h: Position Sensor Object" section on page 97; they allow, for example, to set the singleturn resolution or the total resolution, to enable the scaling function, or to change the counting direction; the complete list of the default parameters is available on page 153.

### 7.1.1 Setting the node address

The node address and the network-related parameters must be set via software.

- Set the **IP Address**, **Network Mask**, and **Gateway Address** parameters in the **F5-01-05 Interface Configuration** attribute, see the "8.12.6 Class F5h: TCP/IP Interface Object" section on page 115;
- set the parameters in the Integrated Web Server, see the "9.8 Network configuration" section on page 149;
- enable a DHCP Server as follows:
  - see the **F5-01-03 Configuration Control** attribute, see the "8.12.6 Class F5h: TCP/IP Interface Object" section on page 115;
  - enable the DHCP Server in the Integrated Web Server, see the "9.8 Network configuration" section on page 149.

### 7.1.2 Setting scaling function and custom resolution

- If you want to use the physical resolution of the encoder, please check that the **23-01-0E Scaling Function Control** attribute is disabled (= "0"), see on page 98; in this case, the device uses the physical resolution (see the **23-01-2A Physical Resolution Span** and **23-01-2B Number of Spans** attributes) to arrange the absolute position value. You can also use the Integrated Web Server, see the "9.6 Setting the attributes" section on page 139; or a software tool, see the "7.5.11 Configuring the encoder" section on page 65;
- on the contrary, if you need a custom resolution, you must enable the scaling function by setting the **23-01-0E Scaling Function Control** attribute to = "1" first and then set the required resolution parameters:
  - set the singleturn resolution next to the **23-01-10 Measuring Units per Span** attribute, see on page 99;
  - set the total resolution next to the **23-01-11 Total Measuring Range** parameter, see on page 101.

You can also use the Integrated Web Server, see the "9.6 Setting the attributes" section on page 139; or a software tool, see the "7.5.11 Configuring the encoder" section on page 65.

### 7.1.3 Reading the absolute position

To read the position value you can choose among the following methods.

- To read the absolute position of the encoder see the **23-01-03 Position value** attribute on page 98;
- open the Integrated Web Server, see the "9.3 Encoder position and speed" section on page 134; see the "9.4 Encoder information (EtherNet/IP attributes)" section on page 136;
- open the **Monitor Tags** tabbed page in your project, see the "7.5.9 Checking the communication" section on page 64.

#### 7.1.4 Reading the velocity value

To read the velocity value you can choose among the following methods.

- To read the velocity value of the encoder see the **23-01-18 Velocity Value** attribute on page 104;
- open the Integrated Web Server, see the "9.3 Encoder position and speed" section on page 134; see the "9.4 Encoder information (EtherNet/IP attributes)" section on page 136;
- open the **Monitor Tags** tabbed page in your project, see the "7.5.9 Checking the communication" section on page 64.

#### 7.1.5 Setting and executing the preset

To set and execute the preset you can choose among the following methods.

- Enter a suitable value next to the **23-01-13 Preset Value** attribute, see on page 102; the preset value is activated as soon as the value is confirmed.
- If a value has been already set next to the **23-01-13 Preset Value** attribute and you need to activate it in a different physical position of the encoder shaft, you can use the bit 0 **Activate Preset** in the **23-01-68 Command Register** attribute, see on page 111.
- Open the **Set Encoder Preset** page in the Integrated Web Server, see the "9.5 Setting the Preset value" section on page 137.
- Use the Test\_encoder\_Lika.acd sample program, you can find it in the **SW\_Hx58x\_EP\_Example.zip** compressed file. Refer also to the "7.5.12 How to create a sample program and send parameters" section on page 65.

#### 7.1.6 Saving data

To save the parameters permanently you can choose among the following methods.

- Use the Class Service 16h available for the Position Sensor Object, see on page 97.
- Set the bit 6 **Save Parameters** in the **23-01-68 Command Register** attribute to 1 and then back to 0, see on page 112.
- Use the **Save Parameters** function in the **Set Encoder Registers** page of the Integrated Web Server, see the "9.6 Setting the attributes" section on page 139.

#### 7.1.7 Restoring defaults

To restore the default parameters you can choose among the following methods.

- Use the Class Service 15h available for the Position Sensor Object, see on page 97.
- Set the bit 7 **Restore Parameters to Defaults** in the **23-01-68 Command Register** attribute to 1 and then back to 0, see on page 112.

- Use the **Load Default Param.** function in the **Set Encoder Registers** page of the Integrated Web Server, see the "9.6 Setting the attributes" section on page 139.

## 7.2 About Lika encoders

Lika encoders are **22 hex type devices** and comply with the specifications reported in the Chapter 6 "Device Profiles, Encoder Device Type 22 hex" of the publication "THE CIP NETWORKS LIBRARY, Volume 1, Common Industrial Protocol (CIP™)".

The Object Model of an encoder device is represented in the following picture:




Figure 3 - Object model

The Parameter Object data mapping complies with information in the "Mapping Parameter Object Data" section.

The attributes that are used to specifically configure the encoder and make it operational in order to provide the absolute position value and the velocity value are all grouped in the Position Sensor Object, refer to the "8.12.5 Class 23h: Position Sensor Object" section on page 97.

### 7.2.1 Network identity

Lika EtherNet/IP encoders use the following identity settings available in the Identity Object, see the "8.12.1 Class 01h: Identity Object" section on page 87:

Identity Name: **Vendor ID**

Attribute: **01-01-01 Vendor ID**

Setting: **0299h = 665dec = Lika Electronic Srl**

Identity Name: **Device Type**

Attribute: **01-01-02 Device type**

Setting: **0022h: Encoder Device Profile**

Identity Name: **Product Code**

Attribute: **01-01-03 Product code**

Setting: **0003h XAC77-18-00-EC2-... singleturn encoder**

**0004h XAC77-16-14-EC2-... multiturn encoder**

Identity Name: **Revision**

Attribute: **01-01-04 Revision**

Setting: **device dependent**

Identity Name: **Serial Number**

Attribute: **01-01-06 Serial number**

Setting: **device dependent**

Identity Name: **Product Name**

Attribute: **01-01-07 Product name**

Setting: **HSx58x Singleturn Encoder = XAC77-18-00-EC2-...**

**HMx58x Multiturn Encoder = XAC77-16-14-EC2-...**

### 7.2.2 Network and communication settings

The **MAC address** of the device is always reported in the label applied to the encoder enclosure. See on page 44.

The **EtherNet/IP Node ID** must be set via software. By default its value is 192.168.1.10. See on page 44.

## 7.3 Configuring the encoder with Studio 5000 V30.00 from Rockwell Automation

In this manual some screenshots are shown to explain how to install and configure the encoder in a supervisor. In the specific example the development environment is Studio 5000 V30.00 from Rockwell Automation; it is used in combination with CompactLogix 5370 L1 Controller "1769-L16ER-BB1B/B" series from Allen Bradley. Therefore, the information on the installation of the EDS file, the assignment of the IP address and the device name, the

configuration of the encoder in the network, topology, diagnostics, etc. will always refer to the aforementioned design environment. If you need to install the encoder using a different configuration tool, please read and follow carefully the instructions given in the documentation provided by the manufacturer.

In the following pages the Controller is assumed to have 192.168.1.20 IP address and 255.255.255.0 Subnet mask.



Lika Electronic EtherNet/IP encoder documentation is complete with a **sample project** supplied free of charge. This program is designed to make your own project planning, programming, communication and diagnostics with Studio 5000 V30.00 design environment user-friendly and reliable. For instance it allows to execute the following functions: setting the Preset value and execute it; setting both the singleturn and the multiturn resolutions; setting an output (refer to page 65 ff). You can find it in the **SW\_Hx58x\_EP\_Example.zip** compressed file.

#### 7.4 MAC address

The MAC address is an identifier unique worldwide.

The MAC-ID consists of two parts: the first three bytes are the manufacturer ID and are provided by IEE standard authority; the last three bytes represent a consecutive number of the manufacturer.



#### NOTE

The MAC address is always printed on the encoder label for commissioning purposes.

The MAC address has the following structure:

Bit value 47 ... 24			Bit value 23 ... 0		
10	B9	FE	X	X	X
Company code (OUI)			Consecutive number		

The MAC address can also be read next to the **F6-01-03 Physical Address** attribute. Refer to the "8.12.7 Class F6h: Ethernet Link Object" section on page 120.

It is further shown in the **Encoder Information** page of the web server under the title of the page. Refer to the "9.4 Encoder information (EtherNet/IP attributes)" section on page 136.

## 7.5 Encoder installation under Studio 5000 design environment

### 7.5.1 Description of the EDS file

The functionality of an EtherNet/IP device is always described in an EDS file (Electronic Data Sheet file). The Electronic Data Sheet file provides information about the device basic communication and functional properties. It must be installed in the Controller.

XAC77 encoders with EtherNet/IP interface from Lika Electronic are supplied with EDS files.

EDS files are provided for singleturn encoder version and for multiturn encoder version, please refer to the order code: HS58 series EDS file is suitable for XAC77-18-00-... singleturn encoder; HM58 series EDS file is suitable for XAC77-16-14-... multiturn encoder.

They are:

- **HSx58x\_EP\_Hx\_Sx.eds**: it is intended for installation of **XAC77-18-00-... encoders**; ("HSx58x" is the encoder series; "EP" is the Lika code that identifies the EtherNet/IP protocol; "Hx" is the hardware version of the encoder; "Sx" is the software version of the encoder);
- **HMx58x\_EP\_Hx\_Sx.eds**: it is intended for installation of **XAC77-16-14-... encoders**.

The version of the EDS file is reported under the Version item inside the file.

EDS files can be paired with the **Lika\_Encoder\_EIP.ico** picture file available inside the file folder (the picture is also integrated into the EDS file).

Follow the path **www.lika.biz > PRODUCTS > ROTARY ENCODERS > ABSOLUTE** to download the EDS files from Lika's corporate web site.



### 7.5.2 Configuring the network interface controller (NIC) of the computer

To set the computer's IP address in Windows, type *network and sharing* into the **Search** box in the **Start** menu and select **Network and Sharing Center** when the **Control Panel** comes up.




Figure 4 – Network and Sharing Center

Then when the **Network and Sharing Center** opens, click on **Change adapter settings**.




Figure 5 – Change adapter settings

Right-click on your local adapter and select **Properties**.




Figure 6 – Local Area Connection properties

In the **Local Area Connection Properties** window highlight *Internet Protocol Version 4 (TCP/IPv4)*, then click the **Properties** button.




Figure 7 – Internet Protocol Version 4 properties

Now select the **Use the following IP address** radio button and enter in the correct IP, Subnet mask, and Default gateway that corresponds with your network setup. Then, if required, enter your Preferred and Alternate DNS Server addresses. We suggest setting a simple Class C network configuration such as 192.168.1.xx as the default software IP address of the encoder has this NET ID. Check **Validate settings upon exit** so Windows can find any problems with the addresses you entered. When you are finished click **OK**.




Figure 8 - Setting the IP Address

### 7.5.3 Networking the PC and the Controller

Use a Category 5 minimum cable to network the Ethernet port of the PC to the Ethernet port of the Controller.

### 7.5.4 Configuring the driver

Launch the **RSLink Classic** communication software and then open **RSWho** by pressing **Communication** and then the **RSWho** command.

Again in the menu bar of the main page press **Communication** and then the **Configure Drivers** command.

The **Configure Drivers** dialog box will appear.




Figure 9 – Configure Drivers

From the **Configure Drivers** dialog box, select the desired driver from the **Available Driver Types** list.

Click **Add New**. The **Add New RSLink Classic Driver** dialog box opens.

Enter a name for the selected driver (15 characters at maximum), and click **OK**. The **Configuration** dialog box for that driver shows.

In the **Configuration** dialog box, enter the appropriate parameters for the desired driver.

Click **OK** to close the **Configuration** dialog box. The new driver now appears in the **Configured Drivers** list.

Press **Close** to close the dialog box.

Now right-click the driver you have just installed and press **Configure Driver**.




Figure 10 - Configure Driver

In the **Configure Driver** dialog box, select the network interface controller you configured and connected to the PLC; finally press **OK** to confirm.




Figure 11 - Browse Local Subnet

### 7.5.5 Starting a new project

Double-click on the **Studio 5000** icon on your Desktop to launch Studio 5000 software. The Studio 5000 Splash Screen appears.

Select **New Project** under the **Create** section.



Figure 12 - Studio 5000 New Project

When the **New Project** pop-up is displayed, select **Logix** and the type of controller (such as "1769-L16ER-BB1B", in the example). Enter the name of the project and the path where the file has to be saved.




Figure 13 - New Project

Press the **Next** button and then set the **Revision** and the **Expansion I/O** settings. Finalize by pressing the **Finish** button.




Figure 14 - Controller's settings

### 7.5.6 Installing the EDS file

To manually register the EDS files of the encoder in the **EDS Hardware Installation Tool**, perform the following steps.

Launch the **EDS Hardware Installation Tool** by pressing **Tools** and then the **EDS Hardware Installation Tool** command.

The **Rockwell Automation's EDS Wizard** dialog box opens.

On the **Options** screen select **Register an EDS file(s)**, then press **Next**.




Figure 15 - EDS Wizard

On the **Registration** screen select **Register a single file** to register one EDS file at a time, and click **Browse** to select the EDS file corresponding to the encoder to be installed (such as HMx58x\_EP\_H1\_S1.eds in the screenshot Figure 16, please check the order code) and press the **Next** button until the registration is finalized.




Figure 16 – EDS Wizard

### 7.5.7 Defining the communication path

To define a path to the controller click on the icon shown in Figure 17.




Figure 17 – Path to Controller



Browse to the Controller, select it, and click the **Set Project Path** button.




Figure 18 - Set Project Path

Close the dialog box: the selected path will appear on the main page.




Figure 19 - Project Path set

### 7.5.8 Adding the encoder to the project

On the **Controller Organizer**, right-click on **Ethernet** and select **New Module ...** from the pull-down menu.




Figure 20 - New Module

On the **Select Module Type** dialog box select the installed encoder module (HMx58x... in the screenshot, Figure 21). Click **Create**.




Figure 21 - Select Module Type

Configure the encoder module by setting the required parameters **Name** and **Ethernet Address**. Then press **Change...** button to select the connection type.




Figure 22 - New module configuration

Select the required connection type and then click **OK**. For more information on the available connection types refer to the "8.12.3.4 Supported connection types" section on page 92.




Figure 23 - Select connection type

In the example an Input Only connection has been set: the encoder will transmit both position and velocity values (i.e. it produces instances), while the Controller will send parameters configuration at switching on (the encoder will receive configuration data).

Set DINT data type in order to display properly the position and velocity values. Press **OK** to finalize and **YES** in the next dialog box.

Close the **New Module** and **Select Module Type** dialog boxes.

### 7.5.9 Checking the communication

You can check whether the communication between the Controller and the encoder is established properly by displaying the encoder parameters.

On the **Controller Organizer**, double-click on **Controller Tags** in the **Controller\_Test\_encoder** folder: the encoder parameters will be displayed in the **Monitor Tags** tabbed page. The **Monitor Tags** page displays the tags.




Figure 24 - Monitor Tags

### 7.5.10 Downloading the configuration to the Controller

To download the configuration to the Controller you must go online first.

Press the drop-down box between the **Offline** and **RUN** items and select **Go Online** in the pull-down menu.




Figure 25 - Going online

Press **Download** in the **Who Active** window to start the download process; the **Download** window will be displayed. Before pressing the **Download** button once more please note the cautionary messages. Click **Download** to continue the download process.

When the download process is completed, the Controller may return to Remote Program mode or ask whether you want to return to Run mode. The message you see is determined by the state the Controller was in at the beginning of the download process.

If everything went well, the encoder is online while the Scanner is in **Idle** state.

### 7.5.11 Configuring the encoder

Before executing the download process, you can set the configuration parameters of the encoder.

On the **Controller Organizer**, right-click **Controller Tags** and choose **Monitor Tags**: the Tag Monitor displays the tags.

A blue arrow indicates that when you change the value, it immediately takes effect.

To see a value in a different style, select the desired style.

To change a value, click the **Value** cell, type the new value, and click **ENTER**.

To expand a tag and show its members, click the **+** sign.



#### WARNING

Parameters are not saved on the non-volatile memory. At next power-on you are required to send them again.

To save the parameters permanently you can choose among the following methods: by means of the Class Service 16h, see on page 97; or by setting the bit 6 **Save Parameters** in the **23-01-68 Command Register** attribute to 1 and then back to 0, see on page 112; or by using the **Save Parameters** function in the **Set Encoder Registers** page of the Integrated Web Server, see the "9.6 Setting the attributes" section on page 139.

### 7.5.12 How to create a sample program and send parameters

Here follows a description of a simple program created using Ladder programming language. The program allows to send a preset "1000" to the encoder by means of EtherNet/IP explicit messages with CIP protocol. See also the **23-01-13 Preset Value** attribute on page 102.

Described program can be used as a base to build further programs: the procedure is exactly the same, you have just to change the Attribute value and the type of variable of the parameter.



## NOTE

As previously stated, the documentation of Lika Electronic encoder with EtherNet/IP interface is complete with a **sample project** supplied free of charge. This program is designed to make your own project planning, programming, communication, and diagnostics with Studio 5000 V30.00 design environment user-friendly and reliable. You can find it in the **SW\_Hx58x\_EP\_Example.zip** compressed file.

Three demo programs are available.

- **Test\_encoder\_Lika.acd** program allows the user to set and execute the preset (**23-01-13 Preset Value**). It is fully described in the following pages.
- **Test\_encoder\_demo.acd** program allows the user to set and execute the preset (**23-01-13 Preset Value**); to set the singleturn resolution (**23-01-10 Measuring Units per Span**) and the total resolution (**23-01-11 Total Measuring Range**); and to send the **23-01-68 Command Register** attribute.
- **Test\_encoder\_ST\_2.acd** program allows the user to set and execute the preset (**23-01-13 Preset Value**); to set high the output 0 when the **23-01-03 Position value** attribute is greater than 10,000 cps; to set high the output 1 when the **23-01-18 Velocity Value** attribute is greater than 10,000 cps; and to set high the output 2 when the **23-01-18 Velocity Value** attribute is lower than (-10,000) cps.

Each program requires a main routine. Once you create your routines, assign a main routine for each program.

On the **Controller Organizer**, expand the **Tasks**, **MainTask**, and **MainProgram** folders and double-click on **MainRoutine**: the **MainProgram – MainRoutine** ladder window appears.




Figure 26 – MainProgram – MainRoutine ladder window

We need to create some tags (variables) that are needful for the program.  
On the **Controller Organizer**, right-click on **Controller Tags**, and select **New Tag...** from the pull-down menu.






Figure 27 - New Tag

The following tags need to be created:

**PresetTrigger** tag, data type BOOL



**PresetOneShot** tag, data type BOOL



PresetMessage tag, data type MESSAGE

The 'New Tag' dialog box for 'PresetMessage' shows the following configuration: Name: PresetMessage, Description: (empty), Usage: <controller>, Type: Base, Alias For: (empty), Data Type: MESSAGE, Parameter Connection: (empty), Scope: Test\_encoder\_Lika, External Access: Read/Write, Style: (empty). Checkboxes for Constant, Sequencing, Open MESSAGE Configuration, and Open Parameter Connections are all unchecked.

PresetValue tag, data type DINT

The 'New Tag' dialog box for 'PresetValue' shows the following configuration: Name: PresetValue, Description: (empty), Usage: <controller>, Type: Base, Alias For: (empty), Data Type: DINT, Parameter Connection: (empty), Scope: Test\_encoder\_Lika, External Access: Read/Write, Style: Decimal. Checkboxes for Constant, Sequencing, Open Configuration, and Open Parameter Connections are all unchecked.



#### NOTE

You can type any name for the tags.

Now we need to add ladder logics to the program. To enter logics you must drag buttons from the **Logic Element** toolbar to the desired location. A green dot shows a valid placement location (drop point).

Drag the **"Examine ON (XIC, Examine If Closed)"** logic element onto rung 0 until the green dot appears. Release the mouse button at the location you wish to place your instruction.

Repeat the operation to add a **"One Shot Block (ONS)"** logic element.




Figure 28 – Dragging logic elements





## NOTE

If you place an instruction in the wrong location on a rung, simply click and hold on the instruction and drag it to the correct location.

Double-click the question mark in the "**Examine ON (XIC)**" logic to assign the **PresetTrigger** tag. Choose the tag from the variable list in the drop-down menu.




Figure 29 - Assigning tags

Double-click the question mark in the "**One Shot Block (ONS)**" logic to assign the **PresetOneShot** tag. Choose the tag from the variable list in the drop-down menu.

Finally you will get the following situation:




Figure 30 - Tags

Now drag a **"Message (MSG)"** logic from the **Logic Element** toolbar to the desired location. Assign the **PresetMessage** tag as described above.





Figure 31 - Message logic element

Configure the message, press the  icon next to the **PresetMessage** label to open the **Message Configuration** dialog box. Configure both the **Configuration** and the **Communication** tabbed pages as shown in the following screenshots, Figure 32.




Figure 32 - Message Configuration

See the [23-01-13 Preset Value](#) attribute in the "8.12.5 Class 23h: Position Sensor Object" section on page 102.

On the **Controller Organizer**, double-click on **Controller Tags** in the **Controller\_Test\_encoder** folder: the encoder parameters will be displayed in the **Monitor Tags** tabbed page. The **Monitor Tags** page displays the tags.




Figure 33 - Setting variables

Set the **PresetOneShot** variable to "0", the **PresetTrigger** variable to "0" and the **PresetValue** variable to "1000", as shown in the screenshot above, Figure 33. To change a value, click the **Value** cell, type the new value, and click **ENTER**. Click the **Style** cell and set the three variables to "Decimal".

Now go online, download data to the Controller and then put the Controller in Run mode.

On the **Controller Organizer**, expand the **Tasks**, **MainTask**, and **MainProgram** folders and double-click on **MainRoutine**: the **MainProgram – MainRoutine** ladder window appears.





Figure 34 – MainProgram – MainRoutine ladder window

Right-click on the **PresetTrigger** logic element and select **Toggle Bit** from the pull-down menu. The position of the encoder will be preset to the value "1000".



### Figure 35 - Setting the Toggle bit

Both the **PresetOneShot** variable and the **PresetTrigger** variable in the **Monitor Tags** tabbed page will be set to "1".




Figure 36 – Monitor Tags

Again right-click on the **PresetTrigger** logic element and select **Toggle Bit** from the pull-down menu to set the variables back to 0.

## 8 EtherNet/IP interface

### 8.1 Introduction to EtherNet/IP

EtherNet/IP is the name given to the Common Industrial Protocol (CIP), as implemented over standard Ethernet (IEEE 802.3 and the TCP/IP protocol suite). EtherNet/IP was introduced in 2001 and today is the most developed, proven, and complete industrial Ethernet network solution available for manufacturing automation, with rapid growth as users seek to harness the advantages of open technologies and the Internet. EtherNet/IP is a member of a family of networks that implements CIP at its upper layers.

EtherNet/IP and CIP are managed by ODVA, see later. ODVA publishes "The EtherNet/IP™ Specification" and helps ensure compliance through conformance testing.

### 8.2 CIP protocol

The Common Industrial Protocol (CIP) is a media independent, connection-based, object-oriented protocol designed for automation applications. It encompasses a comprehensive set of communication services for automation applications: control, safety, synchronization, motion, configuration, and information. It allows users to integrate these applications with enterprise-level Ethernet networks and the Internet. CIP provides users with a unified communication architecture throughout the manufacturing enterprise. CIP allows users to benefit from the many advantages of open networks while protecting their existing automation investments when upgrading in the future. CIP brings:

- Coherent integration of I/O control, device configuration, and data collection.
- Seamless flow of information across multiple networks.
- Ability to implement multi-layer networks without the added cost and complexity of bridges and proxies.
- Minimized investment in system engineering, installation, and commissioning.

The "IP" in "EtherNet/IP" refers to "Industrial Protocol". EtherNet/IP utilizes CIP over standard IEEE 802.3 and the TCP/IP protocol suite. Since EtherNet/IP uses standard Ethernet and TCP/IP technologies, it allows compatibility and coexistence with other applications and protocols.

### 8.3 CIP and International Standards

CIP technologies are compliant with a number of fieldbus-related international standards, and are generally referred to as members of CPF 2 (Communication Profile Family 2) of IEC 61158.

- IEC 61158: Specifies various fieldbus protocols for applications ranging from discrete manufacturing to process control. It includes the

specifications for CIP, as well as EtherNet/IP and ControlNet-specific protocol elements, as Type 2.

- IEC 61784-1 and IEC 61784-2: Specify general-purpose and real time Ethernet fieldbus Communication Profiles (CPs) (i.e., how to build a specific communication network using IEC 61158 and other standards). ControlNet, EtherNet/IP, and DeviceNet are defined respectively as CP 2/1, CP 2/2 (CP 2/2.1 with CIP Sync), and CP 2/3.
- IEC 61784-3: Specifies Functional Safety Communication Profiles (FSCPs), i.e., extensions of fieldbuses for use in safety related applications. CIP Safety is included as FSCP 2/1.
- IEC 61918 & IEC 61784-5: Specify general and fieldbus-specific cabling installation guidelines. IEC 61784-5 includes specific guidelines for ControlNet, EtherNet/IP, and DeviceNet.
- IEC 61800-7: Specifies profiles for power drive systems and their mapping to existing communication systems by use of a generic interface. It includes CIP Motion and its mapping on ControlNet, EtherNet/IP, and DeviceNet.
- ISO 15745: Defines elements and rules for application integration, including communication network profiles and the communication aspects of device profiles for some fieldbus technologies. EDS files used for device and network integration of DeviceNet, ControlNet, or EtherNet/IP applications are compliant with the relevant parts of ISO 15745 (respectively Parts 2, 3, and 4).

Also:

- The lower layers of EtherNet/IP are based on the various RFC Internet standards for the TCP/UDP/IP suite, on the IEEE 802.3 and ISO Ethernet standards (ISO/IEC 8802-3), without modification or extension.
- CIP Safety (on EtherNet/IP) has been certified for use in applications in systems needing to meet the requirements of IEC 61508 up to and including SIL3.

#### **8.4 EtherNet/IP adaptation to CIP**

EtherNet/IP, like other CIP Networks, follows the Open Systems Interconnection (OSI) model, which defines a framework for implementing network protocols in seven layers: physical, data link, network, transport, session, presentation, and application. Networks that follow this model define a complete suite of network functionality from the physical implementation through the application or user interface layer. As with all CIP Networks, EtherNet/IP implements CIP at the Session layer and above and adapts CIP to the specific EtherNet/IP technology at the Transport layer and below. This network architecture is shown in Figure 37.

Ethernet has the unique characteristic of being a network with an active infrastructure. Therefore, unlike typical device or control level networks—which generally have a passive infrastructure that limits the number of devices that can be connected and the way they can be connected—the EtherNet/IP network infrastructure can accommodate a virtually unlimited number of point-to-point nodes, providing users with unsurpassed flexibility in designing networks that accommodate their current requirements while enabling easy, cost-effective expansion in the future.




Figure 37 – EtherNet/IP adaptation to CIP

To further decrease complexity, EtherNet/IP systems require only a single point of connection for both configuration and control, because EtherNet/IP supports both I/O (or implicit) messages—those that typically contain time-critical control data—and explicit messages—those in which the data field carries both protocol information and instructions for service performance (see the “8.9.4 Types of EtherNet/IP communications” section on page 82). And, as a producer-consumer network that supports multiple communication hierarchies and message prioritization, EtherNet/IP provides more efficient use of bandwidth than a device network based on a source-destination model. EtherNet/IP systems can be configured to operate either in a Master/Slave or distributed control architecture using peer-to-peer communication.

### 8.5 The Physical Layer

EtherNet/IP uses standard IEEE 802.3 technology at the Physical and Data Link Layers. This standard provides a specification for physical media, defines a simple frame format for moving packets of data between devices, and supplies a set of rules for determining how network devices respond when two devices attempt to use a data channel simultaneously. This is known as CSMA/CD (Carrier Sense Multiple Access/Collision Detection).

As a network with an active infrastructure, EtherNet/IP is typically configured using a series of network segments constructed of point-to-point connections in a star configuration. The core of this network topology is an interconnection of Ethernet Layer 2 and Layer 3 switches that can accommodate an unlimited number of point-to-point nodes.

### 8.6 The Data Link Layer

IEEE’s 802.3 specification is also the standard used for transmitting packets of data from device to device on the EtherNet/IP Data Link Layer. Ethernet employs



a CSMA/CD media access mechanism that determines how networked devices share a common bus (i.e., cable), and how they detect and respond to data collisions.

Originally, Ethernet worked in a half-duplex mode of operation, meaning that a node could send or receive data, but it could not do both at the same time. This caused data traffic jams, which are unacceptable in time-critical control applications. With full-duplex Ethernet, networked devices can both send and receive packets of Ethernet data at the same time. This is one of several advances in Ethernet technology that has increased its level of determinism to the point where Ethernet can be used in an ever-increasing number of manufacturing applications.

The Media Access Control (MAC) protocol of the IEEE 802.3 specification is what actually allows devices to "talk" on the Ethernet network. Each device has a unique MAC address comprised of a 6-byte number that is regulated by IEEE and the product manufacturer to maintain uniqueness (refer also to the "7.4 MAC address" section on page 51). This MAC address is used in the source address (SA) field of the frame to indicate what node sent the frame, and it is used in the destination address (DA) field to indicate the destination of the frame. Setting the first bit to a "1" in the DA field indicates a packet of data for multiple destinations, and enables an Ethernet node to transmit a single data packet to broadcast to the various destinations.

A single frame of industrial EtherNet/IP can contain up to 1,500 bytes of data, depending on the application requirements. The combination of real-time control with high-data capacity makes industrial Ethernet increasingly attractive, as more intelligence is embedded into smaller and less-expensive devices.

## 8.7 Ethernet data packets

Ethernet data packets are sent in the format shown in Figure 38.




Figure 38 - Typical layout of an Ethernet Data Packet

This data format is used to implement the **Media Access Control (MAC)** protocol that allows a device to "talk" on the Ethernet network. Each MAC device has a unique **Source Address (SA)** comprised of a 6-byte number (48 bits or 12 hexadecimal digits) that was assigned to it at the time of manufacture. The **Destination Address (DA)** is the target MAC address for which the packet of data is intended. Setting the first bit to a "1" in the DA field, indicates a packet of data for multiple destinations. This enables an Ethernet device to transmit one packet that can be received by multiple other devices.

There are a number of different types of Ethernet packets that can be sent and received on an Ethernet network. Some of these protocols are Novell's IPX/SPX, DECNET, UDP, TCP/IP, FTP, TELNET, and so on. All of these unique protocols use the MAC to do the physical sending and receiving of data packets. However, by defining how the "DATA" portion of the data packet is organized, different protocols and functions are created.

### 8.8 The Network and Transport Layers

At the Network and Transport Layers, EtherNet/IP utilizes the Internet standard known as the Transmission Control Protocol/Internet Protocol (TCP/IP) Suite to send messages between one or more devices. TCP/IP provides the necessary communication protocol features needed to implement fully functional networks (i.e., an addressing scheme and mechanisms for establishing a connection with a device and exchanging data) that the IEEE specification in and of itself lacks.

Also, at these layers, the standard CIP messages used by all CIP Networks are encapsulated. TCP/IP encapsulation allows a node on the network to embed a message as the data portion in an Ethernet message. The node then sends the message -TCP/IP protocol with the message inside- to an Ethernet communication chip (the Data Link Layer). By using TCP/IP, EtherNet/IP is able to send **explicit messages**, which are used to perform Client-Server type transactions between nodes.

The TCP/IP Suite consists of the following:

- The TCP portion of the TCP/IP protocol is a connection-oriented, unicast transport mechanism that provides data flow control, fragmentation reassembly, and message acknowledgments. Nodes must interpret each message, execute the requested task, and generate responses. Since TCP is ideal for the reliable transmission of large quantities of data, EtherNet/IP uses TCP/IP to encapsulate CIP explicit messages, which are generally used to transmit configuration, diagnostic and event data.
- The IP portion of the TCP/IP protocol is the mechanism that enables packet routing through multiple possible paths. The ability to send messages to their destinations even when the primary path is disrupted is the basis of the Internet. This same type of routing is used in industrial networks to maintain proper separation of control elements and other factory infrastructure through the use of managed switches and Layer 3 routers. All devices and infrastructure components with added diagnostic capabilities (managed switches and routers) on an industrial

Ethernet-based system must be assigned an IP address. This is most commonly identified by the four-byte address listed in the "network properties" on personal computers that use TCP/IP as their Ethernet network connection (e.g., 192.168.1.10). IP addresses must be unique on a given network (see also the "6.6 EtherNet/IP Node ID" section on page 44).

For real-time messaging, EtherNet/IP also employs UDP over IP, which allows messages to be multicast to a group of destination addresses. This is how CIP I/O data transfers (**implicit messaging**, see the "8.9.4 Types of EtherNet/IP communications" section later) are sent on EtherNet/IP. With implicit messaging, the data field contains no protocol information, only real-time I/O data. Since the meaning of the data is pre-defined at the time the connection is established, processing time is minimized during runtime. UDP is connectionless and makes no guarantee that data will get from one device to another; however, UDP messages are smaller and can be processed more quickly than explicit messages. As a result, EtherNet/IP uses UDP/IP to transport I/O messages that typically contain time-critical control data. The CIP Connection mechanism provides timeout mechanisms that can detect data delivery problems, a capability that is essential for reliable control system performance.

## 8.9 Upper Layers: Objects, Services, and Application Data

### 8.9.1 EtherNet/IP services

The CIP application layer defines a set of **application objects** and **device profiles** that define common interfaces and behaviors. In addition, CIP communication services enable end-to-end communication between devices on the different CIP networks. EtherNet/IP maps the CIP communication services to Ethernet and TCP/IP, enabling multi-vendor interoperability between devices on Ethernet as well as with the other CIP networks.

### 8.9.2 Simplified EtherNet/IP Object Model Overview

Within the CIP application layer, devices are represented using an object model (Figure 39). **Application objects** define how device data is represented and accessed in a common way. **Network-specific objects** define how parameters such as IP addresses are configured and EtherNet/IP specific functions. Communication objects and services provide the means to establish communication associations and access device data and services over the network.




Figure 39 - EtherNet/IP Object Model

### 8.9.3 Exposing Application Data with CIP

**Objects** within a device are groups of related data and behavior associated with this data. CIP requires certain objects to describe a device, how it functions, communicates and its unique identity. The **Identity Object** (see on page 87), for example, contains identity data values called **attributes** that are used to store the identity information of a device. Attributes for the Identity Object include the Vendor ID, Device Type, device serial number, and other identity data. CIP does not specify how object data is implemented, rather, which data values or attributes must be supported and made available to other CIP devices.

There are three types of objects defined by CIP:

- **Required Objects** must be included in all CIP devices. These objects include the Identity Object (page 87), the Message Router Object (page 91), and network-specific objects such as TCP/IP Interface Object (page 115) and Ethernet Link Object (page 120) for EtherNet/IP protocol.
- **Application Objects** describe how data is encapsulated by a device. These objects are specific to the Device Type and function. For example, an input device would have an input object with attributes that describe the value and fault status of a particular input point. See Position Sensor Object (page 97).
- **Vendor-specific Objects** describe services that are specific to a particular vendor; they are optional and not described in a predefined Device Profile. They are not supported by Lika encoders.

Addressing data within a CIP device utilizes the same object-oriented view. A **class** (of objects) is a set of objects that represent the same type of system component (Figure 40). Sometimes it is necessary to have more than one 'copy'

of an object, called **object instances**, within a device. This set of objects is called an **object class**. Each instance of the object class will have the same set of attributes, but will have a unique set of values. An object instance or an object class has **attributes**, providing services and implementing behavior.




Figure 40 – CIP Object-oriented view of application data

The following Object Modeling related terms are used when describing CIP services and protocol.

- **Object** – An abstract representation of a particular component within a product.
- **Class** – A set of objects that all represent the same kind of system component. A class is a generalization of an object. All objects in a class are identical in form and behavior, but may contain different attribute values.
- **Instance** – A specific and real (physical) occurrence of an object. For example: New Zealand is an instance of the object class Country. The terms Object, Instance, and Object Instance all refer to a specific Instance.
- **Attribute** – A description of an externally visible characteristic or feature of an object. Typically, attributes provide status information or govern the operation of an Object. For example: the ASCII name of an object; and the repetition rate of a cyclic object.
- **Instantiate** – To create an instance of an object with all instance attributes initialized to zero unless default values are specified in the object definition.
- **Behavior** – A specification of how an object acts. Actions result from different events the object detects, such as receiving service requests, detecting internal faults or elapsing timers.
- **Service** – A function supported by an object and/or object class. CIP defines a set of common services and provides for the definition of Object Class and/or Vendor Specific services.
- **Communication Objects** – A reference to the Object Classes that manage and provide the runtime exchange of implicit (I/O) and explicit messages.
- **Application Objects** – A reference to multiple Object Classes that implement product-specific features.

Accessing data within a device using a non-time critical message (an explicit message – see “8.9.4 Types of EtherNet/IP communications” section on page 82) typically contains the following address information:

- Device network address
- Class ID
- Instance ID
- Attribute ID
- Service code (describing the action/service required)

The Class/Instance/Attribute ID form of addressing is also used in Electronic Data Sheets (EDS) to identify configurable parameters within a device.

In addition to specifying how device data is represented, CIP also specifies methods by which I/O data can be accessed, using triggers, such as cyclic or change-of-state. Vendors can also describe how data from different objects can be combined in an I/O or configuration message using the Assembly Object, refer to the “8.12.3 Class 04h: Assembly Object” section on page 92.

#### 8.9.4 Types of EtherNet/IP communications

EtherNet/IP defines two primary types of communications: **explicit** and **implicit**.

CIP Message Type	CIP Communication Relationship	Transport Protocol	Communication Type	Typical Use	Example
Explicit	Connected or Unconnected	TCP/IP	Request/reply transactions	Non time-critical information data	Read/Write configuration parameters
Implicit	Connected	UDP/IP	I/O data transfers	Real-time I/O data	Real-time control data from a remote I/O device

- **Explicit Messaging** in general has a request/reply (or Client/Server) nature. This type of communication is **used for non-real-time data**, normally for information. Explicit messages include a description of their meaning (expressed explicitly), so the transmission is less efficient, but very flexible. It may be used by an HMI to collect data, or by a device programming tool. In CIP terms, with Explicit Messaging you request a service of a particular object, e.g., a read or a write service. For EtherNet/IP, Explicit Messaging uses TCP. Explicit Messaging can be done with or without prior establishment of a CIP connection.
- **Implicit Messaging** is also often referred to as **“I/O”** and is **time-critical** in nature. Typically this type of communication is used for **real-time data exchange**, where speed and low latency are important. Implicit messages include very little information about their meaning, so the transmission is more efficient, but less flexible than explicit. The interpretation of the transmitted data is fast. With Implicit Messaging

you establish an association (a "CIP connection") between two devices and produce the Implicit Messages according to a predetermined trigger mechanism, typically at a specified packet rate. The devices both know and agree on the data formats they will use (i.e., the format is "implied"). For EtherNet/IP, Implicit Messaging uses UDP and can be multicast or unicast.

Connections are established using the ForwardOpen Request service of the Connection Manager Object, see the "8.12.4 Class 06h: Connection Manager Object" section on page 96. The ForwardOpen Request contains all of the connection parameters, including transport class, production trigger, timing information, electronic key, and connection IDs. Connection clean-up takes place when a ForwardClose Request service request is issued or when either connection end point times out.

Implicit messaging can make use of the CIP Producer/Consumer communication model. With **Producer/Consumer**, the producing device transmits data once, regardless of the number of consumers. All interested consuming devices receive the same data. For EtherNet/IP the produced data is identified by the IP multicast address and the CIP Connection ID. The Producer/Consumer model leads to greater network efficiency when multiple consumers need to receive the same data from a producer. For I/O connections, once the connection is established there is no request/response, the data with the ConnectionID is just produced and consumed at intervals determined by the Production Trigger which was specified at connection establishment. Triggers can be Cyclic (most common), Change of State (CoS), or Application.

### 8.9.5 Types of EtherNet/IP devices

Several device classifications, based on their general behavior and types of EtherNet/IP communications they support, have been defined:

- **Explicit Message Server:** An explicit message server responds to request/response oriented communications initiated by explicit message clients. An example of an explicit message server is a bar code reader.
- **Explicit Message Client:** An explicit message client initiates request/response oriented communications with other devices. Message rates and latency requirements are typically not too demanding. Examples of explicit message clients are HMI devices, programming tools, or PC or Linux based applications that gather data from control devices.
- **I/O Adapter:** An I/O adapter receives implicit communication connection requests from an I/O scanner, then produces its I/O data at the requested rate. An I/O adapter is also an explicit message server. An I/O adapter can be a simple digital input device, or something more complex such as a modular pneumatic valve system.
- **I/O Scanner:** An I/O scanner initiates implicit communications with I/O adapter devices. A scanner is typically the most complex type of EtherNet/IP device, as it must deal with issues such as configuration of which connections to make, and how to configure the adapter device.

Scanners also typically support initiating explicit messages. A programmable controller is an example of an I/O scanner.

### 8.10 ODVA

ODVA is an international association comprising members from the world's leading automation companies. Collectively, ODVA and its members support network technologies based on the Common Industrial Protocol (CIP™). These currently include DeviceNet™, EtherNet/IP™, CompoNet™, and ControlNet™, along with the major extensions to CIP – CIP Safety™, CIP Sync™, and CIP Motion™. ODVA manages the development of these open technologies, and assists manufacturers and users of CIP Networks through its activities in standards development, certification, vendor education, and industry awareness.

For further information on ODVA, see the ODVA website: [www.odva.org](http://www.odva.org).

### 8.11 EDS file

The functionality of an EtherNet/IP device is always described in an EDS file (Electronic Data Sheet file). The Electronic Data Sheet File provides information about the device basic communication and functional properties. It must be installed in the Controller.

XAC77 encoders with EtherNet/IP interface from Lika Electronic are supplied with EDS files.

EDS files are provided for singleturn encoder version and for multiturn encoder version, please refer to the order code: HS58 series EDS file is suitable for XAC77-18-00-... singleturn encoder; HM58 series EDS file is suitable for XAC77-16-14-... multiturn encoder.

They are:

- **HSx58x\_EP\_Hx\_Sx.eds** ("HSx58x" is the encoder series; "EP" is the Lika code that identifies the EtherNet/IP protocol; "Hx" is the hardware version of the encoder; "Sx" is the software version of the encoder): it is intended for installation of **XAC77-18-00-... singleturn encoders**;
- **HMx58x\_EP\_Hx\_Sx.eds**: it is intended for installation of **XAC77-16-14-... multiturn encoders**.

The version of the EDS file is reported under the Version item inside the file.

EDS files can be paired with the **Lika\_Encoder\_EIP.ico** picture file available inside the file folder (the picture is also integrated into the EDS file).

Follow the path **www.lika.biz > PRODUCTS > ROTARY ENCODERS > ABSOLUTE** to download the EDS files from Lika's corporate web site.



## 8.12 Object Library

As previously stated, object modeling is used to represent the network visible behavior of devices (i.e. the encoder). Devices are modeled as a collection of objects. Each class of objects is a collection of related services, attributes, and behaviors. Services are the procedures that an object performs. Attributes are characteristics of objects represented by values, which can vary. An object's behavior is an indication of how the object responds to particular events. For more information refer to the "8.9.3 Exposing Application Data with CIP" section on page 80.

This section contains the description of the objects specific to Lika encoders, including services and attributes.

In the following pages the Class Attributes are listed and described as follows:

### **Class-Attribute ID Attribute name**

[Data type, Access Rule, NV]

While the Instance Attributes are listed and described as follows:

### **Class-Instance-Attribute ID Attribute name**

[Data type, Access Rule, NV]

- Class, instance and attribute are expressed in hexadecimal notation.
- Data types are as shown in the following table:

Data type	Code	Name	Range
BOOL	C1h	Boolean	0 (FALSE) and 1 (TRUE)
SINT	C2h	Signed 8-bit integer	-128 to +127
INT	C3h	Signed 16-bit integer	-32,768 to +32,767
DINT	C4h	Signed 32-bit integer	-2 <sup>31</sup> to +2 <sup>31</sup> -1
LINT	C5h	Signed 64-bit integer	-2 <sup>63</sup> to +2 <sup>63</sup> -1
USINT	C6h	Unsigned 8-bit integer	0 to 255
UINT	C7h	Unsigned 16-bit integer	0 to 65,535
UDINT	C8h	Unsigned 32-bit integer	0 to 2 <sup>31</sup> -1
ULINT	C9h	Unsigned 64-bit integer	0 to 2 <sup>63</sup> -1
STRING	D0h	Character string	1 byte per character
BYTE	D1h	Bit string – 8 bits	2#b <sub>N-1</sub> b <sub>N-2</sub> ...b <sub>2</sub> b <sub>1</sub> b <sub>0</sub> , where N is the number of bits in the bit string, b <sub>N-1</sub> is the "most significant bit", and b <sub>0</sub> is the "least significant bit"
WORD	D2h	Bit string – 16 bits	
SHORT_STRING	DAh	Character string	1 byte per character, 1 byte length indicator

ENGUNIT	DDh	Engineering unit	0 to 65,535
---------	-----	------------------	-------------

- Access rule can be:

Get (Gettable): the same as "ro" = read only access. The attribute can be accessed by at least one of the get services.

Set (Settable): the same as "rw" = read and write access. The attribute shall be accessed by at least one of the set services. Settable attributes, unless otherwise specified by the object definition, shall also be accessed by get services.

- NV

It indicates whether an attribute value is maintained through power cycles. An entry of 'NV' indicates value shall be saved, 'V' means not saved.

- Default, Min., and Max. values

Default, Min., and Max. values are expressed in hexadecimal notation, unless otherwise indicated.



#### NOTE

All data bytes are sent from least significant byte (LSB) to most significant byte (MSB).

### 8.12.1 Class 01h: Identity Object

Class Code	Object Class	Access	Nr. of Instances
01h	Identity Object	Get	1

The Identity Object provides identification of and general information about the encoder (e.g. Vendor ID, device type, product code, etc.). Instance 1, which is the only mandatory instance, describes the whole product. It is used by applications to determine what nodes are on the network and to match an EDS file with a product on the network.

#### 8.12.1.1 Supported Class Services

The supported **Class Services** of the Identity Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.1.2 Class Attributes

##### 01-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0001h.

Default = 0001h

##### 01-02 Max Instance

[UINT, Get, NV]

The largest instance number of a created object in this class.

Default = 0001h

##### 01-03 Number of Instances

[UINT, Get, NV]

The number of object instances in this class.

Default = 0001h

#### 8.12.1.3 Supported Instance Services

The supported **Instance Services** of the Identity Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

05h = Reset: the following types of reset are defined:

0 = Power Cycle Reset It emulates a power cycling of the encoder.

1 = Return to Factory Defaults Reset It returns to the factory default configuration of the encoder parameters and communication link parameters and emulates a power cycling of the encoder.



#### NOTE

After executing a Return to Factory Defaults reset (type 1), the encoder restarts using the IP address saved internally.

### 8.12.1.4 Instance Attributes

#### 01-01-01 Vendor ID

[UINT, Get, NV]

Identification of the vendor by its own number. Lika Vendor ID is 0299h = 665. Vendor IDs are managed by ODVA.

Default = 0299h = Lika Electronic Srl

#### 01-01-02 Device type

[UINT, Get, NV]

The Device Type value is used to identify the device profile that a particular product is using. Device profiles are managed by ODVA and define minimum requirements a device must implement, as well as common options.

Default = 0022h: Encoder Device Profile.

#### 01-01-03 Product code

[UINT, Get, NV]

Product Code identifies a particular product within the encoder device type.

The available product codes are:

- 0003h = XAC77-18-00-EC2-... singleturn encoder
- 0004h = XAC77-16-14-EC2-... multiturn encoder

#### 01-01-04 Revision

[USINT, Get, NV]

The Revision attribute, which consists of Major and Minor Revisions, identifies the Revision of the item the Identity Object is representing. It is displayed as majorXX.minorYY, so representing the hardware (XX) and software (YY) revisions.

LSByte XX	MSByte YY
Major revision	Minor revision

Default = device dependent

**01-01-05 Status**

[WORD, Get, V]

This attribute represents the current status of the device. Its value changes as the state of the device changes. The Status attribute is a WORD, with the following bit definitions:

Bit(s)	Called	Definition																				
0	Owned	TRUE indicates the device (or an object within the device) has an owner. Within the Master/Slave paradigm the setting of this bit means that the Predefined Master/Slave Connection Set has been allocated to a Master. Outside the Master/Slave paradigm the meaning of this bit is TBD. 0 = no connection to the Master 1 = connection to the Master established																				
1	Reserved	Reserved, shall be 0																				
2	Configured	TRUE indicates the application of the device has been configured to do something different than the "out-of-box" default. This shall not include configuration of the communications. 0 = encoder is set to default parameters 1 = encoder is not set to default parameters																				
3	Reserved	Reserved, shall be 0																				
4-7	Extended device status	Bits are defined as follows: <table><tr><td>0000</td><td>Unknown</td></tr><tr><td>0001</td><td>Reserved</td></tr><tr><td>0010</td><td>At least one faulted I/O connection</td></tr><tr><td>0011</td><td>No I/O connection established</td></tr><tr><td>0100</td><td>Non-Volatile Configuration bad (EEPROM)</td></tr><tr><td>0101</td><td>Major Fault – either bit 10 or bit 11 is TRUE (1)</td></tr><tr><td>0110</td><td>At least one I/O connection in run mode</td></tr><tr><td>0111</td><td>At least one I/O connection established, all in idle mode</td></tr><tr><td>1000</td><td>...Reserved</td></tr><tr><td>1111</td><td></td></tr></table>	0000	Unknown	0001	Reserved	0010	At least one faulted I/O connection	0011	No I/O connection established	0100	Non-Volatile Configuration bad (EEPROM)	0101	Major Fault – either bit 10 or bit 11 is TRUE (1)	0110	At least one I/O connection in run mode	0111	At least one I/O connection established, all in idle mode	1000	...Reserved	1111	
0000	Unknown																					
0001	Reserved																					
0010	At least one faulted I/O connection																					
0011	No I/O connection established																					
0100	Non-Volatile Configuration bad (EEPROM)																					
0101	Major Fault – either bit 10 or bit 11 is TRUE (1)																					
0110	At least one I/O connection in run mode																					
0111	At least one I/O connection established, all in idle mode																					
1000	...Reserved																					
1111																						
8	Minor recoverable fault	TRUE indicates that the device detected a problem with itself, which is thought to be recoverable. The problem does not cause the device to go into one of the faulted states. Not implemented. For Alarms list refer to page 106																				
9	Minor unrecoverable fault	TRUE indicates that the device detected a problem with itself, which is thought to be unrecoverable. The problem does not cause the device to go into one of the faulted states. Not implemented. For Alarms list refer to page 106																				

10	Major recoverable fault	TRUE indicates that the device detected a problem with itself, which caused the device to go into the "Major Recoverable Fault" state. Not implemented. For Alarms list refer to page 106
11	Major unrecoverable fault	TRUE indicates that the device detected a problem with itself, which caused the device to go into the "Major Unrecoverable Fault" state. Not implemented. For Alarms list refer to page 106
12 ...15	Reserved	Reserved, shall be 0

For any further information on status instance attribute refer to the publication "The CIP Networks Library. Volume I. Common Industrial Protocol (CIP™)".

#### 01-01-06 Serial number

[UDINT, Get, NV]

This attribute is a number used in conjunction with the Vendor ID to form a unique identifier for each device on any CIP network.

The Serial Number is shown in the following format: YYwwnnnnn.

YY = Year

ww = week

nnnnn = unique number in ascending order assigned by Lika Electronic

Default = device dependent



#### EXAMPLE

172100123 has to be intended as follows:

17 = Year of production = 2017

21 = Week of production = week 21

00123 = unique number in ascending order assigned by Lika Electronic

#### 01-01-07 Product name

[SHORT\_STRING, Get, NV]

This text string represents a short description of the product represented by the Product Code in attribute **01-01-03 Product code**.

Default = "HSx58x Singleturn Encoder" = XAC77-18-00-EC2-... singleturn encoder

Default = "HMx58x Multiturn Encoder" = XAC77-16-14-EC2-... multiturn encoder

### 8.12.2 Class 02h: Message Router Object

Class Code	Object Class	Access	Nr. of Instances
02h	Message Router Object	Get	1

This object provides a messaging connection point through which a Client may address a service to any object class or instance residing in the encoder.

In Lika encoders it is used internally to direct object requests.

### 8.12.3 Class 04h: Assembly Object

Class Code	Object Class	Access	Nr. of Instances
04h	Assembly Object	Get	4

The Assembly Object binds attributes of multiple objects, which allows data to or from each object to be sent or received over a single connection. Assembly objects can be used to bind input data or output data. The terms "input" and "output" are defined from the network's point of view. An input will produce data on the network and an output will consume data from the network. Assembly objects instances are static: assemblies with member lists defined by the open device profile or vendor specific device profile. The Instance number, number of members, and member list are fixed.

#### 8.12.3.1 Supported Class Services

The supported **Class Services** of the Assembly Object are:

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.3.2 Class Attributes

##### 04-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0002h.

Default = 0002h

##### 04-02 Max Instance

[UINT, Get, NV]

The largest instance number of a created object in this class.

Default = 0096h

#### 8.12.3.3 Supported Instance Services

The supported **Instance Services** of the Assembly Object are:

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.3.4 Supported connection types

Lika EtherNet/IP encoders support "Input only" and "Listen Only" connections.

##### Input Only connection

This type of connection is used to read data from the encoder without controlling the outputs. It does not depend on other connections.

Connection point O → T      Assembly Object, instance 64h

Connection point T → O      Assembly Object, instances 01h, 02h, 03h



T is the Target, i.e. the encoder  
O is the Origin, i.e. the Master

### Listen Only connection

This type of connection requires an Input Only connection in order to exist. If the Input Only connection is closed, the Listen Only connection will be closed as well.

Connection point O → T      Assembly Object, instance 65h  
Connection point T → O      Assembly Object, instances 01h, 02h, 03h  
T is the Target, i.e. the encoder  
O is the Origin, i.e. the Master

Refer also to the "8.12.4 Class 06h: Connection Manager Object" section on page 96.

### 8.12.3.5 Instance Attributes

The following table identifies the I/O Assembly instances, which are supported by the encoder device.

Instance ID	Attribute	Access	Description	Bits	Bytes
01h	03h	Get	23-01-03 Position value	32	4
02h	03h	Get	23-01-03 Position value & 23-01-31 Warning Flag & 23-01-2E Alarm Flag	32 8	5
03h	03h	Get	23-01-03 Position value & 23-01-18 Velocity Value	32 32	8
6Ah	03h	Set/Get	Configuration Assembly	96	12

23-01-03 Position value, 23-01-18 Velocity Value, 23-01-31 Warning Flag, 23-01-2E Alarm Flag, 23-01-0C Direction Counting Toggle, 23-01-0E Scaling Function Control, 23-01-10 Measuring Units per Span, 23-01-11 Total Measuring Range, and 23-01-19 Velocity Format attributes are fully described in the "8.12.5 Class 23h: Position Sensor Object" section on page 97.

### 8.12.3.6 I/O Assembly Data Attribute Format

The I/O assembly data attributes have the format shown below.

Instance	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
01h	0	(low byte)							
	1	23-01-03 Position value							
	2								
	3	(high byte)							
02h	0	(low byte)							
	1	23-01-03 Position value							
	2								
	3	(high byte)							
	4							23-01-31 Warning Flag	23-01-2E Alarm Flag
03h	0	(low byte)							
	1	23-01-03 Position value							
	2								
	3	(high byte)							
	4	(low byte)							
	5	23-01-18 Velocity Value							
	6								
	7	(high byte)							

### 8.12.3.7 Configuration Assembly

Instance	Byte	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Attribute ID
6Ah	0	23-01-0C Direction Counting Toggle								0Ch
	1	23-01-0E Scaling Function Control								0Eh
	2	23-01-10 Measuring Units per Span								10h
	3									
	4									
	5	(high byte)								
	6	(low byte)								11h
	7	23-01-11 Total Measuring Range								
	8									

	9		(high byte)	
	10	<b>23-01-19 Velocity Format</b>	(low byte)	19h
	11		(high byte)	

#### 8.12.4 Class 06h: Connection Manager Object

Class Code	Object Class	Access	Nr. of Instances
06h	Connection Manager Object	Get	1

The Connection Manager Class allocates and manages the internal resources associated to both "I/O Messages" and "Explicit Messaging Connections".

For complete information refer to "THE CIP NETWORKS LIBRARY, Volume 1, Common Industrial Protocol (CIP™), Chapter 3: Communication Object Classes".

### 8.12.5 Class 23h: Position Sensor Object

Class Code	Object Class	Access	Nr. of Instances
23h	Position Sensor Object	Set/Get	1

The Position Sensor Object is meant to describe the attributes used by the device to calculate the transmitted position values. It contains all attributes for acyclic process data and for setting the encoder.

#### 8.12.5.1 Supported Class Services

The supported **Class Services** of the Position Sensor Object are:

05h = Reset: resets all parameter values to the factory default values and saves them on flash memory. The following types of reset are defined:

0 = Power Cycle Reset It emulates a power cycling of the encoder.

1 = Return to Factory Defaults Reset It returns to the factory default configuration of the encoder parameters and communication link parameters and emulates a power cycling of the encoder.



#### NOTE

After executing a Return to Factory Defaults reset (type 1), the encoder restarts using the IP address saved internally.

0Eh = Get\_Attribute\_Single: used to read connection class attribute value.

15h = Restore: restores all parameter values from flash memory and saves them.

16h = Save: saves all parameters to non-volatile memory.

#### 8.12.5.2 Class Attributes

##### 23-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0002h.

Default = 0002h

#### 8.12.5.3 Supported Instance Services

The supported **Instance Services** of the Position Sensor Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

10h = Set\_Attribute\_Single: used to write connection class attribute value.

#### 8.12.5.4 Instance Attributes

##### 23-01-03 Position value

[UDINT, Get, V]

This attribute represents the absolute position detected by the encoder conditioned by the scaling value attributes (see on page 98).

##### 23-01-0B Position Sensor type

[UINT, Get, NV]

This attribute specifies the type of device.

0001h: **XAC77-18-00-... singleturn** absolute rotary encoder;

0002h: **XAC77-16-14-... multiturn** absolute rotary encoder.

Default = 0001h (min. value 0001h, max. value 0001h) for singleturn encoders

Default = 0002h (min. value 0002h, max. value 0002h) for multiturn encoders

##### 23-01-0C Direction Counting Toggle

[BOOL, Set, NV]

This attribute defines whether the position value output by the encoder increases (count up information) when the encoder shaft rotates clockwise (0 = CW) or counter-clockwise (1 = CCW). If the attribute is set to 0, the absolute position value **increases** when the encoder shaft rotates **clockwise**; on the contrary, if the attribute is set to 1, the absolute position value **increases** when the encoder shaft rotates **counter-clockwise**. CW and CCW rotations are viewed from shaft end.

00: turning the shaft CW the position will increase;

01: turning the shaft CCW the position will increase.



#### WARNING

Changing this value causes also the position calculated by the encoder to be necessarily affected. Therefore it is mandatory to execute a new preset and save the attributes after setting this attribute.



#### NOTE

To know whether the counting is currently increasing or decreasing (in real time), you can read the bit 0 **Counting direction** of the **23-01-29 Operating Status** attribute, see on page 105.

Default = 00h (min. value 00h, max. value 01h)

##### 23-01-0E Scaling Function Control

[BOOL, Set, NV]

If this attribute is disabled (00 = OFF), the device uses the physical resolution (see the **23-01-2A Physical Resolution Span** and **23-01-2B Number of Spans** attributes) to arrange the absolute position value; if it is enabled (01 =

ON, default), the device uses the custom resolution set next to the **23-01-10 Measuring Units per Span** and **23-01-11 Total Measuring Range** attributes in compliance with the following relation:

Transmitted position =

$$\frac{\text{23-01-10 Measuring Units per Span}}{\text{23-01-2A Physical Resolution Span}} * \text{real position} \leq \text{23-01-11 Total Measuring Range}$$



#### NOTE

To know whether the **23-01-0E Scaling Function Control** is currently enabled, you can read the bit 1 **Scaling function** of the **23-01-29 Operating Status** attribute, see on page 105.



#### WARNING

Every time you enable the scaling function and/or change the scaling values (see the **23-01-10 Measuring Units per Span** and **23-01-11 Total Measuring Range** attributes), then you are required to set a new preset value (see the **23-01-13 Preset Value** attribute) and finally save the new parameters (by means of the Class Service 16h, see on page 97; or by setting the bit 6 **Save Parameters** in the **23-01-68 Command Register** attribute to 1, see on page 112).

Default = 01h (min. value 00h, max. value 01h)

### 23-01-10 Measuring Units per Span

[UDINT, Set, NV]



#### WARNING

This attribute is active only if the **23-01-0E Scaling Function Control** attribute is enabled; otherwise it is ignored and the system uses the physical values (**23-01-2A Physical Resolution Span** and **23-01-2B Number of Spans**) to calculate the position information.

This attribute sets the custom number of measuring steps per revolution (cpr) that are output for the absolute singleturn position value.

If you enter an out-of-range value, the number of measuring units per revolution is forced to the physical singleturn resolution and the **23-01-2F Warnings** attribute signals the error (see the bit 0 **Measuring Units per Span exceeded** in the **23-01-67 Wrong Parameters List**).

To avoid counting errors, check that:

$$\frac{\text{23-01-2A Physical Resolution Span}}{\text{23-01-10 Measuring Units per Span}} = \text{integer value.}$$

Allowed values must be less than or equal to the physical singleturn resolution (**23-01-2A Physical Resolution Span**).

Default = 262,144 (min. = 1, max. = 262,144) for XAC77-18-00-...  
65,536 (min. = 1, max. = 65,536) for XAC77-16-14-...



### WARNING

When you set a new value next to the **23-01-10 Measuring Units per Span** attribute, please always check also the **23-01-11 Total Measuring Range** attribute value and be sure that the resulting number of revolutions complies with the physical number of revolutions of the device (see the **23-01-2B Number of Spans** attribute).

Let's suppose that the XAC77-16-14-EP2-... encoder is programmed as follows:

**23-01-10 Measuring Units per Span**: 8,192

**23-01-11 Total Measuring Range** = 33,554,432 = 8,192 (cpr) \* 4,096 (rev.)

Let's set a new singleturn resolution, for instance: **23-01-10 Measuring Units per Span** = 360.

If we do not change the **23-01-11 Total Measuring Range** value at the same time, we will get the following result:

$$\text{Number of revolutions} = \frac{33,554,432 \text{ (23-01-11 Total Measuring Range)}}{360 \text{ (23-01-10 Measuring Units per Span)}} = 93,206.755...$$

As you can see, the encoder is required to carry out more than 93,000 revolutions, this cannot be as the hardware number of revolutions is, as stated, 16,384 (see the **23-01-2B Number of Spans** attribute). When this happens, the **23-01-2F Warnings** attribute signals the error (see also the **23-01-67 Wrong Parameters List** attribute).



### WARNING

Every time you change the value in this attribute, then you are required to set a new preset value (see the **23-01-13 Preset Value** attribute) and finally save the new parameters (by means of the Class Service 16h, see on page 97; or by setting the bit 6 **Save Parameters** in the **23-01-68 Command Register** attribute to 1, see on page 112).



**23-01-11 Total Measuring Range**

[UDINT, Set, NV]

**WARNING**

This attribute is active only if the **23-01-0E Scaling Function Control** attribute is enabled; otherwise it is ignored and the system uses the physical values (**23-01-2A Physical Resolution Span** and **23-01-2B Number of Spans**) to calculate the position information.

This attribute sets a custom number of distinguishable steps over the total measuring range. The total resolution of the encoder results from the product of **23-01-10 Measuring Units per Span** by the required **Number of revolutions**. Allowed values are less than or equal to **23-01-2A Physical Resolution Span** \* **23-01-2B Number of Spans**.

Default = 262,144 (min. = 1, max. = 262,144) for XAC77-18-00-...  
singleturn encoder  
1,073,741,824 (min. = 1, max. = 1,073,741,824) for XAC77-16-14-...  
multiturn encoder

**WARNING**

When you set a new value next to the **23-01-11 Total Measuring Range** attribute, please always check also the **23-01-10 Measuring Units per Span** attribute value and be sure that the resulting number of revolutions complies with the physical **23-01-2B Number of Spans** of the device.

Let's suppose that the XAC77-16-14-EP2-... encoder is programmed as follows:

**23-01-10 Measuring Units per Span**: 8,192

**23-01-11 Total Measuring Range** = 33,554,432 = 8,192 (cpr) \* 4,096 (rev.)

Let's set a new total resolution, for instance: **23-01-11 Total Measuring Range** = 360.

As the **23-01-11 Total Measuring Range** must be greater than or equal to the **23-01-10 Measuring Units per Span**, the above setting is not allowed. When this happens, the **23-01-2F Warnings** attribute signals the error (see also the **23-01-67 Wrong Parameters List** attribute).

**WARNING**

Every time you change the value in this attribute, then you are required to set a new preset value (see the **23-01-13 Preset Value** attribute) and finally save the new parameters (by means of the Class Service 16h, see on page 97; or by setting the bit 6 **Save Parameters** in the **23-01-68 Command Register** attribute to 1, see on page 112).



### EXAMPLE

We install the XAC77-**16-14**-EP2-... multiturn encoder.

Its physical resolution is as follows (see the order code):

- Hardware counts per revolution: **23-01-2A Physical Resolution Span** = 65,536 ( $2^{16}$ )
- Hardware number of revolutions: **23-01-2B Number of Spans** = 16,384 ( $2^{14}$ )
- Total hardware resolution: **23-01-2A Physical Resolution Span** \* **23-01-2B Number of Spans** = 1,073,741,824 ( $2^{30}$ )

In the specific installation 2,048 counts/rev. \* 1,024 turns are required:

- Enable the scaling function: **23-01-0E Scaling Function Control** attribute = "1"
- Counts per revolution: **23-01-10 Measuring Units per Span** = 2,048 (0000 0800h)
- Total resolution: **23-01-11 Total Measuring Range** = 2,048 \* 1,024 = 2,097,152 (0020 0000h)



### NOTE

We suggest setting values which are power of 2 ( $2^n$ : 2, 4, ..., 2048, 4096, 8192,...) to be set in the **23-01-10 Measuring Units per Span** and **23-01-11 Total Measuring Range** attributes to avoid counting errors.



### WARNING

If **23-01-10 Measuring Units per Span** and/or **23-01-11 Total Measuring Range** values change, the **23-01-13 Preset Value** must be updated in accordance with the new resolution. A new preset operation is required.

### 23-01-13 Preset Value

[UDINT, Set, NV]

This attribute allows to set the encoder position to a Preset value. The Preset function is meant to assign a desired value to a physical position of the encoder shaft. The chosen position will get the value set next to this object and all the previous and the following positions will get a value according to it. This function is useful, for example, when the zero position of the encoder and the zero position of the axis need to match. The preset value will be set and activated for the position of the encoder in the moment when the preset value is transmitted. We suggest setting the preset value when the encoder is in stop. The preset value is activated as soon as the value is set.

If you need to activate a value already set next to the **23-01-13 Preset Value** in a different physical position of the encoder shaft, you can use the bit 0

Activate Preset in the **23-01-68 Command Register** attribute, see on page 111.

Default = 0 (min. = 0, max. = 262,143 \*) for XAC77-18-00-...  
 0 (min. = 0, max. = 1,073,741,823 \*) for XAC77-16-14-...

\* See the NOTE below.



#### EXAMPLE

Let's take a look at the following example to better understand the preset function and the meaning and use of the related objects: **23-01-13 Preset Value** and **23-01-33 Offset Value**.

The encoder position which is transmitted results from the following calculation:

**Transmitted value** = **read position** (it does not matter whether the position is physical or scaled) + **23-01-13 Preset Value** - **23-01-33 Offset Value**.

If you never set the **23-01-13 Preset Value** or performed the preset setting, then the transmitted value and the read position are necessarily the same as **23-01-13 Preset Value** = 0 and **23-01-33 Offset Value** = 0.

When you set the **23-01-13 Preset Value** or execute the preset setting, the system saves the current encoder position in the **23-01-33 Offset Value** attribute. It follows that the transmitted value and the **23-01-13 Preset Value** are the same as **read position** - **23-01-33 Offset Value** = 0; in other words, the value set next to the **23-01-13 Preset Value** attribute is paired with the current position of the encoder as you wish.

For example, let's assume that the value "50" is set next to the **23-01-13 Preset Value** attribute when the encoder position is "1000". In other words, you want to receive the value "50" when the encoder reaches the position "1000".

We will obtain the following information sequence:

**Transmitted value** = **read position** (= "1000") + **23-01-13 Preset Value** (= "50") - **23-01-33 Offset Value** (= "1000") = 50.

The following transmitted value will be:

**Transmitted value** = **read position** (= "1001") + **23-01-13 Preset Value** (= "50") - **23-01-33 Offset Value** (= "1000") = 51.

And so on.



#### NOTE

- If the scaling function is disabled (**23-01-0E Scaling Function Control** attribute = 0), then the **23-01-13 Preset Value** must be less than or equal to the "Total hardware resolution" - 1, i.e. (**23-01-2A Physical Resolution Span** \* **23-01-2B Number of Spans**) - 1.
- If the scaling function is enabled (**23-01-0E Scaling Function Control** attribute = 1), then the **23-01-13 Preset Value** must be lower than or equal to the **23-01-11 Total Measuring Range** - 1.


**WARNING**

Check the value in the **23-01-13 Preset Value** attribute and perform the preset operation every time you set a new **23-01-0C Direction Counting Toggle** or change the scaled values (**23-01-10 Measuring Units per Span** and/or **23-01-11 Total Measuring Range**).

**23-01-18 Velocity Value**

[DINT, Get, V]

This attribute shows the current output speed value detected by the position encoder and calculated every 100 ms.

The value can be expressed in several engineering units according to the setting next the following **23-01-19 Velocity Format** attribute. As a default the velocity value is expressed in counts per second (cps).

**23-01-19 Velocity Format**

[UINT, Set, NV]

This attribute defines the engineering unit for the velocity value (see the previous **23-01-18 Velocity Value** attribute).

- 1F04 = counts per second: number of steps per second; the minimum resolution is 10 cps (default);
- 1F05 = counts per millisecond: number of steps per millisecond; the minimum resolution is 1 cpms;
- 1F07 = counts per minute: number of steps per minute; the minimum resolution is 600 cpm;
- 1F0E = revolutions per second: number of revolutions per second; the minimum resolution is 1 rps;
- 1F0F = revolutions per minute: number of revolutions per minute; the minimum resolution is 1 rpm;
- 1F10 = revolutions per hour: number of revolutions per hour; the minimum resolution is 4 rph;

Default = 1F04h (min. = 1F04h, max. = 1F10h)

## 23-01-29 Operating Status

[BYTE, Get, V]

This attribute contains the operating status of the encoder according to definitions in the following table.

Bit	Function	bit = 0	bit = 1
0	Counting direction	Increasing counting	Decreasing counting
1	Scaling function	Disabled	Enabled
2 ... 7	not used		

### Counting direction

It shows whether the counting is currently increasing or decreasing (in real time). If the bit is "0" the counting is currently increasing; if the bit is "1" the counting is decreasing. Increasing / decreasing status depends on the rotation of the shaft and the code sequence set either to CW or CCW, see the [23-01-0C Direction Counting Toggle](#) attribute to 0 / 1 on page 98.

### Scaling function

It shows whether the scaling function is disabled or enabled. If the value is "0" the scaling function is disabled (i.e. the system uses the resolution physical values -[23-01-2A Physical Resolution Span](#) and [23-01-2B Number of Spans](#)- to calculate the position information); if the value is "1" the scaling function is enabled (i.e. the system uses the custom values -[23-01-10 Measuring Units per Span](#) and [23-01-11 Total Measuring Range](#)- to calculate the position information). To disable / enable the scaling function you must set the [23-01-0E Scaling Function Control](#) attribute to 0 / 1, see on page 98.

## 23-01-2A Physical Resolution Span

[UDINT, Get, NV]



### WARNING

This attribute is active only if the [23-01-0E Scaling Function Control](#) attribute is set to "0"; otherwise it is ignored and the system uses the custom values ([23-01-10 Measuring Units per Span](#) and [23-01-11 Total Measuring Range](#)) to calculate the position information.

This attribute is intended to show the number of physical distinguishable steps each turn provided by the hardware (physical singleturn resolution).

If you want to set a custom resolution see the [23-01-10 Measuring Units per Span](#) attribute.

Default = 262,144      for XAC77-18-00-... singleturn encoder  
                  65,536      for XAC77-16-14-... multiturn encoder

## 23-01-2B Number of Spans

[UINT, Get, NV]



### WARNING

This attribute is active only if the **23-01-0E Scaling Function Control** attribute is set to "0"; otherwise it is ignored and the system uses the custom values (**23-01-10 Measuring Units per Span** and **23-01-11 Total Measuring Range**) to calculate the position information.

This attribute is intended to show the number of physical distinguishable turns provided by the hardware (number of physical revolutions).

The **Total hardware resolution** results from **23-01-2A Physical Resolution Span** \* **23-01-2B Number of Spans**.

If you want to set a custom number of turns see the **23-01-10 Measuring Units per Span** and **23-01-11 Total Measuring Range** attributes.

Default = 1 for XAC77-18-00-... singleturn encoder  
16,384 for XAC77-16-14-... multiturn encoder

## 23-01-2C Alarms

[UINT, Get, V]

An alarm indicates that a malfunction has occurred which could lead to an incorrect position value. It is set when a bit indicating a fault is set to true (high). The alarm remains active until the alarm is cleared and the device is able to provide an accurate position value. When an alarm is active, also the **23-01-2E Alarm Flag** attribute is set to 1. The attribute is defined according to the following table.

Refer also to the following **23-01-2D Supported Alarms** attribute.

Bit	Function	bit = 0	bit = 1
0	not used		
1	<b>Diagnostic error</b>	Alarm not active	Alarm active
2 ... 11	not used		
12	<b>Flash memory error</b>	Alarm not active	Alarm active
13 ... 15	not used		

### Diagnostic error

It warns about an error that is specified in the Vendor Specific bits 12 ... 15. Only **Flash memory error** alarm is available.

### Flash memory error

Internal error, it cannot be restored. The flash memory contains corrupted data; or maybe the flash memory is damaged.

### 23-01-2D Supported Alarms

[WORD, Get, NV]

This attribute contains information on the supported alarms. Refer to the previous [23-01-2C Alarms](#) attribute.

Bit	Function	bit = 0	bit = 1
0	not used		
1	<b>Diagnostic error</b>	Not supported	Supported
2 ... 11	not used		
12	<b>Flash memory error</b>	Not supported	Supported
13 ... 15	not used		

Default = 1002h (= 0001 0000 0000 0010 = alarms at bits 1 and 12 of the previous [23-01-2C Alarms](#) attribute are supported).

### 23-01-2E Alarm Flag

[BOOL, Get, V]

It indicates (1) that a fault occurred and an alarm has been triggered, see the defined alarms in the previous [23-01-2C Alarms](#) attribute.

### 23-01-2F Warnings

[UINT, Get, V]

The [23-01-2F Warnings](#) attribute indicates that tolerances for certain internal parameters of the encoder have been exceeded. It does not imply incorrect position values. The warning is cleared if the tolerances are again within normal parameters. When a warning is active, also the [23-01-31 Warning Flag](#) attribute is set to 1. The attribute is defined according to the following table.

Refer also to the following [23-01-30 Supported Warnings](#) attribute.

Bit	Function	bit = 0	bit = 1
0 ... 12	not used		
13	<b>Parameters Error</b>	Warning not active	Warning active
14 and 15	not used		

#### **Parameters Error**

An out-of-tolerance parameter has been set. For more details about the specific out-of-tolerance parameter refer to the [23-01-67 Wrong Parameters List](#) attribute, see on page 110.

### 23-01-30 Supported Warnings

[WORD, Get, NV]

This attribute contains information on the supported warnings. Refer to the previous [23-01-2F Warnings](#) attribute.

Bit	Function	bit = 0	bit = 1
0 ... 12		not used	
13	<b>Parameters Error</b>	Not supported	Supported
14 and 15		not used	

Default = 2000h (= 0010 0000 0000 0000 = warning at bit 13 of the previous [23-01-2F Warnings](#) attribute is supported).

### 23-01-31 Warning Flag

[BOOL, Get, V]

The attribute indicates whether any of the defined warnings are active (1) or not (0).

### 23-01-32 Operating Time

[UDINT, Get, NV]

This attribute contains the information on the operating time and is incremented as long as the encoder is powered. It is expressed in tenths of an hour. This attribute is not used currently.

### 23-01-33 Offset Value

[DINT, Get, NV]

The [23-01-33 Offset Value](#) attribute is calculated by the preset function and shifts the [23-01-03 Position value](#) attribute with the calculated value. It is stored automatically by the device and can be read from the encoder for diagnostic purposes. To zero set the value in this attribute you must upload the factory default values (see the Class Service 15h on page 97 and the **Restore Parameters to Defaults** bit option in the [23-01-68 Command Register](#) attribute).



### 23-01-64 Application-DSC FW Version

[UDINT, Get, NV]

This attribute contains the firmware version of the Application DSC (Digital Signal Controller).

The meaning of the 32 bits in the attribute is as follows:

Bit	31 ... 16	15 ... 0
	Major version	Minor version



For example, the value 0001 0001 hex in hexadecimal notation corresponds to the binary representation 0000 0000 0000 0001 0000 0000 0000 0001 and has to be interpreted as: firmware version 1.1.

Default = Device dependent

### 23-01-65 Hardware Version

[UDINT, Get, NV]

This attribute contains the hardware version of electronics.

The meaning of the 32 bits in the attribute is as follows:

Bit	31 ... 16	15 ... 0
	Major version	Minor version



For example, the value 0002 0001 hex in hexadecimal notation corresponds to the binary representation 0000 0000 0000 0002 0000 0000 0000 0001 and has to be interpreted as: hardware version 2.1.

Default = Device dependent

### 23-01-66 Network-DSC FW Version

[UDINT, Get, NV]

This attribute contains the firmware version of the Network DSC (Digital Signal Controller).

The meaning of the 32 bits in the attribute is as follows:

Bit	31 ... 24	23 ... 16	15 ... 8	7 ... 0
	0	Major version	Minor version	Build number



For example, the value 0001 0001 hex in hexadecimal notation corresponds to the binary representation 0000 0000 0000 0001 0000 0000 0000 0001 and has to be interpreted as: firmware version 1.0.1.

Default = Device dependent

### 23-01-67 Wrong Parameters List

[UINT, Get, NV]

The operator has entered invalid data and the **Parameters Error** warning in the **23-01-2F Warnings** attribute has been triggered. This variable is meant to show (bit value = HIGH) the list of the wrong parameters, according to the following table.

Please note that the normal work status can be restored only after having set proper values.

Bit	Function	bit = 0	bit = 1
0	<b>Measuring Units per Span exceeded</b>	Warning not active	Warning active
1	<b>Total Measuring Range exceeded</b>	Warning not active	Warning active
2	<b>Preset Value exceeded</b>	Warning not active	Warning active
3	<b>Offset Value exceeded</b>	Warning not active	Warning active
4 ... 15	not used		

#### Byte 0

##### **Measuring Units per Span exceeded**

bit 0

Wrong data has been set next to the **23-01-10 Measuring Units per Span** attribute. The tolerances for the parameter have been exceeded. Set proper values to restore the normal work condition. The warning is cleared if the tolerances are again within normal parameters.

##### **Total Measuring Range exceeded**

bit 1

Wrong data has been set next to the **23-01-11 Total Measuring Range** attribute. The tolerances for the parameter have been exceeded. Set proper values to restore the normal work condition. The warning is cleared if the tolerances are again within normal parameters.

##### **Preset Value exceeded**

bit 2

Wrong data has been set next to the **23-01-13 Preset Value** attribute. The tolerances for the parameter have been exceeded. Set proper values to restore the normal work condition. The warning is cleared if the tolerances are again within normal parameters.

##### **Offset Value exceeded**

bit 3

Wrong data has been set next to the **23-01-13 Preset Value** attribute and the calculated **23-01-33 Offset Value** is out-of-tolerance. The tolerances for the parameter have

been exceeded. Set proper values to restore the normal work condition. The warning is cleared if the tolerances are again within normal parameters.

bits 4 ... 7 Not used

Byte 1 Not used

### 23-01-68 Command Register

[BYTE, Set, V]

This attribute contains some commands to be sent in real time to the encoder in order to manage it.

Bit	Function	bit = 1	bit = 0
0	Activate Preset	Activate	Finalize
1 ... 5	not used		
6	Save Parameters	Activate	Finalize
7	Restore Parameters to Defaults	Activate	Finalize

#### Byte 0

##### Activate Preset

bit 0

This command is used to activate a preset value in the encoder. As soon as the command is sent, the position value which is transmitted for the current encoder position is the one set next to the **23-01-13 Preset Value** attribute and all the previous and following positions will get a value according to it. The operation is performed at each rising edge of the bit, i.e. each time this bit is switched from logic level low ("0") to logic level high ("1"). Then the bit must be switched back to logic level low ("0") to finalize the command. When the command is sent, the current encoder position is saved temporarily in the **23-01-33 Offset Value** attribute. For any further information on the preset function and the meaning and use of the related attributes and commands **23-01-13 Preset Value**, **23-01-33 Offset Value** and **Activate Preset** refer to page 102.



#### NOTE

Please note that as soon as the preset value is entered next to the **23-01-13 Preset Value** attribute, it is also automatically activated, so you do not need to use this command. Use the **Activate Preset** command to activate a preset value that has been already set next to the **23-01-**

**13 Preset Value** attribute and you want to set it for a different shaft position.



#### WARNING

To save permanently the current encoder position in the **23-01-33 Offset Value** attribute, please execute the **Save Parameters** command. Should the power supply be turned off without saving data, the **23-01-33 Offset Value** that has not been saved will be lost!

bits 1 ... 5

Not used

#### Save Parameters

bit 6

This function allows to save all parameters on the non-volatile memory. Data is saved on the non-volatile memory at each rising edge of the bit; in other words, data save is performed each time this bit is switched from logic level low ("0") to logic level high ("1"). Then the bit must be switched back to logic level low ("0") to finalize the command.



#### NOTE

Always save the new values after setting in order to store them in the non-volatile memory permanently. Should the power supply be turned off all data that has not been saved previously will be lost!



#### NOTE

To save the new values on the non-volatile memory permanently you can use also the Class Service 16h, see on page 97.

#### Restore Parameters to Defaults

bit 7

This function allows the operator to restore all parameters to default values (default values are set at the factory by Lika Electronic engineers to allow the operator to run the device for standard operation in a safe mode). This function can be useful, for instance, to restore the factory values in case the encoder is set incorrectly and you are not able to resume the proper operation.

Default parameters are restored at each rising edge of the bit; in other words, the default parameters uploading operation is performed each time this bit is switched from logic level low ("0") to logic level high ("1"). Then the bit must be switched back to logic level low ("0") to finalize the command. The complete list of machine data and relevant

default parameters preset by Lika Electronic engineers is available on page 153.



### WARNING

The execution of this command causes all parameters which have been set previously to be overwritten!

## 23-01-69 Warning/Alarm Flags

[BYTE, Get, NV]

This attribute is used in conjunction with the I/O assembly data attributes, refer to the "8.12.3.6 I/O Assembly Data Attribute Format" section on page 94.

Its value is **00h** (0000 0000<sub>2</sub>) when neither warnings nor alarms are active.

Its value is **01h** (0000 0001<sub>2</sub>) when alarms are active.

Its value is **02h** (0000 0010<sub>2</sub>) when warnings are active.

Its value is **03h** (0000 0011<sub>2</sub>) when both warnings and alarms are active.

See the byte 4 of Instance 02h on page 94.

## 23-01-6A Encoder Serial Number

[UDINT, Get, NV]

This attribute contains the serial number of the encoder assigned by the manufacturer. This is not the same as the Identity Object's serial number (see **01-01-06 Serial number** attribute on page 90) which is used to uniquely identify the device in the network environment. It can be read in the label applied to the device enclosure.

The meaning of the 32 bits in the attribute is as follows:

Bit	31 ... 24	23 ... 16	15 ... 0
	YoP	WoP	Serial number

YoP: year of production.

Wop: week of production.

Serial number: serial number in ascending order.

Default = Device dependent

**23-01-6C Network-DSC Serial Number**

[UDINT, Get, NV]

This attribute contains the serial number of the Network DSC (Digital Signal Controller).

Default = Device dependent

### 8.12.6 Class F5h: TCP/IP Interface Object

Class Code	Object Class	Access	Nr. of Instances
F5h	TCP/IP Interface Object	Get	1

The TCP/IP Interface Object provides the mechanism to configure the TCP/IP network interface of a device. Examples of configurable items include the device's IP Address, Network Mask, and Gateway Address.

For complete information on TCP/IP Interface Object attributes refer to the publication "The CIP Networks Library. Volume 2. EtherNet/IP Adaptation of CIP".

#### 8.12.6.1 Supported Class Services

The supported **Class Services** of the TCP/IP Interface Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.6.2 Class Attributes

##### F5-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0004h.

Default = 0004h

##### F5-02 Max Instance

[UINT, Get, NV]

The largest instance number of a created object in this class.

Default = 0001h

##### F5-03 Number of Instances

[UINT, Get, NV]

The number of object instances in this class.

Default = 0001h

#### 8.12.6.3 Supported Instance Services

The supported **Instance Services** of the TCP/IP Interface Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

10h = Set\_Attribute\_Single: used to write connection class attribute value.

#### 8.12.6.4 Instance Attributes

##### F5-01-01 Status

[DWORD, Get, V]

This attribute represents the current status of the interface. Its value changes as the state of the interface changes. The Status attribute is a DWORD, with the following bit definitions:

Bit(s)	Called	Definition
0 ... 3	<b>Interface Configuration Status</b>	It indicates the status of the <b>F5-01-05 Interface Configuration</b> attribute. 0 = the <b>F5-01-05 Interface Configuration</b> attribute has not been configured. 1 = the <b>F5-01-05 Interface Configuration</b> attribute contains configuration obtained from DHCP or non-volatile storage. 2 = the <b>F5-01-05 Interface Configuration</b> attribute contains configuration from hardware settings. 3 ... 15 = reserved for future use
4	<b>Mcast Pending</b>	If set to 1 it indicates a multicast pending configuration.
5	<b>Interface Configuration Pending</b>	If set to 1 it indicates an interface pending configuration. A new configuration will be loaded at next reset.
6	<b>AcdStatus</b>	It indicates when an IP address conflict has been detected by ACD. To enable/disable the ACD refer to <b>F5-01-0A SelectAcd</b> attribute on page 118.
7	<b>AcdFault</b>	It indicates when an IP address conflict has been detected by ACD or the defense failed, and that the current Interface Configuration cannot be used due to this conflict.
8 ... 31	Reserved	Reserved, shall be 0

##### F5-01-02 Configuration Capability

[DWORD, Get, NV]

It indicates the method of obtaining an initial IP address.

Bit(s)	Called	Definition
0 1 2 3	<b>BOOTP Client</b> <b>DNS Client</b> <b>DHCP Client</b> <b>DHCP-DNS Update</b>	It is set to 4 (0010 <sub>2</sub> ): the encoder is able of obtaining its network configuration via DHCP.
4	<b>Configuration Settable</b>	If set to 1, it indicates that the <b>F5-01-05 Interface Configuration</b> attribute is



		settable.
5	<b>Hardware Configurable</b>	The encoder is hardware configurable when the bit is set to 1.
6	<b>Reset Required at change</b>	It is always set to 0.
7	<b>AcdCapable</b>	If set to 1, the encoder is capable of detecting address conflicts (ACD capable). See the <b>F5-01-0A SelectAcd</b> attribute on page 118.
8 ... 31	Reserved	Reserved, shall be 0

### F5-01-03 Configuration Control

[DWORD, Get/Set, NV]

It is used to control network configuration options.

When its value is **0**, the device shall use statically-assigned IP configuration values from non-volatile memory.

When its value is **2**, the device shall obtain the interface configuration values from DHCP.

### F5-01-04 Physical Link Object

[Struct of, Get, NV]

This attribute identifies the object associated with the underlying physical communications interface.

#### Path size

[UINT] Size of path (0002h).

#### Path

[Padded EPATH] Path to Ethernet Link Object, **F6-01-03 Physical Address** instance, see on page 121 (20 F6 24 03h).

### F5-01-05 Interface Configuration

[Struct of, Get/Set, V/NV]

#### IP Address

[UDINT] The device's IP address (192.168.1.10).

#### Network Mask

[UDINT] The device's network mask (255.255.255.0).

#### Gateway Address

[UDINT] The IP address of the device's default gateway (0.0.0.0).

#### Name Server

[UDINT] Primary DNS.

#### Name Server 2

[UDINT] Secondary DNS.

### Domain Name

[STRING] The default domain name.

### F5-01-06 Host Name

[STRING, Get/Set, NV]

It contains the device's host name, which can be used for informational purposes.

### F5-01-08 TTL Value

[USINT, Get/Set, NV]

The device shall use the TTL value for the IP header Time-to-live field when sending EtherNet/IP packets via IP multicast.

Default = 1

### F5-01-09 Mcast Config

[Struct of, Set, NV]

It contains the configuration of the device's IP multicast addresses to be used for EtherNet/IP multicast packets.

### Alloc Control

[USINT] 0 = multicast addresses shall use be generated using the default allocation algorithm according to specifications. 1 = multicast addresses shall be allocated according to the values specified in **Num Mcast** and **Mcast Start Addr** parameters.

### (reserved)

[USINT] set to 0, do not change.

### Num Mcast

[UINT] Number of IP multicast addresses allocated (1).

### Mcast Start Addr

[UDINT] Starting multicast address from which **Num Mcast** addresses are allocated.

### F5-01-0A SelectAcd

[BOOL, Set, NV]

It allows to enable / disable the Address Conflict Detection (ACD). If ACD is enabled, as soon as an address conflict is detected, the bit 6 **AcdStatus** in the **F5-01-01 Status** attribute will be set to 1.

0 = Disable ACD

1 = Enable ACD

Default = 1

#### **F5-01-0B LastConflictDetected**

[Struct of, Set, NV]

It is a diagnostic attribute presenting information about the ACD state when the last IP address conflict was detected.

##### **AcdActivity**

[USINT] State of the ACD algorithm when the last IP address conflict was detected.

##### **RemoteMAC**

[Array of 6 USINTs] The IEEE 802.3 source MAC address from the header of the received Ethernet packet sent by the device when reporting the conflict.

##### **ArpPDU**

[Array of 28 USINTs] The ARP Response PDU in binary format.

#### **F5-01-0C EtherNet/IP QuickConnect**

[BOOL, Set, NV]

It shall enable (1) or disable (0) the EtherNet/IP QuickConnect feature. If EtherNet/IP QuickConnect is enabled, it will direct EtherNet/IP target devices to quickly power up and join an EtherNet/IP network.

Default = 0

#### **F5-01-0D Encapsulation Inactivity Timeout**

[UINT, Set, NV]

Number of seconds with no Encapsulation activity before the TCP connection is closed. It is disabled (0).

Default = 0 (min. value 0, max. value 3600)

### 8.12.7 Class F6h: Ethernet Link Object

Class Code	Object Class	Access	Nr. of Instances
F6h	Ethernet Link Object	Get	1

The EtherNet Link Object maintains link-specific counters and status information for an IEEE 802.3 communications interface such as transmission speed, interface status, and the MAC address.

#### 8.12.7.1 Supported Class Services

The supported **Class Services** of the Ethernet Link Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.7.2 Class Attributes

##### F6-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0004h.

Default = 0004h

##### F6-02 Max Instance

[UINT, Get, NV]

The largest instance number of a created object in this class (1 or 3).

Default = 0003h

##### F6-03 Number of Instances

[UINT, Get, NV]

The number of object instances in this class (1 or 3).

Default = 0003h

#### 8.12.7.3 Supported Instance Services

The supported **Instance Services** of the Ethernet Link Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

10h = Set\_Attribute\_Single: used to write connection class attribute value.

4Ch = Get\_And\_Clear: used to get and then clear the specified attribute.

#### 8.12.7.4 Instance Attributes

##### F6-01-01 Interface Speed

[UDINT, Get, V]

Interface speed currently in use, expressed in Mbps (10 or 100).

##### F6-01-02 Interface Flags

[DWORD, Get, V]

Interface status flags, according to the following table.

Bit(s)	Called	Definition
0	<b>Link Status</b>	It indicates whether or not the IEEE 802.3 communications interface is connected to an active network. 0 indicates an inactive link; 1 indicates an active link.
1	<b>Half/Full Duplex</b>	It indicates the duplex mode currently in use. 0 indicates the interface is running half duplex; 1 indicates full duplex. If the <b>Link Status</b> flag is 0, then the value of the <b>Half/Full Duplex</b> flag is indeterminate.
2 ... 4	<b>Negotiation Status</b>	It indicates the status of link auto-negotiation. 0 = Auto-negotiation in progress 1 = Auto-negotiation and speed detection failed. Using default values. Recommended defaults are 10 Mbps and half duplex. 2 = Auto-negotiation failed but detected speed. Duplex was defaulted. 3 = Successfully negotiated speed and duplex. 4 = Auto-negotiation not attempted. Forced speed and duplex.
5	<b>Manual Setting Requires Reset</b>	It is 0 when the interface can activate changes to link parameters during runtime. It is 1 when reset is required in order for changes to take effect.
6	<b>Local Hardware Fault</b>	0 indicates the interface detects no local hardware fault; 1 indicates a local hardware fault is detected.
7 ... 31	Reserved	Reserved, shall be 0

##### F6-01-03 Physical Address

[Array of 6 UINTs, Get, NV]

MAC ID. This attribute contains the physical network address, i.e. the assigned MAC address.

### F6-01-04 Interface Counters

[Struct of, Get, V]

This attribute contains counters relevant to the receipt of packets on the interface.

#### **In Octets**

[UDINT] Octets received on the interface.

#### **In Ucast Packets**

[UDINT] Unicast packets received on the interface.

#### **In NUcast Packets**

[UDINT] Non-unicast packets received on the interface.

#### **In Discards**

[UDINT] Inbound packets received on the interface but discarded.

#### **In Errors**

[UDINT] Inbound packets that contain errors (does not include **In Discards**).

#### **In Unknown Protos**

[UDINT] Inbound packets with unknown protocol.

#### **Out Octets**

[UDINT] Octets sent on the interface.

#### **Out Ucast Packets**

[UDINT] Unicast packets sent on the interface.

#### **Out NUcast Packets**

[UDINT] Non-unicast packets sent on the interface.

#### **Out Discards**

[UDINT] Outbound packets discarded.

#### **Out Errors**

[UDINT] Outbound packets that contain errors (does not include **Out Discards**).

### F6-01-05 Media Counters

[Struct of, Get, V]

This attribute contains counters specific to Ethernet media.

#### **Alignment Errors**

[UDINT] Frames received that are not integral number of octets in length.

#### **FCS Errors**

[UDINT] Frames received that do not pass the FCS check.

### Single Collisions

[UDINT] Successfully transmitted frames which experienced exactly one collision.

### Multiple Collisions

[UDINT] Successfully transmitted frames which experienced more than one collision.

### SQE Test Errors

[UDINT] Number of times SQE test error message is generated.

### Deferred Transmissions

[UDINT] Frames for which first transmission attempt is delayed because the medium is busy.

### Late Collisions

[UDINT] Number of times a collision is detected later than 512 bit-times into the transmission of a packet.

### Excessive Collisions

[UDINT] Frames for which transmission fails due to excessive collisions.

### MAC Transmit Errors

[UDINT] Frames for which transmission fails due to an internal MAC sublayer transmit error.

### Carrier Sense Errors

[UDINT] Times that the carrier sense condition was lost or never asserted when attempting to transmit a frame.

### Frame Too Long

[UDINT] Frames received that exceed the maximum permitted frame size.

### MAC Receive Errors

[UDINT] Frames for which reception on an interface fails due to an internal MAC sublayer receive error.

## F6-01-06 Interface Control

[Struct of, Get/Set, NV]

This attribute is a structure consisting of the following parameters.

### Control Bits

[WORD] Interface control bits.

Bit(s)	Called	Definition
0	Auto-negotiate	0 indicates that 802.3 link auto-negotiation is disabled. 1 indicates that auto-negotiation is enabled. If auto-negotiation is disabled,

		then the device shall use the settings indicated by the Forced Duplex Mode and Forced Interface Speed bits.
1	<b>Forced Duplex Mode</b>	If the <b>Auto-negotiate</b> bit is 0, the <b>Forced Duplex Mode</b> bit indicates whether the interface shall operate in full or half duplex mode. 0 indicates that the interface duplex should be half duplex. 1 indicates that the interface duplex should be full duplex. Interfaces not supporting the requested duplex shall return status code 0x09 ( <b>Invalid Attribute Value</b> ). If auto-negotiation is enabled, attempting to set the <b>Forced Duplex Mode</b> bit shall result in status code 0x0C ( <b>Object State Conflict</b> ).
2 ... 15	Reserved	Reserved, shall be 0

### Forced Interface Speed

[UINT] If the **Auto-negotiate** bit is 0, the **Forced Interface Speed** bits indicate the speed at which the interface shall operate. Speed is specified in megabits per second (e.g., for 10 Mbps Ethernet, the Interface Speed shall be 10).

### F6-01-07 Interface Type

[USINT, Get, NV]

This attribute indicates the type of the physical interface according to the following table.

Instance	Value	Type of interface
1	2	Twisted-pair
2	2	Twisted-pair
3	1	The interface is internal to the device

### F6-01-08 Interface State

[USINT, Get, V]

This attribute indicates the current operational state of the interface according to the following table.

Value	Interface State
0	Unknown interface state
1	The interface is enabled and is ready to send and receive data
2	The interface is disabled
3	The interface is testing



4 ... 255	Reserved
-----------	----------

### F6-01-09 Admin State

[USINT, Set, V]

This attribute allows administrative setting of the interface state according to the following table.

Value	Admin State
0	Reserved
1	Enable the interface
2	Disable the interface
3 ... 255	Reserved

### F6-01-0A Interface Label

[SHORT\_STRING, Get, NV]

This attribute is a string that describes the interface according to the following table.

Instance	Value
1	Port 1
2	Port 2
3	Internal

### F6-01-0B Interface Capability

[Struct of, Get, NV]

This attribute indicates the set of capabilities for the interface according to the following table.

Bit(s)	Called	Definition
0	<b>Manual Setting Requires Reset</b>	It indicates whether or not the device requires a reset to apply changes made to the <b>F6-01-06 Interface Control</b> attribute. 0 = It indicates that the device automatically applies changes made to the <b>F6-01-06 Interface Control</b> attribute and, therefore, does not require a reset in order for changes to take effect. This is the value this bit shall have when the <b>F6-01-06 Interface Control</b> attribute is not implemented. 1 = It indicates that the device does not automatically apply changes made to the <b>F6-01-06 Interface Control</b> attribute and,

		therefore, will require a reset in order for changes to take effect. Note: this bit shall also be replicated in the <b>F6-01-02 Interface Flags</b> attribute in order to retain backwards compatibility with previous object revisions.
1	<b>Auto-negotiate</b>	0 = It indicates that the interface does not support link auto-negotiation (internal interface) 1 = It indicates that the interface supports link auto-negotiation (external interface)
2	<b>Auto-MDIX</b>	0 = It indicates that the interface does not support auto MDIX operation (internal interface) 1 = It indicates that the interface supports auto MDIX operation (external interface)
3	<b>Manual Speed/Duplex</b>	0 = It indicates that the interface does not support manual setting of speed/duplex. The <b>F6-01-06 Interface Control</b> attribute shall not be supported (internal interface) 1 = It indicates that the interface supports manual setting of speed/duplex via the <b>F6-01-06 Interface Control</b> attribute (external interface)
4 ... 31	Reserved	Reserved, shall be 0

### 8.12.8 Class 47h: Device Level Ring (DLR) Object

Class Code	Object Class	Access	Nr. of Instances
47h	Device Level Ring (DLR) Object	Get	1

The Device Level Ring (DLR) Object provides the configuration and status information interface for the DLR protocol. The DLR protocol is a layer 2 protocol that enables the use of an Ethernet ring topology. The DLR Object provides the CIP application-level interface to the protocol. The DLR protocol is fully specified in Chapter 9 of the publication "THE CIP NETWORKS LIBRARY, Volume 2, EtherNet/IP Adaptation of CIP".

#### 8.12.8.1 Supported Class Services

The supported **Class Services** of the Device Level Ring (DLR) Object are:

01h = Get\_Attribute\_All: used to read the value of all attributes.

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.8.2 Class Attributes

##### 47-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0003h.

Default = 0003h

#### 8.12.8.3 Supported Instance Services

The supported **Instance Services** of the Device Level Ring (DLR) Object are:

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.8.4 Instance Attributes

##### 47-01-01 Network Topology

[USINT, Get, V]

It indicates the current network topology mode. A value of "0" indicates "Linear" topology; a value of "1" indicates "Ring" topology.

### 47-01-02 Network Status

[USINT, Get, V]

This attribute provides the current status of the network based on the device's view of the network, according to the following table.

Network Status value	Description
0	Normal operation in both Ring and Linear Network Topology modes.
1	Ring Fault. A ring fault has been detected. Valid only when <b>47-01-01 Network Topology</b> is "1" = Ring.
2	Unexpected Loop Detected. A loop has been detected in the network. Valid only when <b>47-01-01 Network Topology</b> is "0" = Linear.
3	Partial Network Fault. A network fault has been detected in one direction only. Valid only when <b>47-01-01 Network Topology</b> is "1" = Ring and the node is the active ring supervisor.
4	Rapid Fault/Restore Cycle. A series of rapid ring fault/restore cycles has been detected. Similar to the Partial Network Fault status (3), the supervisor remains in a state with forwarding blocked on its ring ports. The condition must be cleared explicitly via the "Clear Rapid Faults" service.

### 47-01-0A Active Supervisor Address

[Struct of, Get, V]

This attribute contains the IP address (IPv4) and/or Ethernet MAC address of the active ring supervisor. The initial values of IP address and Ethernet MAC address shall be 0, until the active ring supervisor is determined.

### 47-01-0C Capability Flags

[DWORD, Get, NV]

The Capability Flags describe the DLR capabilities of the device, according to the following table.

Bit(s)	Called	Definition
0	<b>Announce-based Ring Node</b>	It sets if device's ring node implementation is based on processing of Announce frames.
1	<b>Beacon-based Ring Node</b>	It sets if device's ring node implementation is based on processing of Beacon frames.
2 ... 4	Reserved	Reserved, shall be 0
5	<b>Supervisor Capable</b>	It sets if device is capable of providing the supervisor function.
6	<b>Redundant Gateway Capable</b>	It sets if device is capable of providing the redundant gateway function.
7	<b>Flush_Table Frame Capable</b>	It sets if device is capable of supporting the Flush_Tables frame.

8 ... 31	Reserved	Reserved, shall be 0
----------	----------	----------------------

Default = 0082h = **Beacon-based Ring Node** + **Flush\_Table Frame Capable**

### 8.12.9 Class 48h: Quality of Service (QoS) Object

Class Code	Object Class	Access	Nr. of Instances
48h	Quality of Service (QoS) Object	Get	1

The Quality of Service (QoS) Object is used to treat traffic streams with different relative priorities or other delivery characteristics. Standard QoS mechanisms include IEEE 802.1D/Q (Ethernet frame priority) and Differentiated Services (DiffServ) in the TCP/IP protocol suite.

The QoS Object provides a means to configure certain QoS-related behaviors in EtherNet/IP devices.

The QoS Object is required for devices that support sending EtherNet/IP messages with non-zero DiffServ code points (DSCP), or sending EtherNet/IP messages in 802.1Q tagged frames.

#### 8.12.9.1 Supported Class Services

The supported **Class Services** of the Quality of Service (QoS) Object are:

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

#### 8.12.9.2 Class Attributes

##### 47-01 Revision

[UINT, Get, NV]

Object revision. The current value assigned to this attribute is 0001h.

Default = 0001h

#### 8.12.9.3 Supported Instance Services

The supported **Instance Services** of the Quality of Service (QoS) Object are:

0Eh = Get\_Attribute\_Single: used to read the value of an attribute.

10h = Set\_Attribute\_Single: used to write connection class attribute value.

#### 8.12.9.4 Instance Attributes

##### 48-01-01 802.1Q Tag Enable

[USINT, Set, NV]

This attribute enables (1) or disables (0) sending 802.1Q frames on CIP and IEEE 1588 messages. When the attribute is enabled, the device shall send 802.1Q frames for all CIP and IEEE 1588 messages.

#### 48-01-04 DSCP Urgent

[USINT, Set, NV]

DSCP value for CIP transport class 1 Urgent priority messages.

Default = 55

#### 48-01-05 DSCP Scheduled

[USINT, Set, NV]

DSCP value for CIP transport class 1 Scheduled priority messages.

Default = 47

#### 48-01-06 DSCP High

[USINT, Set, NV]

DSCP value for CIP transport class 1 High priority messages.

Default = 43

#### 48-01-07 DSCP Low

[USINT, Set, NV]

DSCP value for CIP transport class 1 Low priority messages.

Default = 31

#### 48-01-08 DSCP Explicit

[USINT, Set, NV]

DSCP value for CIP explicit messages (transport class 3 and UCMM) and all other EtherNet/IP encapsulation messages.

Default = 27

## 9 Integrated Web Server

### 9.1 Integrated web server – Preliminary information

EtherNet/IP encoders from Lika Electronic integrate a web server. This web-based user interface is designed to offer helpful functions and deliver complete information on the device that can be accessed through the Internet.

In particular it allows:

- to display and check the currently set parameters;
- to set the network communication parameters;
- to set some parameters such as the preset and the code sequence;
- to upgrade the firmware;
- to monitor the encoder and access some advanced maintenance functions.

The web server can be accessed from any PC running a web browser. Since its only requirement is a HTTP connection between the web browser and the web server running on the device, it is perfectly fitted also for remote access scenarios.

Before opening the EtherNet/IP encoder web server please ascertain that the following requirements are fully satisfied:

- the encoder is connected to the network;
- the encoder has valid IP address;
- the PC is connected to the network;
- a web browser (Internet Explorer, Mozilla Firefox, Google Chrome, Opera, ...) is installed in the PC or in the device used for connection.



#### NOTE

This web server has been tested and verified using the following web browsers:

- Internet Explorer IE11 version 11.1593.14393.0
- Mozilla Firefox version 73.0.1
- Google Chrome version 83.0.4103.97
- Opera version 68.0.3618.165



#### NOTE

Please note that the snapshot look may vary depending on the used web browser. The following snapshots have been taken from Mozilla Firefox.



## 9.2 Web server Home page

To open the EtherNet/IP encoder web server proceed as follows:

1. type the IP address of the encoder you want to connect to (in the example: 192.168.1.10, this is the default software IP address set at Lika, see on page 44) in the address bar of your web browser and confirm by pressing **ENTER**;




Figure 41 - Opening the web server

2. as soon as the connection is established, the web server **Home** page will appear on the screen;




Figure 42 - Web server Home page

Some commands are available in the menu bar of the **Home** page.

Press on the **Lika logo** to enter Lika's web site ([www.lika.biz](http://www.lika.biz)).

Press the **Documentation** command to enter the EtherNet/IP encoder technical documentation page available on Lika's web site (<https://www.lika.it/eng/products/rotary-encoders/absolute/ethernet/> ) where specific technical information and documentation concerning the EtherNet/IP encoder can be found.

Furthermore some commands are available in the left navigation bar. All the pages that can be entered through the commands in the bar are freely accessible except the **Upgrade firmware** page that is protected and requires a password to allow access.

These commands allow to enter specific pages where information and diagnostics on the connected encoder as well as useful functions can be achieved.

They are described in the following sections.

### 9.3 Encoder position and speed

Press the **Encoder Position-Speed** command in the left navigation bar of the Web server **Home** page to enter the page where the current encoder position and the current encoder speed are displayed.




Figure 43 – Encoder position and speed page

The current encoder position is expressed in pulses. For any information refer to the **23-01-03 Position value** attribute on page 98.

The current encoder speed is expressed according to the setting next the **23-01-19 Velocity Format** attribute on page 104 (by default it is expressed in counts per second). For any information refer to the **23-01-18 Velocity Value** attribute on page 104.



**NOTE**

The current encoder position and speed values are real-time processed and continuously updated (every 200 msec. on the screen).

Press the **Homepage** command to move back to the Web server **Home** page.

### 9.3.1 Specific notes on using Internet Explorer

The following options must be set properly on Internet Explorer in order to get the **Encoder position and speed** page to be continuously updated.

- Open the **Settings** menu;
- open the **Internet Options** property sheet;
- in the **General** tabbed page, press the **Setting** button available in the **History Browsing** section;
- under **Check for newer versions of stored pages**, click **Every time I visit the webpage**;
- press the **OK** button to confirm whenever requested.

## 9.4 Encoder information (EtherNet/IP attributes)

Press the **Encoder information** command in the left navigation bar of the Web server **Home** page to enter the **Encoder Information** page. In this page the complete list of the available EtherNet/IP attributes is displayed. Attributes are expressed in decimal notation, values are expressed in either hexadecimal or decimal notation. The MAC address of the connected encoder is shown under the page name.

Encoder Information		
MAC Address: 90:35:11:17:02:08		
<b>Input Process Data</b>		
Attr.	Description	Value
03	Position:	18731
24	Velocity Value:	0
n.a.	Warning/Error Flags:	00h
<b>Parameters</b>		
Attr.	Description	Value
42	Physical Resolution Span:	65536
43	Number of Spans:	16384
44	Alarms:	0000h
45	Supported Alarms:	1002h
46	Alarm Flag:	False
47	Warnings:	0000h
48	Supported Warnings:	2000h
49	Warning Flag:	False
50	Operating Time:	Not Supported
51	Offset Value:	0
100	Application-DSC FW Version:	00010001h
101	Hardware Version:	00010000h
102	Network-DSC FW Version:	00012301h
103	Wrong Parameters List:	0000h
106	Encoder Serial Number:	171502940
108	Network-DSC Serial Number:	A02D0674h

Figure 44 - Encoder Information page

The attributes listed under the **Input Process Data** section are process data and read-only (Get) access values.

The attributes listed under the **Parameters** section are the encoder configuration parameters; they can be either read-write (Set) or read-only (Get) access parameters.

For a complete description of the available encoder attributes please refer to the "8.12.5 Class 23h: Position Sensor Object" section on page 97.



### NOTE

Please note that the values shown in the **Encoder Information** page are "frozen" in the moment when the page is displayed. To update the values you must refresh the web page.



### NOTE

The attributes in the **Encoder Information** page cannot be changed even though they are read-write access attributes. To change the set values please enter the **Set Registers** page (see on page 139).

Press the **Homepage** command to move back to the Web server **Home** page.

## 9.5 Setting the Preset value

Press the **Set Preset Value** command in the left navigation bar of the Web server **Home** page to enter the **Set Encoder Preset** page and set/activate a Preset value. For complete information on the preset function please refer to the **23-01-13 Preset Value** attribute on page 102.

As soon as you press the **Set Preset Value** command a warning message (**Are you sure you want to change Preset Value?**) appears on the screen: it warns the operator about the awkwardness of the operation, thus he is required to confirm the procedure before continuing.




Figure 45 – Entering the Set Encoder Preset page

Press the **OK** button to proceed.

Otherwise press the **EXIT** button to abort the procedure. The **Set Preset cancelled!** message will appear on the screen. Press the **OK** button to move back to the Web server **Home** page.




Figure 46 - Preset operation aborted

If you confirm the procedure, the **Set Encoder Preset** page will appear on the screen:




Figure 47 - Set Encoder Preset page

The Preset value that is currently set in the encoder (see the **23-01-13 Preset Value** attribute on page 102) will be displayed in the **READ** box.

To change the Preset enter a suitable value in the **WRITE** box and then press the **Set Preset Value** button to confirm. The value has to be set in decimal notation.



#### NOTE

Please note that the Preset value is now saved temporarily in the **23-01-13 Preset Value** attribute. To save permanently the set Preset value in the **23-01-13 Preset Value** attribute, please press the **Save Preset** button. Should the power supply be turned off without saving data, the Preset value that has not been saved on the Flash EEPROM will be lost!

The preset value is set and activated for the position of the encoder in the moment when the preset value is transmitted. It is activated as soon as the value is confirmed by pressing the **Set Preset Value** button. We suggest activating the preset value when the encoder is in stop.

If you need to activate a value already set next to the **23-01-13 Preset Value** and displayed in the **READ** box in a different physical position of the encoder shaft, press the **Activate Preset** button, refer to the bit 0 **Activate Preset** in the **23-01-68 Command Register** attribute, see on page 111.



#### NOTE

At each confirmation and/or activation of the Preset setting, a message will appear under the buttons (see **No Command sent** message). It informs whether the operation has been accomplished properly or an error occurred (for example **Command was set correctly** if everything went well; or **Command Error!** if something went wrong).

Press the **Homepage** command to move back to the Web server **Home** page.

## 9.6 Setting the attributes

Press the **Set Registers** command in the left navigation bar of the Web server **Home** page to enter the **Set Encoder Registers** page. In this page the read-write (Set) access EtherNet/IP encoder attributes available in the Position Sensor Object (Class 23h) are displayed and their value can be changed.

For complete information on the encoder attributes please refer to the "8.12.5 Class 23h: Position Sensor Object" section on page 97.

As soon as you press the **Set Registers** command a warning message (**Are you sure you want to change Registers Values?**) appears on the screen: it warns

the operator about the awkwardness of the operation, thus he is required to confirm the procedure before continuing.




Figure 48 - Entering the Set Encoder Registers page

Press the **OK** button to proceed, otherwise press the **EXIT** button to abort the procedure. The **Set Registers cancelled!** message will appear on the screen. Press the **OK** button to move back to the Web server **Home** page.




Figure 49 - Register setting operation aborted



If you confirm the procedure, the **Set Encoder Registers** page will appear on the screen:




Figure 50 – Set Encoder Registers page

The values that are currently set in the encoder are displayed in the **READ** box.

To change any value enter a suitable value in the **WRITE** box next to the desired parameter and then press the button between the boxes to confirm. The values have to be set either in decimal notation or by using the drop-down menu (when available).

For complete information on the available registers please refer to the "8.12.5 Class 23h: Position Sensor Object" section on page 97.



#### EXAMPLE

The **23-01-10 Measuring Units per Span** attribute is currently set to "65536" (see the **READ** box in the first line of the Figure above). To change the set value enter a suitable value in the corresponding **WRITE** box of the same line and then press the **MEASUR. UNITS/SPAN** button to confirm.



#### NOTE

Please note that, after pressing the button between the boxes, the set value is saved temporarily in the attributes. To save it permanently, please press the **Save Parameters** button. Should the power supply be turned off without saving data, the values that have not been saved on the Flash EEPROM will be lost! For more information refer to the "7.1.6 Saving data" section on page 48.

Press the **Load Default Param.** button to restore all parameters to default values. Default values are set at the factory by Lika Electronic engineers to allow

the operator to run the device for standard operation in a safe mode. This function can be useful, for instance, to restore the factory values in case the encoder is set incorrectly and you are not able to resume the proper operation. For more information refer to the "7.1.7 Restoring defaults" section on page 48.

**WARNING**

The execution of this command causes all parameters which have been set previously to be overwritten!

**NOTE**

At each confirmation of the set parameters, a message will appear under the buttons (see **No Command sent** message). It informs whether the operation has been accomplished properly or an error occurred (for example **Command was set correctly** if everything went well; or **Command Error!** if something went wrong).

Press the **Homepage** command to move back to the Web server **Home** page.

## 9.7 Firmware upgrade

Press the **Upgrade Firmware** command in the left navigation bar of the Web server **Home** page to enter the **Firmware Upgrade** page. Please note that this is a password protected page, thus a password is requested to access the page.



### WARNING

Firmware upgrading process must be accomplished by skilled and competent personnel. It is mandatory to perform the upgrade according to the instructions provided in this section.

Before installation always ascertain that the firmware program is compatible with the hardware and software of the device. Furthermore never turn off the power supply during the flash upgrade operation.

This operation allows to upgrade the unit firmware by downloading upgrading data to the flash memory.

The firmware is a software program which controls the functions and the operation of a device; the firmware program, sometimes referred to as "user program", is stored in the flash memory integrated inside the unit. These encoders are designed so that the firmware can be easily updated by the user himself. This allows Lika Electronic to make new improved firmware programs available during the lifetime of the product.

Typical reasons for the release of new firmware programs are the necessity to make corrections, improve and even add new functionalities to the device.

The firmware upgrading program consists of a single file having .BIN extension. It is released by Lika Electronic Technical Assistance & After Sale Service.

If the latest firmware version is already installed in the unit, you do not need to proceed with any new firmware installation. The firmware version currently installed can be read next to the **Application-DSC FW Version** attribute in the **Encoder Information** page after connection to the web server (see on page 136; see also the **23-01-64 Application-DSC FW Version** attribute on page 109).



### NOTE

If you are not confident that you can perform the update successfully please contact Lika Electronic Technical Assistance & After Sale Service.

Before proceeding with the firmware upgrade please ascertain that the following requirements are fully satisfied:

- the encoder is connected to the network;
- the encoder has valid IP address;
- the PC is connected both to the network and the IO controller;

- a web browser (Internet Explorer, Mozilla Firefox, Google Chrome, Opera, ...) is installed in the PC or device used for connection;
- you have the SW\_ETH\_revX.Y.exe executable file;
- you have the .BIN file for firmware upgrade.

To upgrade the firmware program please proceed as follows.

1. Press the **Upgrade Firmware** command in the left navigation bar of the Web server **Home** page to enter the **Firmware Upgrade** page.
2. As soon as you press the **Upgrade Firmware** command a warning message (**Are you sure you want to update the flash?**) appears on the screen: it warns the operator about the awkwardness of the operation, thus he is required to confirm the procedure before continuing.




Figure 51 - Entering the Upgrade Firmware page

- Press the **OK** button to proceed, otherwise press the **EXIT** button to abort the procedure. The **Firmware upgrade cancelled!** message will appear on the screen. Press the **OK** button to move back to the Web server **Home** page.




Figure 52 – Firmware upgrade operation aborted

- If you confirm the procedure, the **Firmware Upgrade** page will appear on the screen: the operator is requested to submit a password before starting the firmware upgrade procedure.
- In the **Password** text box type the password **LIKA** (all uppercase letters) and then press the **Send Request** button.




Figure 53 – Firmware Upgrade page

6. If the password you typed is wrong, the following warning message will appear on the screen: **THE PASSWORD INSERTED IS INCORRECT. PLEASE RETRY!**. Please retype the password and confirm.
7. If the password you typed is correct, the following message will appear on the screen: **THE PASSWORD INSERTED IS CORRECT. THE WEB SERVER OF THE ENCODER IS STOPPED. NOW LAUNCH THE PROGRAM SW\_ETH\_REVX\_Y.EXE.**
8. The encoder is now ready to accept the firmware program: the web server is stopped and the communication with the encoder through the web browser is interrupted; if you need to exit the procedure and restore the communication you must switch the encoder off and then on again.
9. Now you must launch the SW\_ETH\_REVX\_Y.EXE executable file provided by Lika Electronic to continue with the procedure; X and Y indicate the version of the firmware upgrading program: REV1\_0 is the version 1.0.
10. Launch the SW\_ETH\_REVX\_Y.EXE executable file; the following page will appear:




Figure 54 - Firmware upgrade executable file

11. Type the encoder IP address in the **Remote IP Address** box. The default IP address set by Lika Electronic is 192.168.1.10.
12. Press the **FILE** command and then the **OPEN** command in the menu bar; once you press the **OPEN** command the **OPEN** dialog box appears on the screen: open the folder where the firmware upgrading .BIN file released by Lika Electronic is located, select the file and confirm. Hx in the file name shows the hardware version of the PCB; Sx shows the software version of the firmware upgrading file.



### WARNING

Please pay attention to install the BIN file that perfectly matches the series of the encoder to be updated.

HS58\_HMS\_EIP\_Hx\_Sx.bin  
HM58\_HMS\_EIP\_Hx\_Sx.bin

for XAC77-18-00-... singleturn encoder  
for XAC77-16-14-... multiturn encoder




Figure 55 - Selecting the firmware upgrade .BIN file

13. Some properties of the selected file are shown next to the relevant labels in the page: **File Name**, **File Dimension (byte)**, **File Date – hour**. Please check the file properties and ascertain that you are installing the correct upgrade file.



### WARNING

Before installation always ascertain that the firmware program is compatible with the hardware and software of the device.

Never turn the power supply off during the flash upgrade operation.

14. Press the **Send File** button to start the firmware upgrade process.

15. A download progress bar as well as additional information are shown in the page while upgrading the firmware.




Figure 56 - Updating the firmware

16. As soon as the operation is carried out successfully, the **FILE SENT CORRECTLY** message appears on the screen.




Figure 57 - Firmware upgrade process accomplished



17. Now you are required to turn the encoder power supply off and then on. Close the program.
18. Turn the encoder power supply off and then on to complete the operation.

**NOTE**

While downloading the firmware upgrading program, unexpected conditions may arise which could lead to a failure of the installation process. When such a matter occurs, the download process cannot be carried out successfully and thus the operation is aborted; error messages are displayed. In case of flash upgrade error, please switch the encoder off and then on again and retry the operation.

Press the **Homepage** command to move back to the Web server **Home** page.

## 9.8 Network configuration

Press the **Network Configuration** command in the left navigation bar of the Web server **Home** page to enter the **Network IP Configuration** page. This page allows the operator to configure the TCP/IP properties, that is how the encoder communicates with other devices in the network.

For further information on the network communication parameters please refer to the "6.6 EtherNet/IP Node ID" section on page 44.

**WARNING**

The network configuration must be accomplished by skilled and competent personnel.

As soon as you press the **Network Configuration** command a warning message (**Are you sure you want to change Network Parameters?**) appears on the screen: it warns the operator about the awkwardness of the operation, thus he is required to confirm the procedure before continuing.




Figure 58 - Entering the Network Configuration page

Press the **OK** button to proceed, otherwise press the **EXIT** button to abort the procedure. The **Set Network parameters cancelled!** message will appear on the screen. Press the **OK** button to move back to the Web server **Home** page.




Figure 59 - Network configuration aborted

If you confirm the procedure, the **Network Configuration** page will appear on the screen:

Figure 60 – Network Configuration page



#### WARNING

Only competent technicians, who are properly trained, have adequate experience and are familiar with computer architecture, network design and operating systems should configure the network communication parameters. The inappropriate setting of the network parameters results in an incorrect operation of the system.

In this page it is possible to set the parameters that affect the proper communication of the encoder in the TCP/IP network: IP address, Subnet mask, DHCP, DNS, etc.

The following table summarizes the default software IP address and the network configuration parameters.

IP Parameter	Value
IP address	192.168.1.10
Subnet mask	255.255.255.0
Default Gateway	0.0.0.0

To save the set values permanently, please press the **Save Settings** button. Should the power supply be turned off without saving data, the values that have not been saved on the Flash EEPROM will be lost!

**WARNING**

After any setting please note down the configuration values to have access to the encoder and the Web server pages in the future.

**WARNING**

If you enable the DHCP network protocol (DHCP = ENABLED), then the following default parameters are set for the encoder:

IP ADDRESS = 0.0.0.0

SUBNET MASK = 0.0.0.0

Please check that these settings are allowed by the DHCP server and they are valid address values.

Press the **Homepage** command to move back to the Web server **Home** page.

## 10 Default parameters list

Default values are expressed in hexadecimal (h) notation, unless otherwise indicated.

### 10.1 Attributes of the Class 01h Identity Object

Parameters list	Default values		
01-01-01 Vendor ID	0299h = Lika Electronic		
01-01-02 Device type	0022h = Encoder Device Profile		
01-01-03 Product code	0003h = XAC77-18-00-... singleturn encoder 0004h = XAC77-16-14-... multiturn encoder		
01-01-04 Revision	Device dependent		
01-01-06 Serial number	Device dependent		
01-01-07 Product name	HSx58x Singleturn Encoder = XAC77-18-00-... singleturn encoder HMx58x Multiturn Encoder = XAC77-16-14-... multiturn encoder		

### 10.2 Attributes of the Class 23h Position Sensor Object

Parameters list	Default values		
23-01-0B Position Sensor type	0001h = XAC77-18-00-... singleturn absolute rotary encoder 0002h = XAC77-16-14-... multiturn absolute rotary encoder		
23-01-0C Direction Counting Toggle	00h = CW rotation		
23-01-0E Scaling Function Control	01h = enabled		
23-01-10 Measuring Units per Span	262,144 = XAC77-18-00-... singleturn encoder 65,536 = XAC77-16-14-... multiturn encoder		
23-01-11 Total Measuring Range	262,144 = XAC77-18-00-... singleturn encoder 1,073,741,824 = XAC77-16- 14-... multiturn encoder		
23-01-13 Preset Value	0		
23-01-19 Velocity Format	1F04h = cps		
23-01-2A Physical Resolution Span	262,144 = XAC77-18-00-... singleturn encoder 65,536 = XAC77-16-14-... multiturn encoder		
23-01-2B Number of Spans	1 = XAC77-18-00-... singleturn encoder 16,384 = XAC77-16-14-... multiturn encoder		

23-01-2D Supported Alarms	1002h		
23-01-30 Supported Warnings	2000h		
23-01-64 Application-DSC FW Version	Device dependent		
23-01-65 Hardware Version	Device dependent		
23-01-66 Network-DSC FW Version	Device dependent		
23-01-6A Encoder Serial Number	Device dependent		
23-01-6C Network-DSC Serial Number	Device dependent		

This page intentionally left blank

Document release	Release date	Description	HW	SW	EDS file version
1.0	14.04.2023	First issue	1.0	1.0	1.1



Dispose separately

**lika**

**Lika Electronic**

Via S. Lorenzo, 25 • 36010 Carrè (VI) • Italy

Tel. +39 0445 806600

Fax +39 0445 806699



info@lika.biz • www.lika.biz